


"I wish I could show you <u>ALL</u> the clips we make at **TERRY'S'**

HT5A



You'd have a surprise-CLIPS in every possible shape and size, CLIPS in steel, bronze, stainless, plated, etc., CLIPS for every trade under the sun . . . and if you want a clip made to specification TERRY'S Research Department is there - ready and willing to give you the benefit of 96 years' experience.

Want to know all about springs? Here's a book packed with spring know-how from cover to cover — the finest of its kind today. Post free 12/6. and here are three " specials"



Sole Makers: HERBERT TERRY & SONS LTD., REDDITCH · LONDON · BIRMINGHAM · MANCHESTER

Take up the best hobby in the world PHOTOGRAPHY

Summer or winter, indoors or out, you can make pictures that will interest you as long as you live. It's easy to produce good results, once you know the way of it, and your snapshots will get better and better as you progress. The incomparable thrill of seeing a piece of white paper gradually build up, in the developer, and become a picture must be experienced to be believed. With most hobbies it takes a long time before things get really interesting, but, with photography, you get satisfying results without any delay at all. The chemicals and simple apparatus, which you will need



20

to make a start, are all included in the outfit described here. With these, and your own wit and common sense, you can not only delight yourself, but you will, very soon, be producing pictures of which you can be justly proud.

JUNIOR HOME PHOTOGRAPHY PRINTING OUTFIT THE comprises an 8-oz. bottle of UNIVERSAL developer, a 250-gram tin of ACID HYPO FIXING, Two xylonite dishes, a plastic printing frame, a packet of SEE-THRU printing masks, a plastic measure and a 2-oz. glass measure, together with a booklet giving full instructions.

JOHNSONS OF HENDON LTD., LONDON, N.W.4

THE 'E.W.' 2¹/₂" x 8" **CONVERTIBLE LATHE**

Now freely available to the readers of ' Practical Mechanics.' *E.W. I lathes are setting a new standard in the small lathe field for design, accuracy and adaptability. If you are interested in purchasing a small lathe, send 2¹/₂d. stamp for an illustrated leaflet, and compare the outstanding features.

Model A (plain lathe)			£13. 4.0
Model B (with leadscrew)		•••	£14.17.0
Model C (with leadscrew and backgear			£17. 1.0 £19.16.0
Model D (with leadscrew, backgear and	screwcutting	attachments)	
Gap bed models			8/3 extra
Obtainable from :			

WANSTEAD TOOL SUPPLIES. 48. HIGH STREET, LONDON, E.II.

A limited number available on credit terms.



GET AN OUTFIT

FROM YOUR DEALER

Precision Drilling Machine 0-lin. capacity

DELIVERY FROM STOCK

Maximur	n dista	nce cl	huck t	o base	1	5in.
Table					81in.	sq.
Base				151		
Column	****				mm.	
Speed rat	nge		4,26	0/1.990	1,020	475.
Motor	+ 7 + 10		1	h.p., 1	425 r.	p.m
Nett wel	ght	·			140	lbs.
	single					
1 17710						

£35 · 8 · 9


Pedestal model, £40.6.9. A.C. 3-phase machine, bench type f33.7.6. Pedestal model, £33.5.6. Mortising attachment (optional ex-tra), £5.5.0. Chuck Guard (optional extra), 12/-.

Chuck Guard (optional extra), 12/-Carriage paid mainland. All models available on our "OUT OF INCOME" terms. Example, A.C. singlo phase bench machine, deposit 28.17.9 and 12 monthly payments of 50/11.

illustrated literature gladly sent on



October, 1952



THE RAWLPLUG POPULAR OUTFIT

Larger sizes are obtainable Whatever your fixing problems, there's a Rawlplug Device that will solve it for you—easily and quickly. Rawlplugs make neat and absolutely firm fixings in any material from brick or tile to stone or slate, with a size for every

screw from No. 3 up to §in. coach screws. Rawlplug Tools are easy to use and ensure a perfect hole without damage to surrounding

surfaces. Other Rawlplug Devices include Rawlbolts for heavy duty fixings, Rawlanchors and Toggle Bolts for thin or hollow materials and Rawlclips for instant fixing of conduits and cables to girders-a device in fact for every need.



SOLDERING IRONS CERTAIN AND SIMPLE

This is a guarantee'd electric tool which will pay for itself many times over by repairing and giving longer life to metal household goods. In the workshop it is indispensable. Supplied with Standard bit, Hatchet or Pencil bit. Voltages 100/110, 200/220, 230/250. Universal AC/DC.

IRON CEMENT Rawlplug Iron Cement hardens very quickly and only needs mixing with water. It will repair Water and Gas pipes, Radiators, Cisterns, Buckets, Kettles, Saucepans, Stoves, Kitchen Utensils, etc., etc.





HEATLESS SOLDER No iron is needed with Rawlpug Heatless Solder which is in paste form and dries in a few minutes. It is very useful for quick repairs to metalwork, but is not suitable for wireless or electrical connections.

EX-GOV. BARGAINS

CHORE HORSE LIGHTING SETS. 12-15 v. 20 a. (300 w.). Complete ready to use with control box, animeter, etc. Fully Automatic and self-starting from 12 v. battery. Runs over 15 hrs. to the gal. Slightly used and guaranteed perfect, £16.10.0 cach. Two 6 v. 85 a. bats to suit, £6.10.0. Carr. Paid. MK. 32 TELESCOPIC RIFLE SIGHTS. 3X with E. and W. adjustments, 47.10.0 cach.

MOTOR BLOWERS. 24 v. A.C./D.C. Mk. III. Used, 12/6. New boxed³ 17/6. (See P.M. July. Hedge trimmer). Transformer to suit, 17/6. RADIO RECEIVERS. 6 v. RI124, complete with valves, 30/- each. Huge Quantity of Radio Gear. See our lists.

MOTORS. 230 v. A.C. & h.p., 30/- each. Unconverted Rotary, 21/-.

DELAYED ACTION TIME SWITCHES. With 8-day jewelled watch movement. Adjustable from 1 hr. to 36 hrs. by a pair of cal. dials. Brand New in sealed tins, 21/- each.

DRAWING INSTRUMENTS. Slightly soiled. Will do all that a £10 set will do, price 12/6 each.

OPTICAL

ENLARGER KITS. 35 m. or 21 sq. All parts ready to assemble with optical condensers and achromatic lens. 98/-. Plans only 3/6.

MICROSCOPE UNITS. 14X. Use with your ordinary camera for photo-micrography. Makes an ant look like an elephant, 45/- each. Cost 10 times the price. This unit has numerous uses. See our Booklets Nos. 1 and 2, 2/6 each. SMALL EPISCOPES. Make your own. Lens and Mirror with plans, 17/6. TELESCOPES. ASTRO or TERRESTRIAL. Make your own. It's dead easy. We have a wide choice of achromatic OGs and Orthoscopic cyepieces at prices to suit your pocket. See Booklets No. I and 2 for details, 2/6 each.

TELEPHOTO LENSES. Ideal for adapting to Excata or similar cameras. All approx. F5.6. Brand New and Bloomed throughout. sin. back focus 3in., 40/-. 8in. bf 4in., 45/-. Ioin. bf 6in., 50/-. All in plain, screwed sleeve.— No iris. EX TUBE to fit the lens only, 7/6.

BOOKLET, " HOW TO USE EX-GOVT. LENSES & PRISMS," No. 1& 2, price 2/6 each.

STEREOSCOPIC REPRESENTATIONS OF THREE DIMENSIONAL SCENES. (No viewers, No gadgets). A book that all should read and practice. To years ahead of the times. Worth its weight in Gold. For this month only we are offering 1,000 copies only at 7/6 each for publicity purposes. Usual Price is ONE GUINEA.

H. W. ENGLISH, **RAYLEIGH RD., HUTTON, BRENTWOOD, ESSEX**

DUROFIX



13.6

WLPLUG

The indispensable adhesive for instant use on crockery, glass, wood, metal, celluloid and the thousand and one things handled by the hobbies enthusiast. Instant drying, insulating, waterproof and heatproof. Durofix

is grand for repairs to electrical, sports and leather Durofix Thinner goods. and Remover is sold in handy 2 oz. bottles.

PLASTIC WV () APPLIED LIKE PUTTY, DRIES LIKE WOOD

Can be cut, planed, polished and painted like wood. Will take nails and screws like wood. It does not blister, crack or Rawlplug Plastic Wood is decay. actually the best quality product of its kind on the market. Plastic Wood Softener and Remover is sold in handy 2 oz. bottles.

THE RAWLPLUG COMPANY LIMITED CROMWELL ROAD LONDON 5.W.T



professionals

For reliable, economical home repairs, Ersin Multicore is the solder to use. It cuts costs by avoiding wastage-the 3 cores of exclusive Ersin Flux ensure that there are no solder lengths without flux. It saves time because the 3-core construction means thinner solder walls, quicker melting and speedier solder-





ing. It can be used for every soldering job, replacing stick solder, fluid and paste fluxes.

SIZE I CARTON PRICE 5/- EACH



PERMAG ELECTRIC LOCOMOTIVE MECHANISMS





4-coupled Mechanism

Motor Bogie Unit

The most efficient and powerful units for Gauge '0'

The permanent magnet is of a high-grade alloy and will retain full magnetic power for many years. The Brush gear is of improved design and the laminated armature and commutator are of the finest-quality materials. The motors are mounted in brass frames, having bushed bearings for the steel axles on which turned cast-iron driving wheels are fitted.

> No. 1462/0 4-coupled Mechanism No. 1463/0 6-coupled Mechanism No. 1471/0 Motor Bogie Unit.

Price £4.2.0 plus 18/3 P.T. " £5.0.0 plus 22/3 P.T. " £4.7.6 plus 19/6 P.T.

Write for our Gauge '0' Model Railway Catalogue G.O.12, which gives details of the whole range of Gauge '0 ' Locomotives and Components. Price 1/-.

T-LOWK


SEE OUR STAND No. 22 AT THE "MODEL ENGINEER" EXHIBITION, OCTOBER 20-29.

Head Office & Works: NORTHAMPTON

London Offices : 112 High Holborn, W.C.2.

Manchester : 28 Corporation Street.

TD.



3

6-coupled Mechanism



4-coupled Clockwork Mechanism

This unit is of robust construction and suitable for fitting into most types of locomotive bodies. Fitted with powerful spring and rachet. Reverse, Brake and Brake Re-start hand controls, also from track by using the Ramp. Rail. Machine cut gears. Complete with Pressure diecast driving wheels 15 in. dia.

THE VERY PART YOU NEED IS WAITING FOR YOU

THE VERY PART YOU NEED IS WAITING FOR YOU RADIO CONTINOL OF CAMERAS, Model Boats, Cars or Alrphanes or the opening of Garage Doors at remote distance. We hold stock of all necessary components. Price List 1id., Data 5/6. TAPE RECORDING of volce or music. Tape Recorders always in stock and also all soares for repairs or parts for home building a recorder. Tape recording Amplifiers. List and data 1/-ELECTRIC MOTORS. Small ones for model boats and all sizes of h. for personal, domestic and industrial use. A lew (write first) ex-Government motors converted for sewing-machine use 24/- Large motors promptly rewound, but not small ones (mostly not worth ft). List 3d. **PHOTO ELECTRONIC FLASH.** All parts and data stocked to enable you to build your own at greatly reduced price. Data and list 9d. **VALVES.** Every type of current velve and many obsolete still available. Always quote the type number, usually on the glass. If not known quote the type numbers of other associate valves and we shall be able to tell the doubtful one. Data list 6d. **ADDU COMPONENTS.** Every make of modern component in stock. We cannot offor list as stock is too vast and varied. This also includes all Television com-ponents. Send old part for replacements but if burned beyond identification please include some helpful information. **ELECTRIC FIRE BARS AND ELEMENTS.** Electric Iron Elements, Sheetric Kettle Elements, Hair Dryer Elements, Aquarium Elements, Photo Glazing Ele-ments, Soil Heating Elements, Electric Banket Elements. Send old part for replacement. ELELWIN CELLS. Extremely sensitive to light. Cells available for all pur-

replacement. SELENIUM CELLS. Extremely sensitive to light. Cells available for all pur-poses. Please state your need to enable us to advise best type. Kit of parts to make your own photo light meter. Hes two ranges, indoor and outdoor. Price 15/-. List of

make your own photo light meter. Has two ranges, indoor and outdoor. Files 20 TRANSFORMERS. Little 'uns up to big 'uns. State your need and sond sketch it possible to enable us to advise accordingly. **ROTARY TRANSFORMERS.** For working model trains from D.C. mains. Out-put 12 volts at 2 amps. and 5 volts for track lights for signals. 2:0 volts D.C. 37(6, or 20 A.C. 47(6, Post 2:6. **VIBRATORY POWER PACKS.** 6 volt D.C. input and 230 volts output. These power packs will work a midget radio set provided it is fitted with 15 amp. flamment range of valve and enables the domestic radio to serve temporarily as a car radio. 57(6, Post 2:6. Util AVS. Hundreds of different types in stock. Some the size of a piece of lump.

power packs will work a basic he domestic radio to serve temporarily as a car radio. 57/6. Post 2/6. RELAYE. Hundreds of different types in stock. Some the size of a piece of lump sugar sensitive to .2 milliamp, current change as we use in models simplanes. 27/6 each. When writing please give full description of your intended use as it helps us to quicker estimate your need of the best type suitable. DECMAGNETISER. 220 volt A.C. for demagnetising small drills, screwdrivers, tweezers, watch parts, etc. 3/6 each. SPRAY GUNS, For use with ordinary cylindrical type vacuum cleaners. These guns are supplied with three nipples, one each for cellulose, paint, distemper. They are also very good for spraying insecticide against garden pests, ants, cockreaches, etc., or for oil spraying car springs and thereabouts. 15/-FLECTRIC BLANKETS cost a tidy penny but daptable you can easily and cheaply convert a spare blanket into a winter blessing. The element all ready to stitch in, 35/-, complete with switch and 2-pin plug for 230 volt, mains, double bed size.

Size. HIT ARING AID MINIATURE HEADPHONES. Light weight supplied with length of flex and plugs ready to plug into radio's extension spraker sockets. Quite safe, no risk for elderly people. 17/6 pair. MIDGET RADIO RECEIVERS work night and day, no power or batterles required. Ideal for lonely jobs or remote places. 21.-. Headphones to suit 8/11

MIDGET RADIO RECEIVERS work hight and day, no power or batteries required. Ideal for lonely jobs or remote places. 21-. Headphones to suit 8/11 pair. Actual and earth is necessary, 5'- 346 the lot. CONTACT MICROPHIONES for guitar or other musical instruments, 19/5. Crystal microphones for public address 24.40. ELECTRIC MOTORS WITH ATTACHED GEAR BOX, detachable. Motor can be driven by 200 volt A.C.D.C. or 24 volt D.C. or if driven by power (wind or water) will generate above voltages. Motor has many uses, Insulation tester, car flat battery starter, rotary display stand, convert to electric band drill. 24-complete with comprehensive instructions.



flooring blocks accurately manufactured from Prime quality Scandinavian Oak ready for laying with full instructions. At a modest cost you can transform concrete or old wooden surfaces into a beautiful polished Oak Parquet floor that will last a lifetime, and add to the value of your property.

THE SURREYBOARD CO. LTD. 72, HIGH STREET, CROYDON, SURREY



B.A.	SCREWS,	NUTS,	WASHERS, I	ETC.
4BA I/-, 2 GRUB SCR A SELE	2/6 O Nuts 21 xs, 55 3A 4/6 Bl ags, Assd. 2/-, 2BA Aluminium Rivets, BA 1/6 doz. Br. Ter LEWS, Assd. 1/6, 6B CTION FROM PRICES	3A , 5/6 3A , 5/- 3A , 4/- 3A , 4/- 3A , 4/- 3A , 4/- 2/3, 4BA 2/-, 6B/- assd. 1/6. Br. minals, w/nuts, A 1/3, 4BA 1/4, OUR HUG 5 PER HAL	Brass Washe bock 6/- Assd. 1/6, OBA ., 5/- IBA 2/-, 2BA ., 4/- 3BA -1/9, 4BA ., 3/9 5BA 1/6, 6BA ., 3/6 8BA 1/6 ., 4/- A1/10, 8BA 1/10, Eyelets and knurled Terminal Nuts, 61 heavy type, NP, 6d. each, 5 2BA 1/6 per 3 doz. SE STOCK OF SCF F-GROSS.	2/- 1/10 1/8 1/6 Rivets, 3A 8d., 5/6 doz.
	kel Plated. CP., BRASS INP 1/6 	Cadmium Pl.	, Round. CS., Counte SC., Self-colour. STEEL 1/5 3 ^B CH NP 1/6 4 RH SC 1/7 4 CS CP 1/9 4 RH SC 1/7 4 CS CP 1/9 4 RH SC 2/- 76 "," 2/1 4 RH SC 2/3 8 CS CP 1/4 4 "," 1/6 4 RH SC 1/7 1" CS CP 1/4 5 "," 1/6 4 RH SC 1/7 1" CS CP 1/8 RH SC 1/7 1" CS CP 1/8 RH SC 1/7 1" CS CP 1/8 RH SC 1/9 1 6 "," 1/9 1 6 "," 1/9 1 6 "," 1/10 1 7 " H/H	I/ I/ I/- I/1 I/1 I/1 I/1 I/2 I/4 I/5 I/5 I/5 I/7 2/6 2/9
4 BA 18" CH 14" 9(32, 58" 12" 78"	BRASS	**************************************	STEEL 1/10 1"CS CP 2/3 """"""""""""""""""""""""""""""""""""	1/2 1/3 1/4 1/2 1/4 1/4 1/4 1/4 1/6 1/9
3" RH	INP 2/10 ,, 3/- ,, 3/3 SC 3/3 NP 4/3 ×/H SC 10/-	1. CH NP 1. SC 1. RH 3. CS NP 1. SC 1. SC	4/3 1/2 H/H SC 3/- 1/2 Lge RH 5/- 3/2 RH SC 4/9 1/2 CH 4/- 1/2 RH CP 4/9 1/2 CS ,,	1/9 2/- 2/- 2/6 2/9 2/-
8BA are "CH are "CH are "CH are "CS are "CH are "CS are "CH are "CS are "CH are "CH	., 2/6 ., 1/8 ., 2/3 ., 1/9 ., 2/6	1* CH SC 8 RH NP 10 10 10 10 10 10 10 10 10 10	STEEL 2/- 1" CH CP 2/2 3" CH CP 2/6 3" CH " 2/9 7'/32" RH " 2/9 4" CH NP 2/10 3" RH CP	2/- 2/- 2/2 2/2 2/3 2/3
ALL ABOVE POSTAGE EXTRA. Large stocks of Copper and RESISTANCE WIRES : Paxolin type TUBING ; Laminated Bakelite and Ebonite PANELS ; TUFNOL and EBONITE TUBES and ROD. GERMANIUM CRYSTAL DIODES G.E.C. GLASS TYPE in x in the SILICON CRYSTAL VALVE				

B.T.H. LATEST TYPE MOULDED IN THERMO-SETTING PLASTIC Both Wire Ends for Easy Fixing. 4/6 each, postage 2jd. SILICON CRYSTAL VALVE 3/6 each, postage 2jd. Fixing Brackets 3d. Extra.

Wiring diagram for a cheap, simple but high quality Crystal Set included with each Diode and Crystal Valve. As above, but with Germanium Crystal Diode, 16/-. Postage 11d.

POST ORDERS ONLY PLEASE.

Adjustable Iron Cored Coil.

RECEPTION GUARANTEED

Polished wood cabinet, 15/-, post IId. A REAL CRYSTAL SET NOT A TOY

CRYSTAL SET


Send stamp for comprehensive lists. Trade supplied.





October, 1952

SENSATIONAL TAPE RECORDING INVENTION BY QUALTAPE ENGINEERS



Your Radio or Radio Gramophone can now be used in conjunction with the Qualtape Deck and Preamplifier. Radio and Records faithfully and perfectly recorded, without use of Microphone and whilst listening. Reproduction is guaranteed equal to your radio. Microphone jack is provided for other purposes. Wow is non-existent. Post Card brings illustrated brochure and details of all Qualtape manufactures. Demonstrations by appointment.

Price £13 : 13 : 0 Address: DEPT. P.A. ELECTRONIC SERVICE (Hallamshire) LTD. BUTTON LANE Telephone 1 Sheffeld 2160



N.11. Telephone: ENTerprise 5234




5

ONE PLASTIC MODELLING MATERIAL

From rough, rugged stone to smooth animal muscles any surface, any shape can be easily modelled, moulded or cut from plastic, ready-to-use PYRUMA. Baked or air-dried to stone-hardness, your Pyruma models can be painted or enamelled in realistic colours, as instructed in the Illustrated Book offered below. Send for it today and learn how to make model—

HOUSES, BUILDINGS FOR MODEL RAILWAYS, DOCKS AND AIRPORTS, SHIPS, MODEL FURNITURE, ANIMALS, FIGURES, RELIEF MAPS, Etc., as well as utility objects such as ASHTRAYS, BOOKENDS, MENU HOLDERS, PAPER WEIGHTS, ORNAMENTS AND DECORATIVE OBJECTS.

NO SKILL OR SPECIAL TOOLS REQUIRED.



PRICE

D)

Q

14

This book should be in your hands!

> Written by one of our foremost experts on handi-; crafts, its 108 pages are full of clear illustrations and concise instruction on how to excel in the art of cutting.

October, 1952

If you already use X-acto this book will show you how to get the best from these remarkably versatile knives and tools. If you don't, you'll soon see how much more accurate your work can become; how, in fact, with X-acto there's more skill at your fingertips. At 4/6d the X-acto Handbook will be the Craftsman's Book of the Year. It should be in all craftworker's hands. See that you get your hands on a copy as soon as possible. From all X-acto Stockists or from

TRIX LTD. (Dept. A) 11 OLD BURLINGTON ST. LONDON, W.1

SPARKS' DATA SHEETS

660

are the Safest, Simplest and Finest Constructional Sheets of Guaranteed and Tested Radio Designs.

THE "ENTERPRISE" A Very Efficient 3-Vaive plus Rect. TRF. MediLong-wave Receiver for A.C. Mains. 41 Watts of Quality on Radio and P.U. Good Range and Selectivity. A Fine Economical Set. DiSheet, etc., 32/1 Post Paid. THE "ENSIGN." Good Quality from the "Local" "Stations. In areas where high selectivity is not essential. Plus most pleasing P.U. reproduction. 41, Watts Output. Med/Long-waves. Easy and Economical to Build. D/Sheet, etc., 3/24 Post Paid.

SPARKS MEANS SATISFACTION

THE "CHUMMY" PORTABLE. An All-dry 2-Valver which does give really good "Phone sigs. on Med. and Long-waves. Self-contained aerial and batteries. Tested in Dorsot 70 miles from nearest Regional Station and 115 miles from Droitwich. Size approx. Sin. x 4jin. x 2jin. Data Sheet, 2020 Post. Paid.

Station and 115 miles from Droitwich, Size apport, 8in, x 2in, bata Sheet, 374 Post Paid.
 THE "MIDDY." A 2-valver which gives amazing results on M. and L. Waves and "Ship-to.Shore" transmissions when used with a short aerial. Good speaker results. All-dry batteries. The Ideal Set for Camp-ing, Caravans, The Den and Yachts. Dorset tested. D/Sheet, 324 Post Paid.
 THE "POCKET PAK." All-dry Pocket I-valve Portable Frame aerial. Good 'phone sigs. Med. Wave. 3/24 Post Paid.
 THE "CUISELL" A 3-Valve T.R.F. circuit for use with a short aerial. Very efficient in any area. All'y batteries. DHE "CUISELL" A 3-Valve T.R.F. circuit for use with a short aerial. Very efficient in any area. All'y batteries.
 DHE "CUISELL" A 2-Valve Plus Rect. Fine Speaker results on ML waves. 324.
 THE "CUP FOLK'S TWO." An A.C.D.C 2-Valver, plus Rect., having Station Selec-tion by Switch. ML Waves. Chassis approx. 51 x 51 x 15. Ins. Med Ior Portable or House model. Fine range in any area. All-dry Batteries. 324.
 Data Sheets available from a Crystal Set

Data Sheets available from a Crystal Set to a 9-valve Radiogram. Stamp for List, -valve Radiogram. Stamp for COMPONENTS SUPPLIED

ORMOND SPARKS (M) L. 48A, HIGH ST., SWANAGE, DORSET.


Plastic Marble The entirely new Karlena artificial Stone for casting Bookends, Ashtrays, Wall-vases, Statuettes, etc. Sets rock hard with a scintillating crystalline structure like marble or alabaster for colour, veining, texture, density and hardness. It is enormously strong, highly resistant to heat, impervious to water. Natural "veining" can be simulated in any colour. A range of pigments is available for this purpose. Most attractive marble effect in models, plaques and statuary.

W.A.G. BRADMAN

FR.S.A

For the close

scrutiny of fractures or de-



Rubber Moulds ELASTOMOLD is high quality synthetic rubber for making flexible moulds that faithfully reproduce the most minute details of ornamentation and surface texture. ELASTOMOLD is permanent and ideal for repetition casting or plaques, bookends, ashtrays, and art models. Moulds can be taken from any type of material including Karlenite, wood, metal, plaster, cement, stone, glass, ivory. Elastomold is incredibly simple to use and has great dimensional stability, but flexes easily for the release of cast without damage to fine detail or undercuts.

Send for full_details of this new, fascinating and profitable craft KARLENA ART STONE COMPANY LTD., PLASTICS 2.F. DIVISION, DEANSGATE ARCADE, DEANSGATE, MANCHEST MANCHESTER, 3

55.

The Ultra Lens is an illuminated magnifier. It is a re-vealing eye of six actual diametrical magnifications,

No instru-

ment you can buy willmore

quickly justily and pay for

itself.

NO MAN CAN KNOW TOO

MUCH OF HIS PRODUCT

S

which brings out points of strength or weakness, and enables the most minute measure-ments to be gauged accurately. Accuration whether you are engaged in manufacturing, buying or selling, it is an ally of real value. fects on sur-faces, cutting edges, faults ual Size 63/4 × 15/8 in tools, cracks in 15, stings, the Itra Lens Ultra is invaluable. REITISH MADE Revealing every detail with startling exactness, highly magnified and bril-liantly illuminated in natural colourings, it presents in many instances in there our suspected data which can be used to advantage. Price 45.15.0 complete in cardboard case with spare bulb, battery and transparent measuring scale. Packed in luxury velvet lined case, 10/- extra. Postage and Packing 1:6. full pa ticulars on request

THE ULTRA LENS COMPANY

75, Finsbury Court, Finsbury Payement, London, E.C.2.

Army Carbon Microphones with handle and switch, 5/9. Trans., 4/6.

This is the range of X-acto interchangeable blades and tools that keep X-acto Knives ever-sharp. There's a blade for every cutting job.

Izin. Pulleys, take zin, spindle. Double groove. Cast Ali. 1/6.

M/C. Microphones with switch in handle, 7/6. Trans. to match, 5/-.

High Resistance Phones, 12/6. Low Resistance, 8/6 pair.

h:p. A.C./D.C. Motors, 200/240 v.:or 110 v. D.C., 18 spindle each end, 46/-. Powerful Small Blower Motors, 24 v. A.C./D.C., 14/6. As used for the Hedge Trimmer.

24 v. Blower Motors, double the size of the above, 22/6.

Transformers. Input 200/240 v. Sec. Trapped 3-4-5-6-8-9-10-12-15-18-20-24-30 volts at 2 amps., 21/6. 12 months' guarantee. This is ideal for use with the 24 v. Blower Motor.

Selenium Rectifiers F.W. 12-6 volt, 3A., 14/6. 4A., 26/-. 6A., 30/-. 3A., 5/6.

D:P.D.T. Relays. Operate at 200/300 volts D.C., 8/6. D.P. Make and Break, 8/6. Any combination or voltage can be supplied at varying prices.

New Deaf Aid Miniature Valves DL72 and CK512AX, 9/-, Ideal for radio control units. Valves

New Exide 2v. Accumulators II A.H. 71_

VCR97. Cathode Ray Tubes, New and Crated, 45/-. Bases, 3/6. Tufnol Panels, 12in. x Bin. x Jin., 4/6.

2 v. Battery Operated Mine Detector Amplifiers, complete with Headphones and Magnetic Crystal Microphones, 30/-. Trans., Input 230/240, Output 40 voit. I Amp. Tapped at 25 volt, 21/6.

All Carriage Paid. THE RADIO & ELECTRICAL MART 253B. Portobello Road. London, W.II. Park 6026

Nore skill at our fingerlips

HANDICRAFTS WITH RECEIC

NEWNES PRACTICAL MECHANICS

510P! _ DO YOU KNOW HOW TO GET TO THE "MODEL ENGINEER" EXHIBITION!

Held at the New Horticultural Hall, London, from the 20th/29th October. This is a *must* for all Model Engineer enthusiasts. Entries are received from all over the World and valuable prizes are awarded in the various competition sections. Also on view will be all the latest developments in new tools and techniques for model makers while the Services and Industry will have many attractions on their stands.



October, 1952

VALUABLE NEW HANDBO

Have you had your copy of "Engineering Opportunities"?

The new edition of "ENGINEERING OPPORTUNITIES' is now available-without charge-to all who are anxious for a worthwhile post in Engineering. Frank, informative and completely up to date, the new "ENGINEERING OPPOR-TUNITIES" should be in the hands of every person engaged in any branch of the Engineering industry, irrespective of age, experience or training.

We definitely Guarantee "NO PASS - NO FEE"

This remarkable book gives details of examinations and courses in every branch of Engineering, Building, etc., outlines the openings available and the essential requirements to quick promotion, and describes the advantages of our Special Appointments Department.

WHICH OF THESE IS **SUBJECT**? PET YOUR RADIO ENGINEERING Gen. Radio Eng.-Radio servicing. Maintenance & Repairs-Sound Film Pro-jection - Telegrophy Telephony - Television -C. & G. Telecommunica-time

MECHANICAL

8

Gen. Mech. Eng.—Main-tenance — Draughtsman-ship—Heavy Diesel—Die & Press Tool Work—Weld-ing—Production Eng.— Jig & Tool Design—Sheet ing—Production Eng.— Jig & Tool Design—Sheet Metal Work—Works Man-agement — Mining — Re-frigeration—Metallurgy.

AUTOMOBILE

ENGINEERING Gen. Automobile Eng.— Motor Maintenance & Repoirs — High Speed Repoirs — High Speed Diesel—Garage Mngment.

ELECTRICAL ENGINEERING Gen. Elec. Eng.—Elemen-tary & Advanced Elec. Technology — Installations Draughtsmanship—Supply —Maintenance — Design —Electrical Traction — Mining Electrical Eng.— Mining Electrical Eng.-Power Station Equipment, etc.

CIVIL

CIVIL ENGINEERING Gen. Civil Eng.—Sanitary Eng.—Structural Eng.— Road Eng. — Reinforced Concrete—Geology.

BUILDING Gen. Building—Heating & Ventilation—Architecturol Draughtsmanship — Sur-veying—Clerk of Works —Carpentry and Joinery —Quantities—Valuations.

1

1

tions

WE HAVE A WIDE RANGE OF AERONAUTICAL COURSES AND COURSES IN FORESTRY, TIMBER TECHNOLOGY, PLASTICS, G.P.O. ENG., TEXTILE TECHNOLOGY, ETC., ETC.

One of these qualifications would increase your earning power ! WHICH ONE ?

A.M.I.Mech.E., A.M.I.C.E., A.M.I.P.E., B.Sc., A.M.Brit.I.R.E., A.F.R.Ac.S., A.M.I.M.I., L.I.O.B., A.R.I.B.A., A.M.I.H. & V.E., M.R.San.I., F.R.I.C.S., A.M.I.E.D., CITY & GUILDS, COMMON PRELIM., GEN. CERT. OF EDUCATION, ETC.



WHAT THIS BOOK TELLS YOU

- HOW to get a better paid, more interesting job.
- HOW to qualify for rapid promotion.
- HOW to put some valuable letters after your name and become a "key-man" quickly and easily.
- HOW to benefit from our free Advisory and Appointments Depts.
- WHERE today's real opportunities are . . . and HOW you can take advantage of the chances you
- are now missing. HOW, irrespective of your age,
 - education, or experience, YOU can succeed in any branch of Engineering that appeals to you. 144 PAGES OF EXPERT

CAREER-GUIDANCE

You are bound to benefit from reading "ENGINEERING OPPOR-TUNITIES," and if you are earning less than £15 a week you should send for your copy of this enlightening book now-FREE and without obligation.

.

TO: B.I.E.T. 410A. SHAKESPEARE HOUSE, 17-19, STRATFORD PLC., LONDON, W.1.

Please send me FREE and without obligation, a copy of "ENGINEERING **OPPORTUNITIES.**" I am interested in (state subject, exam., or career)

NAME

ADDRESS

WRITE IF YOU PREFER NOT TO CUT THIS PAGE

KIND

25 7 6 75

8

3

6

Only Ild.

stamp is needed if posted in an nsealed envelope.

VORL

2.

9

OCTOBER.

1952

PRACTICAL

By The Editor

EDITOR

F. J. CAMM

9

VOL. XX No. 226

Owing to the paper shortage "The Cyclist," "Practical Motorist," and "Home Movies" are temporarily incorporated.

MECHANICS

FAIR COMMENT

Sonic and Supersonic Speeds

HE aircraft display at Farnborough helicopters must sometime follow present demonstrated beyond all doubt the superiority of British aircraft and the considerable lead we have over many other nations. The fact that tragedy supervened is a reminder that a price must be paid for all the scientific advancements. However carefully designs are prepared and stresses calculated it is only by practical tests that the theories can be proved. Mechanical flight has suffered most in this respect from its earliest days.

The early pioneers had no data on which to work and they had to find out by placing their own lives in peril and risking death. The fact that to-day that peril is much less as a result of their work is but a poor consolation for the loss of highly specialised scientists.

Not so many years ago it was thought that the limit of speed was that of sound and that it would never be possible to break through the sound barrier. It is now being done by many different makes of aircraft both in this country and others. Those who have never heard the sonic boom as a plane breaks through that barrier have a thrilling experience before them. Speeds of 800 m.p.h. and more are now common and the experience and data gained is paving the way for that time probably during the present century when interplanetary travel will be possible. There is, in fact, only practical limits to speed and certainly speeds will have to be of the order of thousands of miles an hour if journeys to the moon are to be undertaken.

The shape of the modern 'plane takes us back to the darts of our schoolboy days and the man who first conceived the idea of shaping a dart was ahead of his time and discovered something of tremendous import. The piston engine is passing although it will remain with us for many more years. The turbo-jet car is still only a remote possibility of the future. As far as aircraft is concerned many other problems remain to be solved.

Special runways, for example, are necessary for them, because the tremendous heat burns up the tarmac. Jet

developments.

A STEERABLE RADIO TELESCOPE

N another direction this country is regaining the lead it formerly had. The Government, through the Department of Scientific and Industrial Re-search and the Nuffield Foundation have decided to provide a steerable radio telescope for the Manchester University at a cost of £336,000.

The very first large telescopes was built in Great Britain by Herschell and Rosse in the 18th and 19th centuries, but we were unable to maintain our lead because such telescopes require clear skies and good atmospheric conditions. It was for this reason that the large telescopes of the 20th century have been built in America on Mount Wilson and Mount Paloma.

In Great Britain climatic conditions severely handicap visual astronomy. Since the war the techniques of radio and radar as applied to astronomy have yielded a series of discoveries about the universe, and in this field the pioneering work of research astronomers at Manchester and Cambridge Universities have given this country a pre-eminent and prominent position.

At Cambridge, for example, important results have been attained using interferometric methods, and at Manchester a fixed radio telescope has been used to

SUBSCRIPTION RATES	
including postage for one year	
Inland 14s. per annu	m. .
Abroad 14s. per annu	m.
Canada 13s. per annu	m.
Editorial and Advertisement Office : "Pract Mechanics," George Newnes, Ltd.,	ical
Tower House, Southampton Street, Strand, W.	C.2
'Phone : Temple Bar 4363	
Telegrams : Newnes, Rand, London.	
Registered at the G.P.O. for transmission Canadian Magazine Post.	by
Copyright in all drawings, photographs	ind
articles published in "Practical Mechanics"	is
specially reserved throughout the count	ries
signatory to the Berne Convention and	
U.S.A. Reproductions or imitations of any	of
these are therefore expressly forbidden.	

pick up radio waves reaching the earth from sources as far distant as the great spiral nebula of Andromeda, which is no less than 750,000 light years away, and at both Universities radio waves have been recorded from light sources in space which do not coincide with known visible stars.

In 1920 the telescope on Mount Wilson showed that the Milky Way was a system of stars far more extensive than hitherto imagined and that it would take 100,000 years travelling at the speed of light to traverse it. One of the remarkable features of these discoveries is the fact that man's eyesight is able to penetrate the atmosphere of the earth. It was in 1931 that the discovery was made that radio waves were reaching the earth from outer space. From the number of queries we have received regarding the construction of telescopes it is evident that many of our readers are interested in this absorbing subject, and we shall from time to time publish further articles on telescope construction.

OUR COVER

TERE we are in our new dress and with more pages. This is a sign, if a small one, that the rigid economy of the past ten years is passing; whilst costs of production and paper are still very high when compared with pre-war, they are none the less showing a decline. This journal is one of the first to pass along to its readers the benefit of those reductions.

From now on our front cover will feature one of the main articles in each issue, and we shall welcome suggestions from readers as to the style of article which lends itself to cover illustrations.

We already have under construction a number of devices, models, and other apparatus which readers have requested during the past year but which space restrictions have prevented us from de-veloping. The ample space we now have has released the shackles and we shall welcome your suggestions.

The finished tape recorder in its cabinet.

A TAPE recorder is an instrument which utilises a length of plastic tape coated with a magnetic material, upon which it is possible to impress speech, music and other sounds, and which can be made to reproduce those sounds without any form of processing. There are now available

various arrangements by means of which the complete process may be carried out, but they all involve certain fundamental principles. First, the impressions on the tape are carried out by amplifying the sounds through an amplifier similar to that used in a radio receiver,

and then feeding them to a small magnetic unit known as a Recording Head. This bears some resemblance to a telephone earpiece, and the variation across a magnetic gap is passed across the magnetic surface of the tape which is drawn across the gap by a motor at a certain speed. For very high quality recordings the speed is fast (15in. per second), and for speech it is slow (3½in.

speech it is slow $(3\frac{1}{2}in. per second)$. The tape is carried on a metal spool similar to those used in the amount to to those used in the amateur home cinematograph, and when a suitable record has been made the tape is wound back on to its original spool and then passed forward again, either across a different head or across the Recording Head, but this time the head is connected to the input side of an ampli-fier and the fluctuations introduced in the winding of the head are amplified and fed to a loudspeaker. If the recorded tape is passed across a strong magnetic field the recorded impressions will be "erased." This, briefly, is the complete process, but it is rendered very complicated by the fact that in order to obtain a suitable impression on the tape the recording head must carry alternating current impulses, upon which the recording may be superimposed, and the erasure must be carried out also with a suitable magnetic field to avoid making a noisy background to the record. The motors must, of course, pull the tape past the head very steadily and without any jerkiness or unevenness, and the recording amplifier must have certain forms of tone correction introduced to maintain a suitable quality standard. Similarly, when playing back the recorded music, further forms of tone correction are



Designed and Built in the "P.M" Laboratory Full Constructional Details of a Recording and Reproducing Unit Utilising a Commercial Tape Deck

required, and thus the complete recorder would appear to be a complicated piece of equipment. tape-deck which incorporates the motors for driving the tape, and the Erase and combined Recording and Playback Head. In addition, as the waveform produced by the

special oscillator unit which is used for erasing and recording must conform to a high standard, a commercial oscillator unit is used for this part of the combined apparatus. The work is, therefore, greatly simplified and there is little difficulty in setting up the complete equipment and obtaining a high-class performance without the need for special test or measuring instruments. In order to

make the recorder of greater use, arrangements are made in the circuit for coupling the recorded signal into any standard amplifier or broadcast receiver so that a high level of output may be obtained, instead of playing back via

the loudspeaker which is built into the instrument. This speaker acts as a monitor when making a recording, and when switched to playback it will deliver sufficient volume for normal domestic purposes. The circuit is also arranged to permit of the plugging-in of a meter, whilst it is also possible to include a

The amplifier unit of the tape recorder The Circuit

In the Recorder which is described here, the complete process has been greatly simplified by using separate amplifiers for the recording and reproducing, and a commercial small neon to indicate the recording level, instead of using the loudspeaker. (Figs. I and 2.) Controls

There are three controls, one adjusting




Fig. 1.—Theoretical circuit of the recording section of the equipment.

the level when recording, one adjusting the playing-back volume (with which is com-bined the on/off switch), and a rotary two-position switch. This changes over the connections to the head and connects it to the recording amplifier or the playback amplifier, and to enable the user to know which part of the circuit is in use a section of the switch is connected to a special signal lamp which changes colour and should be wired as shown in the sketch, wiring to show "red" when recording, and "green" when playing back. The switch also disconnects the H.T. supply from the oscillator unit when playing back—an essential point, as the erase head must be "dead" when the tape passes it or the recording will be erased.

On the actual tape deck there is a further switch which provides for the tape to travel past the heads at a speed of 7½ in. per second, and, in addition, it may be rewound at a very high speed after recording. This high-speed feature is also available for winding-on the tape when it is desired to pick out a portion of recording in the centre of the tape, or for "dubbing" purposes. The high speed permits the normal 1,200ft, spools which are used on the machine to be fully rewound in approximately I minute, whilst the playing time of the spool is about 30 minutes. As the head which is fitted records on only half the width of the tape, the spool is turned over and reversed when full and the recording thus continued on the other half of the tape, thereby providing approximately I hour's playing. The tape may be used over and over again almost indefinitely, and the only

deterioration which				
is a noisy backgrou				
many recordings ha	ve beer	n made	and wiped	
out				



This illustration shows the chassis and tape deck out of the cabinet, and also the microphone.

LIST	OF C	COMPONENTS
		STORS
(Erie	e Resis	tor Company)
RI-1M Q 1	W.	R25-820 9 1W.
R2-39K Q		R26-1.5M Q W.
R3—150K Ω		R27-2.2K Q 1W,
R4-1.2K Ω		R28-270 9 1W.
R5-120K Q		R29-220K 2 W.
R615K Ω 1	W.	R30-22K 9 1W.
R7-2.2K Q	₩.	R31-1.2M 0 +W.
R8-3.6K Ω	₿W.	R32-125K & W.
R9-100K S	₩	R33-1M Q 1W.
R10-22K Q	₩	R34-1.5K Q 1W.
R11-240K S	₹ <u></u> ₩.	R35-100K Q 1W.
R12-120K S	₹ 1W.	R36-150K Q 1W.
R13—15K Ω	1W.	R37-50K Q 1W.
R14-2.2K Ω		R38-470K Ω 1W.
R15-240K· s		
· R1682K Ω		R40-1.5K 9 1W,
R17-500K S		$\mathbf{R41} - \mathbf{10K} \ \Omega \ \frac{1}{2}\mathbf{W}.$
R18-50K Ω		R42-100K \Quad 1W.
R19—1.5K Ω		R43500К Ω ±W.
R20-200 Ω		R44—560 Ω 1W.
R2156K Ω		R454.7K Q 1/2W.
R22-620K 4		R46-2,500 Ω 5W.
R23470K £		R47-2,500 \$ 10W.
R24-5.6K Ω	IW.	

CONDENSERS (T.C.C.) C1-16 μ F. elect. cond. 450V. wkg. C2-16 μ F. elect. cond. 450V. wkg. C3-0.1 μ F. paper cond. 250V. wkg. C4-0.01 μ F. paper cond. 250V. wkg. C5-0.1 μ F. paper cond. 350V. wkg. C6-0.50pF. mica cond. 250V. wkg. C5--0.1 μ⁻, paper cond. 250V. wkg. C6--50pF. mica cond. 250V. wkg. C7--0.01 μ⁻F. paper cond. 250V. wkg. C9--500pF. mica cond. 350V wkg. C10--0.1 μ⁻F. paper cond. 350V. wkg. C11--0.01 μ⁻F. paper cond. 350V. wkg. C12--0.5 μ⁻F. paper cond. 350V. wkg. C13--200pF. mica cond. 250V. wkg. C14--0.001 μ⁻F. mica cond. 250V. wkg. C14-0.001 μ F. mica cond. 250V. wkg. C15-0.01 μ F. paper cond. 250V. wkg. C16-0.1 μ F. paper cond. 250V. wkg. C17-16 μ F. elect. cond. 350V. wkg. C19-0.25 μ F. paper cond. 250V. wkg. C20-0.01 μ F. paper cond. 250V. wkg. C21-0.25 μ F. paper cond. 250V. wkg. C22-0.002 μ F. paper cond. 250V. wkg. C23-0.001 μ F. mica cond. 250V. wkg. C23-0.001 μ F. mica cond. 250V. wkg. C24-0.25 μ F. paper cond. 350V. wkg. C24-0.25 μ F. mica cond. 250V. wkg. C24-0.25 μ F. mica cond. 250V. wkg. C25-300pF. mica cond. 250V. wkg.




Fig. 2.-This is the play-back section of the instrument.

C27-8.0 μ F. elect. cond. 350V. wkg. C28 - 50.0 μ F. elect. cond. 25V. wkg. C29 - 0.25 μ F. (type 543). C30 - 16 μ F. (CE29P). C31--16 μ F. (CE29P). C32--16 μ F. (CE29P). C32--16 μ F. (CE29P). C34 - 9 μ F. (CE29P). C34-8/F.

- VR1-0.5M. Potentiometer without switch Type SG/1. (Reliance Mfg.) VR2— 0.5m with S.P.S.T. switch (Re-
- liance Mfg.) International Octal Valveholders. (Clix.)
- 2 **B8A Valveholders (Clix.)**
- Knobs—K365. Knob—K357.
- Plug-P38. Socket-J11.
- Plug and Socket—P73.) Signal Lamp—D670.
- High Impedance Microphone with Table

Bulgin.

- Stand—Model C51Z. (Lustraphone.) 1 Mains Transformer (350/0/350 at 100mA.; 6.3V. at 4A.; 5V. at 3A.) (Radio Supply
- Co.) 2 L.F. Chokes (100mA., 2002.) (Radio
- 1
- Supply Co.) 8in. Loudspeaker with Transformer. S810T. (Whiteley Electrical Co.) Coaxial Plugs and Sockets, L734/P and 4
- L604/S. (Belling and Lee.) 4-pole two-way Rotary S 24in. spindle. (Teleradio.) Świtch with 1
- 8 1 at EF37A.
 - Mullard. at 6SL7. 1 at 6J5. 1 at 5Z4G. at 6SN7. Brimar.
- 1 at 6V6. 1 Lane Tape Deck MK2. (Verdik Elec-

- Lane Tape Deck MK2. (Vertik Electronic Co.)
 Lane Oscillator Unit type OC/1 with Valve. (Verdik Electronic Co.)
 Metal Chassis, 16in. by 12in. by 3in. (PrecIsion Equipment Co.)
 yard of single-screened Flex.
 yard of 80-Ohm Coaxial Cable.
 Tinned Copper Wire and Sleeving, Nuts, Bolte atc.

- Bolts, etc. Screened Top. Cap Connector.
- 1 Reel H.C. Emitape and 1 empty Spool. 3 Rubber Grommets.


- 10 Soldering Tags. 1 Cabinet. (J. Tallon and Sons.)

Construction

Rear view of the

amplifier unit.

As may be seen from the illustrations and the picture on our cover this month, the complete equipment is housed in a neat table cabinet the overall size of which is governed by the dimensions of the tape deck. This is approximately 11 9/16in. by 16 5/16in., and the amplifier chassis measures 16in. by 12in. by 3in. deep, and is drilled as shown in Fig. 3. The holes for the valveholders are all drilled the same size, but



and one end is joined to the lead connected to the centre contact and the other lead should be passed through the eyelet in the cap and soldered to the metal cap. The screening round the lead should also be soldered cleanly round the cap where it enters so that the grid connection is completely screened.

To assist in wiring up the switch a separate sketch is given in Fig. 5, and the leads to the signal lamp should be carefully chosen after looking inside the lamp and noting the position of the coloured filters. There are actually three colours and three contacts, and it is a simple matter to select the correct contacts for the colours which are used. A separate diagram of the valve pin connections of the different types of valve is also given in Fig. 7, whilst the colour code and connections of the special Bias and Erase Unit are shown in Fig. 6. There are two screened flexible leads on this component, and as will be seen from the wiring diagram one is joined to St whilst the

Fig. 3.—Drilling details of the chassis.


two of the valves are mounted on strips of rubber to avoid any microphonic troubles, and as these valves are of the miniature type this leaves ample clearance round the normal type of valve hole. The rubber actually used in the prototype was $\frac{1}{4}$ in. thick strip as supplied for car floor mats and was cut $2\frac{1}{4}$ in. by $1\frac{1}{2}$ in., with a hole to clear the B9A valveholder. The bolts holding these strips to the chassis must be provided with locknuts so that the rubber is not clamped too tightly and the "floating" effect on the valves thus lost. As there are chassis earthreturn soldering tags attached to these bolts it is essential to see that the tag is locked solidly to the chassis but the rubber is not pulled tight.

5

0

EP EP

When the chassis is drilled mount the components as shown, noting that an earthing tag is fitted to each of the valve-holders (with the exception of V8), as well as to two of the coaxial sockets on the rear chassis runner. The earth side of the components in each stage of both amplifiers is taken to a common point, which is the earthing tag referred to, and it is important to see that this is done. The draughtsman, in the wiring diagram, Fig. 8, has had to show them connected together, but separated from the earthing tag, in order that the drawing may be clear, but in the case of V2, for instance, the metal braiding of the lead from S1b and S1, and the ends of C9, R8, C4 are all taken to the tag to which R10 is shown connected. Other points in the disgram must be similarly treated, and this greatly assists in keeping the amplifiers stable. Note that R33, the small $\frac{1}{4}$ watt, I megohm resistor is mounted inside the screening cap which is fitted to the top of V6. It should have its end wires cut short



12

Fig. 4. — Theoretical circuit of the mains portion of the recorder.

NEWNES PRACTICAL MECHANICS

other is taken from the unit on top of the chassis up to the erase head. A grommet is fitted to a hole in the centre of the four electrolytic condensers and through this hole is passed a short length of twin flex, and a single lead which is connected to the common H.T. - point.

All details of the wiring are clearly shown in Fig. 8 and the usual precautions of using insulated sleeving over certain wires should be taken, and the maker's instructions concerning the colour code used on the mains transformer should be followed. A threepoint mains connector is fitted so that a lead may be taken to earth to assist in keeping the unit quite hum-free and also as a safety measure. If, however, the power point to which the recorder is connected is of the two-point type, simply ignore the third

(Continued on page 38)






Fig. 5.—Details of wiring of the change-over switch.








Fig. 8 .- Detailed illustration of the wiring of the chassis. See text regarding the connections made to the various tags marked "E."

shaped

By R. K. BATTSON

handled when rubbing down, as the end

All the foregoing applies to carvel-built

to edge. If the plank you are using calls for clinker-built boats, with the planks over-lapping, this is quite easily represented by proceeding as described, but before painting,

strips of stout cartridge paper. You will have

to get the shape of each strip by trial and

error (most of them look roughly like a banana) but start, of course, from the bottom

seeing that the first strip each side (called the garboard strake) butts nicely against the

keel; and when you have got one strip to

fit, use it as a pattern for cutting its opposite number. If you work this way, laying on one "plank" each side, you will keep the lines of the "planking" level when viewed from the ends. Stout cartridge paper is just

about the scale thickness for a small boat,

but keep the strips as narrow as possible,

both from the point of view of scale appearance, and also because wide strips will not

lie to the curve of the bilges. Use Durofix,

which is colourless and clean-working, and

Carry out all the processes carefully, taking plenty of time (after all, modelmaking is fun,

the paper will then take any desired finish.

covering the outside with narrow,

grain will be rather weak.

Clinker-built Boats




Fig. 1.-Boats for model liners.

NE of the more tricky (and in some cases, tedious) jobs in ship modelling is the making of the small boats which every ship carries for one purpose or another. But really good boats are as impor-tant to the appearance of a model as any other part, and the following notes may be helpful.

The long rows of lifeboats on a minia-ture liner (there may be as many as sixty) can be easily, quickly, and really well represented in the following way. Prepare a stick of wood the width and depth of the boats, its length being that of the whole line. With a small plane, round the bottom edges of the strip, and form the top surface to a flat V, as in Fig I. Next, mark off the length of each boat and, with a three-cornered file, cut nicks on each side at the marks, going nearly, but not quite through the strip at each point. Then, with sand-paper, shape the file-cuts into smoothly-rounded contours (do this delicately, because the nicked strip is now rather weak) so that there are no flats or angles anywhere.

Now paint the strip with at least three coats of white and, when dry, draw with a fine pen and Indian ink, the outline of the canvas covers with their securing tabs, pre-serving the sheerline of the gunwale, and showing the top strake as solid black between the tabs.

To mount the boats on the model insert three beheaded pins point upwards in the boat deck, and gently press the line of boats down on the pinpoints, fitting dummy davits of wire when the strip is in position. The sketches should make the job quite clear, and the result is extremely convincing.

Interior Detail

For larger models, where the desired boat may be two or three inches long, with proper interior detail, the following method is most effective; the essential tool is a fretsaw or machine with a tilting cutting table.

Take two pieces of wood, the length and breadth and, respectively, one-third and two-thirds the full depth of the boat (measured at the ends) and, on the thicker piece, draw first the plan of the boat, and another line 1/16in. inside and parallel to it. Setting the cutting table on a slight bevel, cut out the middle of the piece along this inner line, so that the sides are left thicker at the bottom than at the top (Fig. 2). Keep this cut-out piece for a moment.

Now sandpaper the inside of the cut dead

A Novel Method of Making Miniature Lifeboats for

Model Liners

smooth, and glue this piece to the other, or bottom, section. Place it under pressure in a vice, and leave till absolutely set.

Next, lay the whole thing on its side, and cut, first the sheerline, and then, with it flat, the plan, going as close to the inner edge as you can.

Temporarily replace the cut-out piece you have saved (without it the now thin sides would break-up) and, with plane and gouge, shape the outside of the boat in the ordinary then smooth with sandpaper. way

Next, the ribs, in stripwood or thin card, can be cut and glued in place, keeping them fairly closely-spaced, and when these are dry, two stringers, or longitudinal strips, each side, at gunwale and thwart level. Glue these with Durofix or "balsa cement," as they have to be held to the inner curve, and need to set quickly. Then cut and fit the thwarts, or seats, gluing them to the lower stringer each side ; add knees, or brackets, of thin wood, and finish off the gunwale with a capping strip of card. You can get the right curve for this by using the cut-out piece as a pattern for the inner edge. Then, on the outside, cut and glue stripwood to represent stem and sternposts, and keel, making sure they all fit the curvature properly.

Painting

The now-finished boat can be painted or varnished as desired, and a neatly-coiled




Fig. 2.-Various stages in the construction of fully-detailed boats.

painter of thin cord (first passed through a lasts), and you will end up with model boats little glue to make the coils stick) laid on to be proud of. in place, though the holes for them should be indicated, and as many oars as are required shaped up and laid inside. This method of boat-making gives a much

cleaner effect than any attempt at hollowing from solid (or even the well-known method of hollowing each half and gluing to a central keelpiece) and is much less risky to the hands, which can be severely gashed if, as often happens, the gouge should slip; it is also much easier. It applies equally well to either a double-ended boat or one with a flat transom, though in the latter case, the stern must be cut on a bevel, and delicately

lust Published WORKSHOP CALCULATIONS TABLES AND FORMULÆ

Tenth Edition

by F. J. CAMM

A handbook dealing with methods of calculation, solution to workshop problems, and the rules and formulæ necessary in various workshop pro-cesses. It contains all the information a mechanic normally requires.

From all booksellers. 6/- nct. by post 6/6 from the publisher, GEORGE NEWNES LTD. (Book Dept.), Tower House, Southampton Street, W.C.2

CLOSE-UP PHOTOGRAPHY

How Enlarged Photographs of Various Subjects Can be Taken With Simple Apparatus By F. G. RAYER

LOSE-UP photos may be taken with any kind of camera, including the simplest box type, and open up a new field of interest. Coins, stamps, and other small objects can be photographed indoors, by natural or artificial light, while during the summer, flowers, insects, and many other subjects of interest will be found. No permanent changes of any kind need be made to the camera and the total cost, in most cases, will be extremely low. In view of this, it was thought that readers would be interested in some examples of how such photographs can be taken with simple and inexpensive apparatus.

Clip-on Additional Lens

The usual type of camera with focusing adjustment cannot be used with objects nearer than about three feet. The simplest way to get nearer objects into focus is to use an additional lens, which may be clipped in position in front of the existing lens. Such an arrangement is that illustrated in Fig. 1. Here a narrow strip of metal has been cut out and bent into a ring which will clip on to the front of the camera lensmount. A few small projections, turned inwards, serve to prevent the additional lens slipping out at the front. This arrangement can be brought into use with the minimum of trouble, and is readily removed when ordinary photographs are to be taken.

Ranges from 9in. to 3ft.

The extra lens may be of almost any type, provided it is a positive (e.g.—magni-fying) lens. The more powerful the lens the nearer to the camera must the object being photographed be. Photographic dealers can supply such lenses in many diameters, or old spectacle lenses or magnifying lenses of any kind can be used. Assuming that the camera ordinarily focuses from 3ft. to infinity, as is usual, a weak lens would change this from about 2ft. to With a more powerful lens, a range 3ft. of about 1ft. 3in. to 2ft. may be obtained, while an even more powerful lens would focus from about 9in. to 1ft. 3in. If a lens of about the same diameter as the lensmount of the camera is obtained, fitting will be easier. Larger lenses may be ground down fairly easily with an emery wheel, as optical glass is soft. (Only the edges should be ground, of course.)

Determining Exact Focus

If some unknown lenses are to hand, or have been obtained, it will be necessary to see at exactly what distance the objects to




Fig. 1.-A push-on holder for close-up lens Fig. 2.-A simple fitment for bax cameras made from metal strip.

be photographed must be. This can easily be done by removing the film from the camera and inserting in its place a strip of thin paper. With the usual camera taking 120 films, this strip will need to be about 24in. wide. The length is immaterial. The extra lens is then placed in position and the camera shutter set open as for a "Time" exposure. Objects may then be viewed on the paper, and the distance for sharp focus measured. A certain amount of focusing can also be done with the usual adjustment on the camera, but the distances marked here will not now




apply. Having determined the correct distance from camera to object with the lens or lenses to be used, this can be measured off, when photographing, and the test would not need to be carried out again.

With reflex cameras, or cameras with a back focusing screen, the effect of the extra lens will be immediately seen. But with a roll-film camera with no such arrangement. the foregoing test will be necessary. Ground glass, or a "fixed" plate, can be used in-stead of the paper.

With Box Cameras

This simple type of camera usually has no lens-mount to which a ring may be clipped, and no focusing arrangement (except in the better-class models). A simple method of securing the close-up lens in position is shown in Fig. 2. Three pieces



shaped from cardboard.



(Above) Minute blooms of the elder-flower. (Actual photo roughly 100 times natural size.)

(Left) Common housefly that had impaled itself on cactus spine. (Actual photo roughly 100 times natural size.)

of card are cut to the size of the front of the camera. One piece has a hole which will accommodate the lens; the other pieces have a somewhat smaller hole. A "sand-wich" is formed, with the lens held between the pieces, and this can be held in front of the camera by passing elastic bands com-pletly round the camera and assembly.

The distance at which objects should be is determined as already explained, and this simple method has been used with perfect success.

With Increased Extension

Another method of photographing close-up objects is to increase the distance between the camera lens and film, no extra lens being used. This cannot be done with some types of camera; with others the lens may be unscrewed and an extension tube used, as shown in Fig. 3. For ordinary close-up shots this tube only needs to be very short-a tube about an inch long will enable objects up to within 1ft. or so to be (The exact result of adding photographed. such a tube will depend upon the focal length of the lens.) The distance may be determined as already explained, or, with the type of camera shown, the object itself will be seen on the reflex screen, so that the result of adding the tube is immediately apparent.

Using Cardboard Tube

Such tubes can be made without much difficulty, and are also stocked in various sizes by some dealers. A stout cardboard tube can be used, provided it is reasonably

sheet is best if the object is light; with a dark object a light background will throw it into relief. White paper can be used for the reflector; its purpose is to lighten the Focusing shadows on the side away from the lamp. Assuming that a 100 watt lamp is used, in a holder with reflector, then 1/5th second exposure at F8 would be correct, for normal subjects, with the lamp Ift. from the subject and using 30° Sch. panchromatic film. For orthochromatic films the exposure should be doubled. If the lamp only has an ordinary type of shade the exposure should be doubled again. The light should be allowed to fall directly on the subject, but not upon the Original lens (screwed into tube) lens of the camera.

Subjects

Focusing hood

Extension

tube

These are numerous, and some have been suggested. Others include models of all kinds, copies of illustrations, pictures, and so on. There are also many natural-history subjects, and lighting and other conditions

can be adjusted exactly according to the photographer's needs when the objects are photographed indoors. As a guide, the appended photographs serve to show what is possible, and

to suggest subjects. That of the fly was taken by daylight, indoors, extension tube and close-up lens being used together to obtain a large image. The elder-flowers were taken by artificial light, a close-up lens being used. The midget receiver was taken by daylight, no lens being close-up used, but an extension tube added as explained. There scarcely any limit to the degree of magni-fication which may be obtained. It might be added, in conclusion, that the purchase of a camera for such photography may have come to the reader's mind. If so, a secondhand plate camera will be most suitable (excluding the more expensive film cameras).

Using Plates

It will have a focusing screen, and such cameras may be obtained very readily and cheaply because the average person now pre-fers to use film. Plates $(\frac{1}{4} \text{ plates} - 4\frac{1}{4} \text{in. x}$ $3\frac{1}{4} \text{in.}$ —are a useful size) can be purchased easily, and have the advantage that even one or two alone may be developed, whereas the whole spool needs to be used, with roll film, before the results can be seen. Storing and indexing is also simplified.

much easier.

Another advantage in using plates is that they remain flat thus making printing so

Miniature 2-valve radio made by the writer shown in comparison with full size.)

a matchbox. (The original photograph showed the set approximately

United States" New-Liner lhe


Reflector Cbject Object on screen reversed Electric Camera

Fig. 4.—A useful lighting arrangement when taking photographs indoors.

between lens and film with the former in its usual position.

Indoor Photography

Indoor photographs by artificial light are particularly suitable during the darker evenings, and the arrangement shown in Fig. 4 is both simple and satisfactory. The back sheet may be cloth or paper. A dark



The new 53,000-ton U.S. liner " United States," the largest commercial vessel ever built in America, arrived at Southampton recently after crossing the Atlantic in record time on her maiden voyage. She completed the crossing from Ambrose Light to Bishop Rock in 3 days 10 hours 40 minutes at an average speed of 35.59 knots—10 hours 2 minutes faster than the "Queen Marv's" record of 1938.



October, 1952

Reflex camera

size.

to the front of the camera.

the image on the film become.

Exposure to Use

Fig. 3.-Using extension tubes for close-up

shots.

well-made so that the lens is kept parallel

to the tube, thereby bringing the distance

down to a few inches. When this is done,

the photograph can be larger than natural

powerful the additional lens, the larger will

When using a close-up lens alone no

which using a close-up tens anote in increase in exposure is necessary. During bright summer weather, shots out-of-doors would require about 1/100th second at F8 aperture, with a 30° Sch. film. ("Selo-chrome" films are of such a speed.) This

would need to be doubled during somewhat

overcast weather, and doubled again (e.g.,

When using extension tubes some increase

in exposure is necessary. Roughly $1\frac{1}{2}$ times

the normal exposure can be used for tubes

about $\frac{3}{4}$ in. to $I_{\frac{1}{4}}^{\frac{1}{4}}$ in. long, with double the

exposure for tubes 14in. to 2in. long. Here,

the exact figure depends upon the focal

length of the lens, but is not critical. If desired, the user may work it out by

measuring the length of the tube and noting

what proportion this is to the distance Back sheet

1/25th second) during dull weather.

The longer the tube, and the more

A close-up lens may be added in addition

FOUR HEDDLE MD LOOM

Constructional Details of an Inexpensive and Efficient Weaving Machine for Home Use By G. G. CRAWSHAW

(Continued from page 408, September issue)

HE reed unit is now mounted in a floating frame and this consists of two side pieces 12in. long, each let into the corner of a block $2\frac{1}{2}$ in. $\times 1\frac{1}{3}$ in. $\times \frac{1}{3}$ in. and firmly fixed thereto by two screws. (The lower corner of the block and attached side pieces must be rounded off for about 1 in., as in Fig. 8.) A hole to accommodate a stout 1 in. screw freely is drilled through the ends of the blocks opposite the side pieces about half an inch from the end and equidistant from the top and bottom edges. These two blocks are now joined by screwing on to the end faces a piece of wood 18in. \times 1 $\frac{1}{2}$ in. \times $\frac{3}{2}$ in., using two 1 $\frac{1}{2}$ in. screws at each end.

A fin. hole is now drilled fin. from the top end of all four side pieces and the reed frame hung in the outer frame by passing a tin. rod 181in. long through the four holes, placing a small plain washer between each pair of side pieces when doing so. Not more than five or six 4 BA threads should be cut on each end of the rod, and nuts are screwed tightly thereon to secure it in position. The object of having so few threads is to obviate the necessity of having an additional lock nut at each end.

Main Frame

We now come to the main frame of the loom which consists of two side members $254in \times 54in \times 2in$. (or tin.). These pieces 251in.×51in.×1in. (or Iin.). are joined together by the front and back bars of the loom and are also screwed to the heddle mounting frame by means of four stout screws each side, as previously mentioned. The position of this frame is about 131in. from the front of the loom and about 91in. from the back. The front and back bars are $19\frac{1}{2}$ in $\times 1\frac{1}{4}$ in \times through both into the edge of the frame, the being to raise the top edge of the frame, the object being to raise the top edge of the bars I lin. above the level of the frame. The screws must be very stout and well driven The bars are located 2in. from the home. ends of the loom, and the top edges should be rounded off and well smoothed down with fine sandpaper.

The holes for the rollers are cut centrally in the side pieces, the centres thereof being 1 in, from the ends. The rollers have been made from old blind rollers and are quite satisfactory. The plain disc at one end was retained, as it forms a good stop to prevent the cellura form elidication and the set of the set of the the roller from sliding out of its position; otherwise a disc of larger diameter than the roller must be screwed or glued on. The other end of the roller requires squaring off carefully to make it a good fit in the socket of the ratchet wheel which has to be screwed on to it. The rollers used are 1 in. in diameter and the length between the inner face of the retaining disc and the ratchet wheel allows a clearance of kin. for free turning, and, similarly, the bearing holes must have a slight clearance for the same reason.

A dowel rod 17 in. $\times \frac{1}{2}$ in. should have a $\frac{1}{2}$ in. hole drilled through it 1 in. from each end and a matching pair of holes also drilled through the roller which should allow the rod to be centrally placed when tied thereto by means of cords through the holes. Both rollers are treated similarly.







Fig. 9 .- Showing the approximate position of the shuttle- race.



View from beneath

(Right) Showing the construction and placing of the reed mounting. The reed is in the fully forward position.






A $\frac{1}{2}$ in, hole 1 in, deep should be drilled vertically in the top edge of each main frame side member $\frac{3}{2}$ in, in front of the edge of the heddle frame box. Two $9\frac{1}{2}$ in. $\times\frac{1}{2}$ in. steel rods should have a length of $2\frac{1}{2}$ in, bent at right angles at one end and $\frac{1}{2}$ in, at the other end. Push the longer end into the 1 in, hole drilled to receive it and drill a $\frac{1}{2}$ in. $\times\frac{1}{2}$ in, hole to receive the other end in the front bar in the place now indicated by its position. Drive in firmly, seeing that the rod is reasonably level, the purpose being to provide a rail to hold the trailing weft out of the way of the lower end of the reed and its form of shuttle race. The loom should now be stood on end,


The loom should now be stood on end, front uppermost, and the reed assembly laid in position with the lower ends of the dents about jin. below the level of the heald eyes, as previously mentioned. Make sure that the assembly is laid truly in position, then carefully mark the position of the bearing screw holes against the inside of the frame and make gimlet holes for the screws, which should be driven in firmly enough to keep each side of the mounting from rubbing on the inside of the loom frame, but not so tightly as to make it in the least stiff to swing backwards and forwards.

Shuttle Race

For this type of loom, two unusual, but invaluable accessories make their appearance; namely, a miniature shelf fixed on the front of the reed mounting to serve as a form of shuttle race; and a pair of detachable brackets, to be used as shuttle rests, and from which the shuttle may be slid directly across the loom as required, thus obviating the necessity of laying it down and picking it up again and manœuvring it into the correct position every time it is used—and that means every thread !

The "shuttle race" (Fig. 9) is made of two i7 $\frac{1}{10}$. lengths of lath mounted side by side, thus forming a single piece $17\frac{1}{10}$. X zin. They are affixed to a block of wood at each end 1in. X In. X I $\frac{1}{2}$ in. by means of a number of panel pins driven in near the edges of the





Details of a shuttle body, and a view of a finished shuttle.

blocks, thus leaving the centre clear for a hole to be drilled to take a fine $1\frac{1}{2}$ in. screw. A good piece of wood should be used for these blocks or they may split easily. They should not be fitted until a few threads have been passed between the rollers, via the heddle eyes and through the reed, and then pulled fairly tight. With all the heddles in the lowest position, the race must just clear the threads when the reed is moved to its highest working position, which is about 3in. in front of the heddles. When fixing with fine $1\frac{3}{4}$ in. screws, take care not to split the reed mounting. Carefully make suitable holes for the screws in order to minimise this risk.

The brackets, or shuttle rests, Fig. 10, are made from a piece of wood $12in. \times 2\frac{1}{2}in. \times \frac{4}{3}in$. along each edge of which a similar length of lath has been fixed with panel pins, thus forming a kind of shallow trough. Underneath one end of this is screwed a piece of wood flush with the end and at right angles to it, $2\frac{1}{2}in. \times 3in. \times \frac{4}{3}in$, to form a mounting bracket, from which is cut a gap $1in. \times 1in$, see Fig. 10. From end to end and situated exactly in the middle of the


exactly in the middle of the gap a in. clearance hole is drilled for a in. rod 3in. long which has a hook turned at one end and the other threaded 4 BA for about 1in. A screw-eye is screwed into each side of the loom so that when the top of the bracket is level with the top edge of the shuttle race, and the inner face of the back rim just level with the front face of the reed mounting, the hook on the bracket may be engaged with the eye. If a 4 BA milled knob (such as those found on bell batteries with screw terminals) is used on the rod, it can be screwed up tight, which will pull the bracket firmly up to its position.

(Left) Side view showing heddle lever construction and mounting—one up and one down. (The hook on reed mounting is to hold weft threads which are not in use out of the way when using several shuttles.

(Right) Fig. 12.—Front and side view of the bobbin winder.

Shuttles

A number of shuttles will be required, as it is upon these the weft thread is wound to enable a reasonable quantity of it to be passed expeditiously through the warp shed (the upper and lower layers of thread formed by lifting one or more heddles). A primitive form of shuttle can be made by cutting a U-shaped slot in each end of a warp stick. The thread is wound round the stick from end to end. The whole is then passed through the shed and the thread unwound as required. This is very cumbersome, but it is as well to have a few available as spares. The bobbin type of shuttle is far more convenient and about five times quicker to use; it is easy to make and well worth the slight extra trouble. At least two should be made, but each colour in any design needs its own shuttle. It has



October, 1952




Fig. 13.-Single and double warping posts and clamp.

been found that these shuttles can be made for about 5d. each as against Ios. each, plus postage if they are purchased ready made. A bobbin shuttle (Fig. 11) consists of a picce

of wood, preferably a hard wood, 12in. × 1in. × Išin. with pointed ends and has a slot in it, practically from end to end, about $\$_{in. \times 1in.}$ Down the centre of this slot is a $\frac{1}{3}$ in. steel spindle resting in sockets at each end, one of which has a spring-loaded pin in it to enable the spindle to be removed and replaced when required. The thread is wound on to a paper tube about 4in. long (on a bobbin winder). This bobbin of thread is then placed on the spindle in the shuttle and the end of the thread passed through a 4in. slot in the side of the shuttle. In practice it is much easier to assemble the shuttle from two separate end pieces and two separate side pieces, these being $I_{1in}^{3} \times I_{1in}^{3} \times I$ in. and $10\frac{1}{10}$ in. × 1in. × $\frac{3}{16}$ in., respectively. Cut two rebates opposite each other at the end and on the narrower sides of each end piece 3 in. deep by Iin. Into these the side pieces are screwed with four small screws at each end, the heads being carefully countersunk below the surface of the wood. Before any assembling is done the sockets for the spindle must be made. Each one can be made from any nut which will comfortably allow the in. spindle to slide through it. For one end drill a hole slightly smaller than the external diameter and only just the same depth as the nut, which may now be either hammered in level with the surface of the wood or squeezed in with a vice. At the other end a similar hole is drilled, but this time it is continued about half an inch deeper than the length of the nut.

The hole is now extended another {in. with a smaller drill which should just allow the free insertion of the shank of a rivet described below. It will be seen that if a rivet about $\frac{1}{2}$ in. long with a head larger than the hole in the nut, but just smaller than the upper part of the hole in the wood is placed therein with a lin. spring under the head, a spring-loaded base to the socket is formed. The spring is made from 21 S.W.G. piano wire. In one of the side pieces of the shuttle a centrally placed slot 4in. long by fin. wide is cut. The four pieces are now assembled and a kin. steel rod of not less than 8% in. is cut for the spindle. It is best to cut this definitely oversize, finding out by experiment how far the spring-loaded pin can be pushed down, and cutting the rod just short enough to allow easy insertion of the other end in the plain socket. If the latter is, by chance, too deep and the rod goes slack when in position hammer a very small nail or boot


brad into it until it leaves the hole just the right depth. The ends of the shuttle should now be sawn, planed and then sandpapered to a curved, pointed finish and the whole rubbed down with fine sandpaper until all surfaces are quite smooth, and then polished. It was found that a good finish was obtained by heating the wood in sections and brushing in dark tan boot polish. A good polish on the shuttles is essential or they will not slide freely when in use, and it may be necessary to repolish them occasionally. (The shuttle dimensions given are suitable for a 15in. loom, but for a 32in. loom they should be about 13in.×11in.×11in. in view of the larger amount of thread used.) About ⁹/₁₆ in. of one end of the spindle should be threaded 4 BA and another of the bell battery terminals screwed tightly thereon-to enable it to be removed easily-

after which the threads below the terminal should, for convenience, be filed smooth. If a 4 BA nut has to be used instead of the wider terminal top a washer should be placed between it and the bobbin to prevent the end of the latter from being damaged by the sharp edges of the nut.

Bobbin Winder A bobbin winder is essential as it is quite impossible to wind the bobbins of thread by hand. If one is purchased ready made, it will cost about \pounds_2 . However, a most service-able one has been made for a few pence the cost of a kin. steel rod about 8in. long-the rest being scrap material. A boot polish

to hold it out and directly over the larger driving "pulley"—or polish tin. The driv-ing band is the rubber ring from a 2lb. preserving jar, and the rod and pulley are kept in position by a piece of bent rod screwed to the top of the mounting at one end and bearing lightly on the centre of the pulley at the other end. Two little subsidiary jockey pulleys were cut from §in. lengths of cane and mounted by means of 1 in. screws so as to rest against the driving band, keeping it in position. Owing to the overhang of the small pulley, it was thought advisable to mount a lin. thick piece of brass on the mounting and to drill right through that and the wood to form a bearing for the rod. A 21in. piece of paper 5in. wide at the base and tapering to a point is gummed and wound tightly on to the rod, so as to form a slightly tapering shaft from which the bobbin may easily be removed. This winder is now screwed fairly firmly to the front end of the left hand side of the loom, and a lin. from the top edge by means of a 2in. screw which passes through the base of the bobbin mounting lin. from the end. In the bottom left hand corner of the mounting (viewed from the back) and on the same side. as the loom a round-headed {in. screw is driven in hin. from the corner and is left projecting to form a stop. It will be found that the winder may be turned upright for use, where it will be held by the stop, or turned down against the left hand side of the loom out of the way when not required.

To wind a bobbin, a piece of paper about $4in. \times 4in.$, with rounded corners, is wound on the rod to form a tube on which the thread is wound from end to end until a roll the required thickness to fit a shuttle has been completed. It will be found that this slips off the rod quite easily. Do not attempt to wind too many threads at the ends of the bobbin, or they will slip off and cause a lot of trouble all round.



Warping posts, which can be used on a table, shown correctly mounted on a suitable board.

tin 23in. in diameter and Zin. thick has a hole bored exactly through the middle of both the lid and base which must just fit a 14in. screw which fixes it 24in. from the lower end of a piece of wood approximately $6in \times 1\frac{1}{2}in \times 3in$, washers being placed be-tween it and the wood to enable it to turn freely. At a distance of 21 in. up from this fixing screw a lin. hole is drilled to take the rod, gin. of which was threaded-any thread. A §in. diameter × §in. hardwood pulley was turned with substantial flanges and a flat based groove 7/32in. wide and with a central hole slightly less than in. diameter (Fig. 12).

This pulley was then screwed straight on to the threaded end of the rod which was then passed through the hole in the top of the wood mounting, washers, etc., amounting to at least in. being placed under the pulley

Warping Posts

Another item of equipment is a set of warping posts which may be fixed on to a table by means of simple screw clamps. For warps longer than about double the width of the table available, an extra post, or posts, should be provided, or the set of three may be mounted on a board which is at least half the length of the proposed warp.

These posts are expensive to buy, but merely consist of two pairs of $\frac{1}{2}$ in. or $\frac{3}{4}$ in. × 6in. dowel rod mounted in two blocks of wood and a similar single one so mounted, plus the relative number of screw clamps to hold them to the table, etc. The illus-trations (Fig. 13) make the construction quite clear.

(In be concluded) - 1 20 B

LOOR POLISHER

1111

General view of the floor polisher.

HIS device is a machine for applying polish and doing all the work of polishing floors, apart from the final shine, which can best be done by a dry mop. The machine consists of two rubber-tyred wheels fixed on an axle to which are also fixed two vee-pulleys, four blades arranged at rightThis Design, Submitted by Mr. W. E. Davies, Won First Prize in Section 2 of Our Recent £200 Free-for-all Competition

ing axle and tray-raising device. Centrally mounted on the radial arms, which are secured to the axle by welding, are the four polish Screwed into the blades. inside faces of the two driving wheels are four short, steel pins which engage with two twelve-toothed sprocket wheels to each of which is connected a spindle with a in. B.S.F. thread, which screws into in. B.S.F. internally threaded sleeves, fixed to the ends of the polish The polish tray frame tray. is steadied at each corner by adjustable stays, as shown in are best turned from bar to suit the bearings used.


For the framework any weldable tube of light gauge, such as old cycle frames, could be used with care; the centre-piece should be of a size to suit the handle available.

Operation

With the polish tray supplied with polish and the tray set to the correct level, hold the handle and push away as in sweeping. The vee-belt will drive the rotary brush at the ratio of 4:1, and the polish blades in rotating dip into the polish and apply it to the rotating brush, which, due to the difference in speed ratio, takes on the polish over a wide area, and brushes it into the floor.

Driving Pins

The pins on the driving wheels move one tooth of the ratchet wheel as cach blade passes over the polish tray. On the return stroke the ratchet "free wheels" so that the



The wheels and axles could, if necessary, be made up from old pram wheels keyed to the axle. The vee-pulleys, belts, ratchet gears and bearings are best purchased. Polish

Figs I and 2.

Wheels and Axles

Figs. 1 and 2. Part sectional front and side views of the completed floor polisher.

angles, a polish tray suspended from the bearing housings by adjustable stays, and provided with screwed sleeves and spindles operated by ratchet wheels, actuated by pins driven into the sides of the driving wheels, so that each quarter of a revolution of the driving axle slightly raises the level of the polish tray. The tubular metal framework to which are welded the bearing housings, extends across the machine at the top, and in the centre is a socket for a broom handle. The supports extend to the rear and carry the rotary brush and its bearings, as shown in Fig. 2.

Construction

Most of the constructional details are explained by the illustrations, Figs. 1 and 2, except, perhaps, the arrangement of the drivblades, supporting arms and adjustable stays can be made from $\frac{1}{8}$ in. m/s strip, and the cover from 22 s.w.g. sheet. Bearing housings may be removed.

-NOW READY!-

The Entirely New 12th Edition of the Famous Standard Work

THE PRACTICAL WIRELESS ENCYCLOPÆDIA By F. J. CAMM

Considerably enlarged, amplified and entirely re-written and re-illustrated. Com-plete Television Section, with theoretical and constructional data.

All the facts, figures, and constructional data of Radio and Television-Definitions, Terms, Units-Principles, Circuits, etc. Over 300,000 copies sold!

Price 21/- or 21/11 by post from :

GEORGE NEWNES LTD., Tower House, Southampton Street, Strand, W.C.2.

_ead Glazing

With Particular Reference to Stained Glass Windows

D ESPITE the broad scope implied by the title of this article it is not the whole of the operations and processes of leading up glass with which it is proposed to deal, but only one or two unusual features which are occasionally met with and these, more particularly, in connection with stained and painted windows.

As all glaziers know, the stained glass artist and designer often calls for glasses of greatly varying thicknesses, which are used solely to obtain certain effects, in either texture or colour, or a combination of the two, and the discriminating artist will always, himself, select each individual piece of glass. It is then the glazier's job to cut it and, after it is painted and fired; to lead it up.

Now certain fastidious artists not only are lovers of Norman slab glass but they like to double-plate certain portions of their windows and even to double-plate with Norman slab. The beauty of a window so treated is enhanced to an infinite degree and well repays the designer for the 'extra work which it entails for his glazier.

This use of Norman slab and doubleplating sets up mechanical difficulties, if ordinary milled leads are used for glazing, because of the great differences in thicknesses of adjoining glasses, the thick and the thin both have to go on opposite sides of the heart, into the same lead, and the heart of that lead must obviously be deep enough to take the maximum thickness of the thicker glass; but since that maximum extends often for a short distance only, due to the fact that a slab varies in thickness between hin. and zin., the usual method of dealing with the difference is to divide the heart of the lead where it is required to be spread, as shown in the cross section in Fig. 1. If, where I have put "antique," there should happen to come a cross lead at right angles to the divided one-which cross lead I have drawn and marked: "C.L."-then some special means would have to be contrived for soldering up that cross lead to the upper half of the divided lead. Many glaziers would, I suppose, lift the antique glass and slide the cross lead in to the divided heart and then depend upon getting such a blob of solder in as will connect up the cross lead to the upper part of the divided lead, but at best it is a poor and clumsy job.

Another orthodox method of dealing with great differences in glass thicknesses is by using a lead which is deep enough in the heart to embrace the thicker glass, without




Fig. 4.-Forming special deep leads.

By E. W. TWINING

any dividing of the heart, but this also is crude and a mere makeshift and it leaves the thinner glass with nothing to support it but a deep filling of soft cement, as is the case in Fig. 1.

A New Method

In Fig. 2 is drawn a cross section of a junction between glasses which I think the





Fig. 1.-One orthodox method : divided heart.








Fig. 3.-Method of double plating.

skilled glazier will admit is far neater and mechanically more efficient than any of the recognised methods. I, myself, first used it over 20 years ago. It is capable of accommodating itself to any thickness and all the variations in thickness, including the undulations in slab glass. The leaf which is shown turned over on to the slab can not only follow the undulations but the whole lead can be bent to follow the shapes of the glasses in accordance with the cut line, just as does the milled lead.

Fig. 3 shows the application of the same principle to double plating. Here is shown a little item which I consider is very necessary in plating, i.e., a line of something soft between the glasses to serve the double purpose of acting as a cushion and to prevent the possibility of cement being forced into the inter-glass space. The cushion which I have generally used is a piece of ordinary cotton string which is first impregnated with cement paint and then allowed to partially dry before being placed on the first, or lower, glass, sufficiently far into the angle to be hidden by the leaves of the lead.

It will be understood that the fillet marked "solder" in Figs. 2 and 3 is added after leading up is completed, when the whole light or panel is being soldered.

Making Special Leads

The special leads shown are, as I have indicated, not milled but fabricated from two straight strips of ordinary sheet lead having a thickness of a little less than 1/16in. These are cleaned bright with, say, a scratch brush and clamped with a strip of paper between them, between two pieces of wood, the edges of which are planed straight, as shown on the left of Fig. 4. The 3/16in. leaves are then turned sharply over on to the wood and a good half-round line of solder run along, as on the right of Fig. 4. The object of the paper is to prevent the solder from flowing down too far between the strips, so the paper should, therefore, come to 5/16in or $\frac{2}{3}in$. below the upper edges of the leads before bending over. After soldering the paper is pulled out. When leading up, the bead of solder

When leading up, the bead of solder shown in Fig. 4 is laid downward on the cutline. If this lead were used for slab glass, or double plating on both sides of its heart, the two strips of sheet lead would have to be of equal width. Where they are shown unequal, in Fig. 4, they are intended for unequal thicknesses of glass, as in Figs. 2 and 3.

Joints in Panels at Make-offs

Different glaziers use differing methods of finishing at the make-off at the tops and bottoms of panels and of the way in which an upper panel fits over a lower one at a saddle bar. A very common one is shown, together with a tie wire, in Fig. 5, where both of the leaves of the lower lead are folded flat, down on the heart. This is very good mechanically, it certainly stiffens the edge of the lower panel, but such stiffening is quite unnecessary because the tie wires and saddle bar will take care of rigidity. There is this objection to folding over the leaves: it increases the total depth of the whole joint—if ½in. leads are being used at make-off—to as much as 11/16in. at least ; an amount which is greatly in excess of the diameter of the saddle bar. If ½in. bars are used to cross the light where there are no make-offs then these wider bands of dark, at the make-off, will disfigure the window, for they will definitely show where the joints

In my opinion it is much better to cut




Fig. 5.—An orthodox make-off joint and wire tie.

away the leaves from the lower lead and let the upper one saddle over it as drawn in Fig. 6. By this means the total depth of the joint is only 1/32in. in excess of the saddle bar diameter, and this can be reduced by using the main portion of a 7/16in. lead on the lower panel instead of $\frac{1}{2}in$.

Tie Wires

The tie sketched in Fig. 5, notwithstanding all its faults, to say nothing of its failings, has been used from the earliest ages of stained glass work and is still used with conservative persistency. Its failings are: that being a single wire, and straight when soldered to the lead, it, after a time, breaks away from the solder and this breaking, or tearing, is often commenced when the wire is first bent around the saddle bar. Then, again, the twisting together of the two ends puts torsional stresses in the wire, at the commencement of the twist, which weakens it very considerably.




Fig. 6.-Proposed new make-off joint and tie wire.

I have examined windows, which had been installed perhaps fifty years and over, in which one half of the wires were either broken at the twist or, more frequently, torn away from the solder on the lead.

A far more reliable kind of tie is that shown in Fig. 6, where the wire is doubled into the form of a hairpin; this is soldered by both legs of the pin to the lead, after bending to the curve of the saddle bar, not put on straight and then bent. When the window is being fixed, the two free ends of wire are laid up over the bar, the loop brought down over them and then the ends are pulled through, bent sharply and tucked down on to the bar; any excess can be cut off. As a tie it is much neater than the

old form, there is no torsional stress in the copper and there are two wires in the solder instead of only one. These features make it at least 50 per cent.

Hammered Metalwork

Making Small Plates and Trays

T should be emphasised that the production of a true flat surface is possibly the most difficult of all hammered metalwork techniques, so that the making of a plate or small tray is no light task, and its successful accomplishment may be regarded with some pride by the amateur coppersmith! The plate or small tray is sunk on the




Fig. 3.-Edge treatments.

edge of a hardwood block held in the vice (Fig. 1). Two concentric circles as far apart as the required depth of the plate may be scribed lightly on the disc of metal so as to guide the fall of the hammer. Two large nails set in the block on which the sinking is done will provide a handy means of locating the disc accurately so as to keep the width of the rim as even as possible.

With the disc held firmly in position on the block, the ball end of the hammer is used to beat down the metal. The small depressions resulting from each blow should overlap slightly, the disc being rotated a little at each stroke. After each round of "sinking" it will be found that the rim and bottom of the plate are buckled, and these must be trued-up before making the plate any deeper. Place it right way up on a flat surface, and tap over the bottom with a flat mallet. With the plate upside down, correct the rim similarly. Anneal the work as required, i.e., as soon as the metal becomes so hard that the hammer has little effect on it. Check that the inner edge of the rim

Check that the inner edge of the rim maintains a true circle, by spinning the dividers from the centre point of the bottom and noting that the radius is true all the way round.

Planishing

When the required depth has been reached the plate is planished as follows:---

The bottom is best done on a surface of at least the same size (e.g., an iron surface plate), but if great care is used a large bottom stake will do (Fig. 2). With pencilrings to guide you, planish with a flat-face hammer, starting *lightly* from the centre and working outwards to the curve of the side with *increasing strength of blows*.

The curve of the side can be planished over a suitably-sized stake such as a pokerknob, or ball-peen hammer.

To planish the sharp inner corner between the rim and the side, hold the plate vertically with this corner on the edge of a bottom-stake. Strike with a large ball-peen hammer and slowly rotate the plate. When the inside of the corner is planished, hold the plate horizontally with the rim flat upon the bottom-stake, and the inner-corner well up to the stake edge. Planish the rim flat. Make sure that the plate is truly round and the corner set square.

To true the plate finally to size, scribe the




Fig. 4.- A wooden mould for small work.

By H. C. PIGGIN

stronger.

required circumference from the centre point, checking that both rim-corner and rim-edge will be concentric. Cut and file the edge as necessary.

The plate is now ready for any of the countless decorative treatments of the flat rim or edge which will suggest themselves, and which may be carried out easily with file and punches (Fig. 3).



Making Small Plates

Small plates or trays up to about 3in. internal diameter can be more easily made as follows. Gouge out a block of hardwood to the depth and size of the plate (Fig. 4). See that the bottom of the recess is level and smooth. Take a suitably sized piece of annealed metal, place it over the block so as to cover the recess, and carefully. hammer it down. Anneal it as required and continue to drive it down carefully until it fits the wooden "mould." As with the "sinking" of larger work, make sure that the rim remains flat and does not buckle. Planish and true the work in the order described for larger work.

Such small plates are extremely quick to produce. The mould can be so shaped as to include small recesses radially across the rim, as are quite often found on ash-trays.

Making Concrete Paths

How to Prepare the Ground and the Concrete Mix

T HE laying of a concrete path is not a complicated business, but there are certain conditions to be observed if the path is to be durable. One sees so many paths which in a comparatively short time have cracked and crumbled that it is obvious that these essential conditions are not always complied with.

Siting the Path

October, 1952

First decide on the site of the path in relation to the garden plot. The path will be a permanent feature, and if wrongly placed in the first instance it may be a permanent nuisance. Sited directly down the centre of the plot it may leave insufficient room on either side for a well proportioned lawn, as well as giving an impression of undue regularity and formality. On the other hand, in most cases the path is used by the housewife when hanging washing on the line, and if it is sited too far to the side the clothes may blow on to the fence.

Paths should preferably lead directly to some feature which forms a strong focal point. It may be a summer house, a pool,

Fig. 1—How the boards for the formwork are arranged and held in place with wooden pegs.

of paths of up to 3ft. wide on a solid foundation, 2in. of thickness is ample. Wider paths and those on loose, soft ground should be 3in. thick to avoid subsequent cracking, and drives which have to withstand the weight of cars should be at least 4in. thick. The side boards are held in place by stout

pegs driven firmly into the ground on the outside of the boards (see Fig. 1). Crosspieces are then fixed at about 5ft. intervals. These can be of $\frac{1}{2}$ in. thickness, in which case they are left in after the path is laid, or they may be stouter boards which are removed as laying proceeds. If the cross-pieces are to remain, the laying of the concrete is done continuously from bay to bay, but if they are to be removed alternate bays are laid; the cross-pieces are removed when the concrete has set and the inter-mediate bays then filled. Cross joints, made by either method, are necessary to prevent risk of subsequent contraction cracks, or warping of the slab due to expansion. To economise in timber, 20ft. of the formwork may be fixed at a time and moved on when the first section is laid and set.

By W. P. MATTHEW

The Correct Concrete Mix

For work of this nature there are two alternative mixes. The first, known as the "one-two-three" mix, consists of one part cement, two parts sand and three parts shingle. The other is of one part cement to four parts of mixed ballast. Shingle is usually easily obtained at builders' yards. Mixed ballast should be graded from about 11 in. down; that means that the largest stones are not more than 12 in. in diameter. If a few larger stones are present they should be removed when mixing. for paths of 3 in. thickness. or less.


Quantities

As a rough guide to the quantities required it may be calculated that, for a path 90ft. long and 3ft. wide and 2in. thick, you will require 9 cwt, cement, I cu. yd. of sand and $1\frac{1}{2}$ cu. yd. of shingle, using the one-two-three mix. If using mixed ballast you would, of course, need $2\frac{1}{2}$ yd. of ballast and 9 cwt. of cement. These quantities are calculated to the nearest cwt. of cement and the nearest $\frac{1}{2}$ cu. yd. of aggregate, and are on the generous side.

Mixing the Concrete

The concrete must be mixed on a clean surface, and a swept area of paving or concrete is ideal. Measure the quantities accurately, and an ordinary bucket is convenient for this. For one bucket of cement, two of sand and three of shingle you will need a little over half a bucket of water to produce a usable mix.

Spread the measured quantity of aggregate in a flat heap. Aggregate, by the way, means the coarse part of the mix—the sand and shingle or the ballast. Now spread the cement evenly over the heap. The whole is then thoroughly mixed by being turned over



The lay of the land, too, should be studied. On a gently falling site the path may be laid to follow the slope of the ground, but if the fall is steep it will probably be better to run level sections of the path, say, 15 or 20ft. long, breaking each section with a step. This in itself will lend interest to the path as a garden feature and will be well worth the effort of excavating the soil where necessary.

Preparation of the Ground

Having sited the path, define the sitz with pegs and string or a garden line, and remove the turf and any loose surface soil. On loose, soft ground ram in stone, broken brick, clinker, and so on, to form a solid base. On firm, heavy ground this is generally not necessary, and a sufficiently firm foundation may be formed by rolling, or even beating with the flat of a spade.

Formwork

The formwork for a straightforward concrete path is very simple?. Boards are laid along each side of the site of a width equal to the thickness of the path. In the case




Fig. 2.- Using a screed, and detail giving dimensions.

with a shovel until the mass is of a uniform colour, with no streaks of brown or grey. At least three complete turnings will be necessary,

Measure the correct quantity of water into a watering can with a rose nozzle and sprinkle it slowly over the heap, pausing frequently to turn it over with the shovel. Continue until you have a thoroughly mixed plastic mass of uniform colour and consistency. You can test for a good mix by taking a handful of the concrete and squeezing it. It should retain its shape under slight hand pressure and the surface at the same time should become moist without dripping.

Placing the Concrete

It is of the utmost importance that concrete should be placed as soon as possible after mixing; certainly no longer than half an hour should elapse. If the ground is dry the surface should be sprinkled with water just before the concrete is placed. If the surface is waterlogged, place sheets of old newspaper over the site before laying the concrete.

Fill one bay at a 'time, working the con-crete well into the side boards and then distributing it with an ordinary garden rake. At this stage let it be up to 2 in. above the height of the formwork. Level it off with a wooden screed, used first with a chopping forwards, sawing action. Notice that the screed shown in Fig. 2, which is made out of 4in. x 1in. timber, has its lower edge shaped to a slight curve. This curve should be about §in. depth for a path 3ft. wide. It gives a camber to the surface of the path which throws off the rain.

By the above method of screed finishing a rippled, slightly roughened surface is obtained, which is non-slip. If, however, a smooth surface is desired it is obtained subsequent smoothing with a wooden float. This need not be an elaborate affair, and Fig. 3 shows one which may be made in a few minutes out of waste wood. This trowelling must not be overdone or fine hair





Fig. 3.—Details of a wooden float.

cracks will develop later. Further, a glassy surface will be produced which will be positively dangerous in frost.

Shingle Surface

Another form of surface finish given to path made with shingle and which has the appearance of a gravel path is obtained if, about one hour after the concrete has been laid, it is brushed with a hair broom to remove surplus mortar. Some time later, when it is found by experiment that the



An Ejectable Cockpit

AN entirely new protective system of bailing out of very high-speed aircraft has been successfully developed and tested by the Douglas Aircraft Company Inc., at El Segundo, California. Whereas present pilots have only the British-designed medium altitude, medium-speed Martin-Baker ejector seat to turn to for their chance of eventual escape and descent to safety, the new Douglas system features complete ejection of the cockpit and certain fairings attached to it, thus forming a streamlined capsule.

In future practice, when a pilot finds it necessary to abandon his aircraft he ignites a rocket charge and the entire cockpit is thrown clear of the doomed airtrame. Within a few seconds three fins automatically unfold at the tail end of the newly created capsule to act as stabilisers; simultaneously, a small parachute billows out and slows down the forward speed. When a safe speed is reached (one that will not cause dangerous stresses) a main parachute unfolds and the capsule begins a gentle descent to the surface.

Because the capsule is highly pressurised it becomes possible, for the first time, to bail out at heights of over 50,000ft. It is dangerous with current equipment to bail out at more than 30,000ft.

For Water Landing

In the event of a water landing the capsule will float, with the electrical storage battery of the abandoned aircraft acting as as ingenious keel. Survival equipment, as stored on a Naval life raft, is stowed internally, while the motion of the waves pumps fresh air into the sealed and insulated compartment. The capsule has already been tested in the water by Douglas and the U.S.

Navy at Long Beach, California, and has teen dropped into rough seas from a crane at a velocity of 25ft. per second to simulate a parachute descent.

Many other convincing tests have been concluded. In static trajectory observation tests the capsule was propelled from a tests the capsule was propendu from a stationary position into a rope net. Final tests were conducted on the 10,000ft, aero-ballistic track at Naval Ordnance Test Station, Inyokern, to ensure satisfactory ejection at sea level speed of sound. To do this the forward part of a fighter aeroplane was fixed to the track and hurled down the rails by rocket propulsion at about 760 m.p.h. Half-way down the track an ejection charge was fired and the capsule sped forwards and upwards to function as intended.

It has been authoritatively stated that the new system can be applied advantageously to all aircraft cockpits. Too often these days we hear of a pilot escaping from a crashing jet aircraft, only to perish in the cold winter seas or to strike his. plunging machine. At last, it seems, we are to welcome a develop-ment which makes it difficult for a pilot to die.

New Inshore Minesweepers

HER MAJESTY'S Inshore Minesweeper 11 Number 5 was recently launched at the shipyard of Messrs. Vosper Ltd., Portsmouth. The ceremony was performed by Mrs. J. S. Purvis, wife of the Warship Production Superintendent, Southern Area. The Navy Estimates for the current year

show that 29 of this class of vessel were in course of construction but not launched at the end of March, 1952.

Of 106ft. 5in. in length with a beam of 20ft. 6in., these inshore minesweepers are designed to operate in shallow waters, such shingle is not easily dislodged, it is again brushed with a stiff broom, leaving the stones of the shingle slightly proud of the surface.

It is very important to protect newly laid concrete from the effect of fierce sunlight and drying winds, and if these conditions obtain during the first week or so after laying, the surface should be protected with wet sacks, strips of old carpet, etc.

Coloured Paths

The best-laid path of ordinary concrete is apt to be rather dull, and it is well worth while considering the effects which can be obtained by the addition of colouring powders to the cement. For this purpose ordinary dry colours may be used, but those made specially for the purpose are well worth the little extra cost. They have a much greater staining power and permanence of colour, and are resistant to frost, heat and light. They are resistant to frost, heat and light. They are used in the proportion of 10lb. of powder to each cwt. of cement, and they are thoroughly mixed with the cement before it is added to the aggregate.


These powders are made in about a dozen colours, and are intermixable so that almost any shade may be obtained. If more than one colour is used, however, great care should be taken in measuring so as to avoid differences in shades in a long path. This consideration is not so important if the path is laid in paving slabs.

In the next article it is proposed to deal with the whole subject of the making and use of in situ and pre-cast slabs for paths, dry walling, steps, pergolas and other fea-tures in the garden.

as rivers and estuaries. They are an entirely new type of vessel and embody novel features resulting from lessons learned dur-ing the war and in the course of subse-quent developments. In addition to mine-sweeping equipment, each will mount one small gun.

A Tiny Model Ship

THE accompanying illustration shows what is said to be the "smallest actual model sailing clipper in the world." It was made by 'Mr. C. V. Thompson, of West Kensington, London, W., and it sails excellently, all sails and yards being movable. The minute size of the model can be gauged by comparison with the halfpenny shown in the illustration.



The tiny scale model clipper is only 2 to in. long overall.

Industrial Infra-red

These Rays are Now a Necessity for Quick Drying ressive name By Professor A. M. LOW of infra-red

NFRA-RED is a rather impressive name for a very old thing. Call it radiant heat and much of the "mystery" surrounding it disappears. It is literally as old as the sun and no doubt its first application to industry was in the drying of the skins which primitive man used for his clothing. But so long as the sun remained the only source of these rays the possibilities for the extensive use of infra-red in industry were limited. Heat generated by the impact of waves of energy from the sun was very difficult to concentrate and, especially in a its availability.

It was, in fact, the need for much more rapid application of local heat that gave rise to the use of infra-red in industry. With the coming of mass production and conveyor belt methods of manufacture, it was essential that heating processes, particularly in the drying of paint, should be speeded up. The pace of a whole chain of operations might be determined by the rate at which certain products could be dried. It was inconvenient and wasteful for the drying such a process took far too long. Such is the delicacy of modern mass production methods that the time taken for the panels to dry might determine whether a motorcar was made at a profit or a loss.

For Drying Paint


Taking the example of paint, there are three ways in which the heat, required can be transferred: conduction, convection and radiation. Conduction is obviously impracticable in the majority of cases. Not even the amateur would try to dry paint on metalby applying a blow-torch to the metal. Convection in which the heat is transferred to a gas (generally air) which circulates round the paint was for long almost the universal method. Its disadvantage is the time required due to the losses of heat in the

transfer and the comparatively low limit of

temperature possible. Radiation has the advantage that the energy needed to produce heat is transferred rapidly and with low losses, yet can be strictly controlled. It is for this reason that during recent years infra-red has been increasingly used in many industries for all processes where rapid drying is required. It is equally suitable for drying paints on metal objects and varnish on delicate electrical components. It is also used where heat is required to soften parts for bending or cutting, as in the case of certain plastics. Infrared often enables the temperature required, generally between 400 and 700 deg. F., but with a higher possible maximum, to be attained within a matter of minutes or even seconds. Ten minutes may be considered a long time for stoving, where before one to five hours was short. In some cases the time has been cut from several days to the same number of hours.

Infra-red, of course, is that section of the spectrum just below the visible red and the actual radiations are invisible. It is, however, sometimes difficult to produce "commercial" infra-red radiations without some visible red. An efficient infra-red radiator should give the maximum amount of radiations between the comparatively narrow limits of infra-red and the minimum radiation of greater frequencies, exactly the opposite effect required of the illuminating lamp. Almost any "red-hot" substance radiates infra-red, but the design of infrafor industrial purposes often calls for complete control over the intensity of the radiation, simplicity of construction, and case of maintenance. Many substances which emit infra-red when heated are unsuitable because of their short "life."

A very obvious source of infra-red is refractory brick heated by gas jets—the ordinary gas fire radiates a considerable amount



The feed end of an infra-red ore-drying machine, manufactured by the Fraser and Chalmers Engineering Works of the General Electric Company, Ltd.

of infra-red. It is only recently, however, that completely satisfactory industrial units have been evolved by British research to meet the growing demand for infra-red in factories. These have one striking advantage over other systems. A small amount of the heat produced is transferred to the air in the oven and sets up convection currents. Now, while convection is a comparatively slow method of transferring heat it has the advantage that it "gets round corners" and is not affected by the colour of the material about which it circulates. In an infra-red oven, therefore, the convection currents compensate for "shadowing," the "shading" of uneven surfaces, and for difference of absorption by different coloured surfaces. The result is an even drying which it is seldom possible to obtain when infrared alone is used.

A Simple Unit

The construction of the latest type of unit is extremely simple. It consists essentially of a metal panel which holds the refractory brick and the gas jets, ten to each unit. It is interesting to note that neat gas, without admixture of air, is used; this permits of better control. The back of the panel is well insulated and the infra-red radiated from the front. These units can be built up in many different patterns according to the article being handled. They can, for instance, be built into circular ovens through which such articles as fireplaces can be carried by conveyor, the drying process taking place in the very short time required for the article to travel the length of the oven. They can be built up into a cubeshaped oven for dealing with batches' of articles, or again into a cupboard-like oven on wheels for portability.


For ordinary purposes there are no particularly unpleasant gases, and the excellent insulation means that an oven can be used in a workshop without special ventilation or over-heating. Whatever the size and design of oven required, the same type of unit is used, only the supporting framework being altered. One very considerable advantage of this system is that an existing drying plant can be extended without interruption of its use.

Various Processes

Amongst the processes carried out with the aid of these infra-red units are not only rapid drying of paints and lacquers, but also the heating of Perspex for moulding, the softening of plastic materials for punching and extrusion, the dehydration of paper pulp and similar materials, the rapid drying of ceramic materials, drying printing ink and curing sheet rubber. The variety of these operations shows the flexibility of the system as well as the many applications of infra-red in modern industry.

Infra-red is also being used in industry for warming the workers as well as the articles they make. By mounting heaters about 12ft. apart at about 8ft. from the floor it is possible to cover an area of 100 sq. ft. with radiant heat, the warmth of which is quite independent of the movement of the air between. Apart from the feeling of comfort given by direct infra-red heating, he advantages are the directional effect, the rapidity with which warmth is obtained after starting, the low cost of installation and the great economy in use.

October, 1952



S UCH work as the binding of a two-year volume of PRACTICAL MECHANICS cannot ordinarily be done except in a special workshop because of the need for bulky appliances too cumbersome to be kept in a private house for occasional use. Here, nothing but the resources of an ordinary household have been used, except for the sewing frame and special clamp or press, both of which the handyman will have no difficulty in contriving, and which may be easily stowed away during the long intervals in which they are likely to be idle.

After arranging the numbers of the magazine in their proper order, face up on the table, straightening out dog ears at the same time, the next thing to be done is to sew the "sections" together. "Section" is the term for each bundle of leaves to be sewn as a unit, in this case a whole issue of the magazine. "A "sewing frame" will be needed for this, and is illustrated in Fig. 1.

The Sewing Frame

The measurements in the diagram need not be followed closely. All that is needed is that the baseboard will freely accommodate the largest book to be bound, and that the frame be strong and firm. For easy stowage the frame and baseboard may be made in separate units, to bolt together.

The tapes are fixed to the top bar and the front edge of the baseboard by drawing pins, so be careful not to use hardwood for these parts. If you do not take this precaution you will find it impossible to press the pins home, and will have to add softwood battens —this unnecessary complication can be seen in Fig. 2.

Use strong linen tape about half an inch wide and before starting the sewing you will need a large, easily threaded needle and some stout cotton, some yard-long lengths of tape, and a thimble—if you can use one. The number of tapes to be used depends on the size of the book. A prayer book will need two tapes, an ordinary octavo novel three, and in the case of PRACTICAL MECHANICS four can be used. Put the first section on the baseboard, back to front and face down, so that it will be in its proper place when the sewing is finished. Place the tapes at reasonable intervals fixed in position; leave about two inches of tape to spare below the bottom and the rest flying loose from the top bar. The drawing pins ordinarily go in the front of the bar and baseboard.

To start sewing, thread the needle with an arm's length of cotton and make a knot in the end. Again make certain that the correct section is properly placed on the baseboard, put the left hand inside the centre of the section, holding it partly open at the middle and ready to receive the need!e as it comes Fig. 2.— The volume being sewn. Twentythree issues of Practical Mechanics are seen on the sewing frame. The bodkin is for beginners use.

through. Put the point of the needle on the outside of the folded edge about $\frac{1}{4}$ in. from the "head" and central. Push the needle through until the left hand inside can catch hold and pull it, followed by the thread, right through. There will be a tail of thread behind the knot; do not cut this off yet. With the left hand push the needle back through the fold so that its point comes

With the left hand push the needle back through the fold so that its point comes out just to the right of the first tape. This is not easy at first, and the point will probably show itself anywhere up to half-an-inch or so either side of the correct place. Trial




Fig. 1.—Sewing frame with one tape pinned in position.

and error is the proper way and within in. is good enough, but do not go through the tape on any account. The tape must be free to slide inside the stitching. An exasperated beginner contemplating a

An exasperated beginner contemplating a fold rapidly becoming a line of perforations may be excused for using a subterfuge. With a bodkin, shown in Fig. 2, pierce a hole from the *outside* at the proper place and then, looking over the top, let the left hand guide the needle through this hole. This is an unorthodox proceeding, but not really bad practice except for the time wasted. But there is a great pleasure in doing it the proper way and seeing the needle point appearing in the right place with only an occasional miss.

In this way go on sewing the entire section to the tapes, finishing with the needle coming out $\frac{3}{2}$ in, from the bottom, on the left. Again section that has been operated on, that it is page one down, and that it is has been sewn through the middle pages of the section, for it is easy to miss them. After making sure that there is nothing to be corrected in the first section, place the second section in position on top of the first, centred exactly over the first section should the two be of slightly different size. Push the needle in through the new section exactly above the hole it last came out of, and complete the sewing of this section to the tapes. Then you will have the thread, led by the needle, coming out exactly above the place where sewing started with the knotted end still hanging out. Pull both parts taut and knot them together and cut off the original end, but not the part

Bookbinding

How the Handyman Can Bind His Own Volumes

make certain that it has been number one

threaded through the needle. Put the third section in position and sew it the same as the other two. On arrival at the other end of this section the time has come to make the first "kettle skitch." This





Fig. 3.—The kettle stitch. Thread shown dotted where passing under.

is a simple half hitch made with the working part of the thread round the stitch joining the two sections below it (see Fig. 3). Push the needle between the two lower sections from inwards out (or right to left in this case) inside the stitch, then pass the needle through the loop of cotton beneath the last-made hole and the stitch underneath, following the line in the figure. Pull taut and go on with the sewing, and so on till the end, making a kettle stitch at the end of each section. After sewing the last stitch, knot the last kettle stitch doubly, but do not cut its end off too closely ; the ends of cotton hanging out are taken care of by the glue in a further stage of the binding.

The sewing will not be completed with one length of cotton—the several lengths are knotted together, each one to the last *outside* the book in front of the frame. Do not try to be too economical with the thread in doing

Fig. 4.—Cutting the top edge. The press is made from scrap iron, the boards are loose. The knife is a leather knife and is whetted on the firestick made with medium emery.





Efficiently and Cheaply

By S. H. SMOXLY

this for it will be difficult to get the knot in the right place unless there is a comfortable amount of thread to play with. The knot is so placed that it will be pulled through the next hole after the needle and left inside the section when the thread is taut and the next hole made.

The volume is now beginning to look like a book. Cut off the tapes 1 in. to 2in. long

and save the rest of the tape for next time. A professional does not call this process "bookbinding" at all; to him it is "casing." The superior term is applied to that way of covering books in which the boards of the cover are applied first and their covering and embellishment later. The sort of cover that we are going to put on, made separately and complete, is termed a "case."

Fly Leaves and Edge Trimming

Next come the fly leaves or "end papers." Each end paper is the size of a double page and is folded in two, one half to form the





Fig. 5.-Book between boards in clamps, showing the edge partly cut.

fly leaf and the other to be pasted inside the binding case. The end papers are pasted to each end of the volume by an eighth-of-aninch wide smear of paste along one side of the middle edge. As to paste, flour paste is the regular thing, but any office paste will do, thinned for the bigger jobs so as not to dry out too quickly. Leave under a board and a heavy weight to dry. If the book is to have its edges cut, now

is the time to do it. Cutting is not really necessary, but it adds a lot to the looks, makes possible the dusting of the book when lodged on a shelf, and is a source of satisfaction to the binder. However, should the binder feel that he is undertaking quite enough without cutting the edges, he is



advised to drop this process with his first volume.

An Improvised Press

A simple press will be needed and a suitable knife. The press can be made with two strong battens coupled together with two in. Whitworth bolts and butterfly nuts. In Fig. 4 the press used is made from two lengths of iron from an old window grilliron is good for the top bar to avoid damage from the knife, but wood can be made to do. To clamp the book for cutting, a piece of board for the book to lie on, a piece of card





Fig. 6.—The cover cloth freshly glued with cover boards and brown paper in position ready for folding the cloth over.

to cut on and another piece of board to lay over the top will be needed.

Knock the volume up on the table so that it is all square. Rule in with a set-square two lines at the top and bottom on the end papers to show the depths of cut to be made to ensure flush edges. It will not be possible to take off more than a bare minimum, or the finished margins will be too small. The fore-edge will also need a cutting line.

Having pencilled in the guide lines, put the book with the boards and cardboard in the press. The fore-edge (pronounced exactly as the stuff horses eat) is the first to be cut,

The cloth is



so arrange the top bar and top board to lay along this guide line. Make sure that the book has its top and back all square. Screw the bars as tight as possible without damaging the paper.

For cutting, a pocket knife makes a passable job ; razor blades will not do at all ; and the best of all is a shoemaker's leather knife costing about two shillings. A sharpening stone will be necessary and also a "firestick," which is a piece of medium emery paper glued to a board (about 10in, by 2in, is a suitable size). The knife must be kept sharp during cutting and about half-a-dozen whettings on the firestick will be needed while cutting the fore-edge. To whet, hold the knife flat on the stick with a slight pressure on the cutting edge, and draw it along the stick blunt side first, giving it a heel-and-toe motion at the same time. Don't hurry the stroke or the knife will heat and the cutting edge lose its temper. The toe needs most sharpening, especially the thickness of the The stone is used for more drastic toe. action and for thinning away the toe. A knife can easily be inspected for sharpness by glancing down the edge: if the edge shows a white line it is blunt and needs whetting.

Cutting Technique

For good cutting the pressure holding the paper together must be more than that on the knife. Here the press provides pressure, but even so, it is as well to start by cutting lightly and find out by experience how much pressure on the knife the job will stand. Start by cutting a page or two at a time and increase gradually up to about half-a-dozen Too much pressure on the knife will pages. cause a crooked cut.

Start cutting along the pencilled line, guiding the knife by the top bar, the flat of the knife against the bar, and the length of the knife as nearly horizontal as possible, so that it slices through the paper. Guard against raising the handle end at the finish of the cut, and use the tip of the knife to flip the waste away. As cutting proceeds a small cliff of cleanly cut paper will form. At the beginning of each cut make sure that the knife starts at the foot of this cliff following exactly the trace of the previous cut; it is easy to start the knife a hair's breadth away from the previous cut, and in this way miscuts are made. Once a cut is properly started the knife tends to follow its nose and keep right.

After the first few cuts, about a quarter-ofan-inch down, the top bar will no longer serve as a guide (Fig. 5). If the knife were to be kept pressed against it each time, its cutting edge would stray outwards and the edge of the book would slope outwards. After the first few cuts the knife must be guided by the " cliff " so as to keep the cut vertical.

After cutting the fore-edge, do the top and the bottom in the same way. It does not matter whether you cut towards or away from the spine. The thickness of the back due to the stitching makes the book lie slant-wise in the press, but this cannot be helped.

Gluing

Gluing up the book comes next. Put the book back in the press between two pieces of board with about 1in. projecting. Use ordinary glue, weakened with water for all bookbinding purposes. Thoroughly brush up and down the back, working the glue into the spaces between the sections and the endpapers too, the object being to glue the sections together. Then put the book aside for some hours to dry.

Pencil in on the cloth the the way round. shape of the underneath board as it lies so that it can be quickly replaced in its proper position. Now heat up the glue and brush it, all over the cleth, having first cut it to shape, of course, with an inch to spare all the way round. Use watery glue, or it will dry too quickly.


Lay the glued cloth on the table, very care-fully assemble the book with the boards in place, and lower it on to the glued cloth with the under board to the pencil marks. Once the lower board is in position it stays there, and there is no need to jiggle it about to-get it exact. Now pick up the cloth by the left end and, slightly stretching it, draw it up over the book till it lowers on to the top board, to which it sticks. Now fold

with and shape one end to that purposesuch a folder is shown in Fig. 7. With the folder smooth down the brown

paper on the spine and turn the edges of the cloth over the boards, being careful about the folder work at the corners. Then turn the whole thing over on the table (there will be no exposed gluey parts that matter now) and rub down all parts with the folder; the ridges and pimples will easily smooth out. With the folder rub down the creases where spine joins the sides, gluing the cloth to the edges of the boards; rub very well here. Now the cover can be put aside to dry.

Back Covering

While the cover is drying, the back of the book is covered with a layer of "mull" and the other piece of brown paper glued on.



When dry to the touch, but before drying completely, take the book out of the press and shape it with a round back. To do this lay the book on the edge of a table and push and pull it till it gets the round shape on the back and a similarly concave fore-edge. A practical bookbinder would use a hammer to beat the book into shape, and there is no reason why the handyman should not do so as well. A shoemaker's hammer with a broad, flat pane is the best to use. This rounding is not strictly necessary; it is only a matter of looks but helps the book to look ordinary and not amateurish. The fan-shaped splaying out of the sections at the back cannot be done without a heavy press, but its absence is not very noticeable.

Making the "Case"

For the "case" there will be required cloth, boards, glue, mull and a "folder." The boards are cut from cardboard, and old cartons and boxes provide suitable material. The size is such that the bare boards will cover each flypaper, overlapping in. on the cut sides, but coming up the same amount short on the back side to make a hinge. As for the cloth to cover them with, a special bookbinding cloth is naturally best; but a variety of household off-cuts can be made to serve. American cloth left over from the kitchen table was used for The .Readers' Digest, the second volume down in Fig. 10. The material from which blinds are made is also good. Messrs. Aero Spares, who advertise in this magazine, often have pieces of real bookbinder's cloth at a shilling a piece in their Holborn window. In addition to the cloth, two pieces of ordinary brown paper cut to the width of the spine and about 1 in. longer will be required.

Lay the book on the cloth on the table, with the boards in position, being careful to place them kin. from the spine, leaving a strip of fly leaf showing. Arrange the cloth so that it can be drawn over the top board, leaving about an inch of margin all

back the cloth flat on the table again and remove the book, leaving the two boards, sticking to the cloth. With a pair of scissors cut off the four angles about a $\frac{1}{4}$ in, from the boards, so as to make folding the cloth easy (see Fig. .6).


heavy weight.

Take one of the pieces of cut brown paper and-lay it-evenly down the spine of the cloth (with a gap each side showing cloth) between the boards, and rub it down with a "folder." The folder is a piece of bone like a paper knife; an old toothbrush cut and filed to shape makes a good one, but it is more proper to take a bone that the dog has done

"Mull" is a kind of coarse net, and although very cheap is not easy to come by ; but any An kind of light, strong material will do. inch of mull either side is left free, and the ends trimmed up with scissors when the glue is dry. (Fig. 8.) Then the book and its case, or cover, are

brought together. The fly leaves, tapes and mull are thoroughly pasted (but not the back) and all pressed together, then placed between boards, so that the spine is free, under the very heaviest weight that, can be mustered. (Fig. 9.) Apart from a neat label pasted on, the volume is finished.

BOFFIN



"I've been retained by the Mercedes-Benz people to build a successor to the B.R.M."

October, 1952



Silvering Clock Dials

Methods of Waxing, Silvering and General Finishing of Dials for Clocks and Instruments

THE silvering and resilvering of clock and other instrument dials, and of nameplates of various kinds, is usually regarded as a complicated and exacting process suitable only for the experienced trade worker, and hedged all round with numerous "trade secrets" which make the whole procedure impossible of adoption by any amateur manipulator. So, also, is supposed to be the re-lettering of the engraved figures and other characters which are usually present on such nameplates and dials.

The fact is that, given reasonable skill and a little prior practice, the art of silvering and waxing dials and engraved or incised plates is an easily acquired one, thus making it possible for a careful amateur worker at a minimum of expense to turn out work which may compare favourably with even the best of professional efforts.

Instrument plates and dials are usually of brass or copper, particularly when they are to be surface-silvered by the chemical method, the reason being that only these metals take the white, matt, silver deposit well. When the plates are not required for



The cleaned, desilvered brass circle from which the old wax in the engraved numerals has been removed.

silvering, they may be of any metal, ranging from aluminium to stainless steel or even common lead. Brass and copper dials and plates, as well as those of bronze, are the more usual because these metals permit of ready and accurate, clear-cut engraving, stamping or other means of forming the incised characters which are afterwards to appear in black against a plain, polished or silvered background. The traditional background. silvered example of the old-time workmanship is to be seen in the well-known silvered " chapter or numeral circle on the dials of old clocks, on old barometer dials, and on other instruments of various descriptions. It should be understood, however, that it is possible to produce a passable imitation of these old and often very beautiful silverings merely by a process of printing in black on an aluminium, or on an anodised aluminium background.

In order to illustrate the correct method of working the matt silvering process, let us' take by way of example, one of the silvered dial rings or circles of a domestic clock which, in the course of time, has become

By J. F. STIRLING, M.Sc.

more or less badly abraded, discoloured and tarnished, or even, perhaps, actually blackened. The many "brass-faced" clocks of the grandfather type which are seen nowadays usually have other silvered circles, too—the seconds ring, the calendar ring, and, often enough, the maker's nameplate, which, in these days, is coming more and more to constitute a valuable feature of the clock. The silvered dial plates of the old domestic barometers are all similarly made-up, so that the procedure herein described and illustrated can be applied to any type of dial or nameplate, old or new, provided that it is of copper or brass.

The four illustrations given below show successive stages in the waxing and resilvering of the seconds circle of a grandfather clock dial.

Preliminary Cleaning

First of all, the dial or plate must be detached from its support on the instrument which carries it and then immersed in a solution of t part of caustic soda in 6 parts



The brass circle surface coated with hard engraving wax, a portion of which latter has been removed by gentle abrasion, revealing the filled engraving.


of water contained in an enamelled tray or other suitable non-metallic vessel. The tray is placed over a large pan of gently-simmering water in order to warm up the caustic solution. On no account should any article of zinc or aluminium be submitted to this treatment, since such metals are dissolved by the solution. After some Io-15 minutes' immersion, the part is withdrawn from the solution and gently scrubbed with a soft brush. This will remove the existing lacquer on the silvered part, together with the black wax paint or filling in the engraved numerals or other characters. For obstinate cases, two or three treatments of this nature be required. Remember that warm may caustic soda solution will readily remove the skin from the fingers, so that, after much manipulation of the parts immersed in such solution, the fingers should be rinsed con-stantly in cold water and dipped from time to time in strong vinegar or in weak hydrochloric acid.

After the silvered part has been stripped in the above manner, it should be thoroughly well rinsed in warm water and laid down on a flat table or bench top on which it can be dried properly.

Waxing the Dial

The article is now laid face upwards on a clean iron sheet which is gently heated by being placed over a gas ring, the object being to heat the component gently and uniformly. If the object carries any soldered parts (the relics, perhaps, of former repairs) great care must be taken during this process not to melt or soften the solder. All that is required is that the object should be heated uniformly and to a temperature which makes it too hot for handling. Excessive heating is quite unnecessary and should be avoided

Take a stick of black engraving wax (which is usually obtainable from dealers in clockmaking materials). Hold it between the fingers and rub it vigorously and forcibly over the surface of the heated article so that the entire surface is blackened. This done, increase the heat slightly so that the applied film of wax becomes more fluid and sinks



The complete circle as it appears before silvering but after the removal of the wax. The numerals are now filled with the hard wax which is flush with the surface of the metal.



The finished result. The wax-filled seconds circle of a clock dial after its final silvering and lacquering, showing the characteristic contrasts between the black waxed numerals and the matt-silvered background.

down into the engraved characters. Rub a hot flexible steel spatula blade over the blackened surface in order to press down and to consolidate the wax into the incised figures or letters. Then turn off the heat and allow the article to cool down itself to normal temperature.

Removing Surface Wax

The next operation is the most tedious of all. It consists in removing the surplus wax from the surface of the plate without, at the same time, pulling it out of the engraved hollows or other markings which the wax has filled. There are various methods of doing this. You can, for instance, try gently wiping over the wax-filmed surface with a soft cloth saturated with petroi, paraffin, white spirit, benzene or some other solvent. Usually, in this instance, it will be found that the solvent, whilst readily and quickly dissolving the unwanted wax coating on the surface of the plate, will also remove some of the wax from the engraved characters, so that when the surface of the plate or dial has been finally cleaned the filling of the characters will look poor and uneven.

The surface cleaning-off of the wax without affecting the fillings should preferably be done by abrasive methods rather than by solvent ones. It is best, in the long run, to go over the entire wax-coated surface of the component with a soft cloth charged with a paste of fine pumice powder and water, or, better still,-silica flour and water. Keep the surface well swilled with plenty of cold water and keep the rubbing in one direction only. Given patience with the job,




Pressing the applied layer of wax filling into the engraved surface by means of a hot spatula blade.

this procedure will remove all the surplus wax from the surface of the component without tearing any of the wax out of the "filings," however fine the engraving may be. What is more, the abrasive treatment imparts a finely matted surface to the plate or dial which is admirable for silvering or for direct lacquering. Moreover, the wax in the fillings will not stand up with an objectionable gloss. Still further, as a result of this treatment the surrounding metal surface will be made chemically clean and free from tarnish.

If the plate is not required to be silvered it may be lacquered by brush or spray methods, care being taken to choose a transparent lacquer in which the wax filling is not soluble. Usually, the average clear cellulose lacquer suffices for this purpose.

Making Silver Chloride

If the plate has to be silvered, this operation will be found quite simple and rapid. Various silvering powders can be bought ready-made from dealers in clockmaking requisites or the amateur can make up for himself quite a good silvering powder by grinding together equal parts (by measure) of silver chloride, cream of tartar, and com-



Precipitating pure silver chloride by adding a common salt solution to a solution of silver nitrate. The heavy white insoluble precipitate of silver chloride rapidly sinks to the bottom of the vessel.

mon salt. Note here that silver chloride is stipulated, not the more readily available silver nitrate. Silver nitrate is obtainable from most pharmacists, but not silver chloride. The nitrate, however, can be converted into the chloride by dissolving one part of silver nitrate in about four parts of warm water,

nitrate in about four parts of warm water, and then by adding to the resulting solution, drop by drop, a solution of one part of common salt in four parts of water. This will precipitate the silver chloride as a white, curdy mass which is insoluble in water. It should then be filtered off through blotting paper, washed by pouring cold water through the mass, and then spread out to dry without heat.

Be careful not to add too much common salt solution to the solution of silver nitrate, because the precipitated silver chloride is soluble in excess of common salt solution and, in this way, some of the valuable silver chloride would be lost.

The correct procedure is to add the common salt solution drop by drop to the solution of silver nitrate and to stop adding it when it is seen that no more of the white silver chloride is being formed. The handling

Just another precaution. The handling of silver nitrate solutions indelibly stains the skin black, and also destroys it, for which reason this salt is much used for the removal of warts. Silver chloride has not this effect, although it will blacken if exposed to strong light. But if silver nitrate solution is splashed on to the skin it should be washed off at once.

In the operation of silvering, a little of the above silvering powder, either ready-made or home-produced, is taken up on a wet, soft woollen pad; and is rubbed gently but firmly over the cleaned surface which has been previously waxed in the manner above described. The film of white, matt, metallic silver appears almost immediately. It may be thickened and whitened a little with continual rubbing with the pad. If the under metal surface has been nicely and very finely matted the new silver surface will have the same character. This appearance is usually aimed at in the best work, but if the under surface has been polished the silver layer will likewise tend to acquire a polished and lustrous appearance.

All that now remains is to rinse the silvered article well in cold water, and then to wipe it roughly dry with a soft cloth, allowing it afterwards to dry completely in the air and without heat.


Lacquering Necessary

If left in this condition, the newly silvered or re-silvered surface would quickly tarnish under ordinary atmospheric conditions. It must, therefore, to complete the job effectively, be given a thin coating of a clear cellulose lacquer, this being applied either by spray or by means of a soft brush. If this particular type of lacquering is overdone, or if the lacquer is too thick it will impart an objectionable glaze or shininess to the silvered part. In order to guard against this, it is usually advisable to use the latter in a diluted state, employing, say, two parts of a standard cellulose lacquer thinned down with one part of either acetone or toluene.


New brass and copper parts can be silvered in precisely the same way as the parts which require to be stripped before the work is commenced, but it should be noted that only copper and brass articles are amenable to the process. Articles made of other metals must be brass or copper-plated (preferably the former) before they can be matt-silvered in the above manner.

It is possible when dealing with purely letter nameplates to fill in the lettering with coloured waxes.

EADH







That's all it costs for a complete kit of materials (No. 2147) to build a really first-rate 15-inch. model of the famous galleon "Mayflower." A perfect model for the discriminating crafts-

There are many other Hobbies Galleon Kits, too—all equally good

value for moncy. For example, there's the miniature— the galleon depicted on the back of the present-day halfpenny —"The Ha'penny Galleon." The complete kit costs 6/3. Among the larger models is Kit No. 235 Sp. with which you can build the "Revenge," a really colourful galleon. The cost of this Kit is 23/9. All Hobbies kits are easily made with a fretsaw and a few odd tools.

From leading stores, Hobbies Branches in London, Glasgow, Manchester, Birmingham, Leeds, Sheffield, Hull, Southampton and Bristol-or post free from Hobbies Ltd., Dept. 7, Dereham, Norfolk. Free illustrated two-colour booklet of complete range on request.



HOBBIES HANDBOOK. This fromous annual, full of things to make and do, is now on sale. Price 2/- from newsagents, etc., or 2/3 post free from Hobbies, at Dereham,



DRAWING INSTRUM

31

SLIDE RULES We are the largest manufacturers

of high-grade Drawing Instruments and Slide Rules in the British Empire, and our Kinwest Drawing Materials have gained a reputation throughout the world for superb quality and accuracy. Insist on using only Thornton's for complete satisfaction.

Our illustrated Catalogue, which includes particulars of Drawing Instruments, Drawing Boards, Tee and Set Squares, Scales, Curves, etc., is sent Post Free on request.





ottery Kilns How to Convert a Small Solid Fuel Burning Pottery Kiln to Gas

VyITH modern developments in insulating materials, this easily controlled method of firing becomes a practicable and

not expensive proposition. Three or four visits during an eight-hour firing are all the attention needed. In addition, a muffle can be dispensed with, increasing the capacity of the kiln and reducing the mass to be heated.

Gas Supply

A kiln with an interior capacity of one cubic foot can be brought to the desired temperature by the consumption of 80 to 160 cubic feet of gas per hour depending upon the efficiency of the insulation and the internal construction of the passages which remove the waste gases. Not less than a ³in. gas supply is needed. The following information relates to what is commonly known as town gas to distinguish it from natural gases and "bottle" gas, for which different provision must be made. I have found it helpful to connect the burner to the gas tap by means of a stout flexible hose. This enables the burner to be withdrawn for lighting, which is a great advantage from the safety point of view.

Burners

As will be seen in Fig. 1, burner bars are taken off the main stem from the gas supply. They are constructed of ordinary gas barrel, using caps, collars, and T-junctions. These can be cut to size and threaded up by a plumber if facilities are not available in your own workshop. The part of the burner actually in the kiln may burn to such an extent that the burner-port area needs replacement, and it is for this reason that a collar is placed at A. It is a great advantage to use heat-resisting steel for this length.

Injectors

A thin stream of gas must be injected into the burner bar drawing with it, through openings in the side of the bar, the right amount of primary air to secure maximum heat liberation. It is possible to make up a primitive kind of injector by rolling a copper cone, brazing it into the mouth of the burner bar and drilling out the required hole in the narrow end. (See Fig. 2.) Alternatively, where a lathe is available a jet can be made up as shown in Fig. 3. The efficiency of the jet will depend upon the accuracy of centring of the jet aperture. The commercial product of a firm specialising in the manufacture of a firm specialising in the manufacture of jets will give the best result. In addition to the accuracy of the jet aperture, the placing of a venturi tube immediately after the intake




Fig. 2.—Showing injector made by rolling a copper cone and brazing into mouth of the burner. Fig. 3.-Jet turned up on the lathe.

By D. A. YOUNG

for primary air ensures that the stream of gas picks up and mixes with the proper amount of primary air.

Burner Ports

The first burner port must be not less than six times the diameter of the burner bar away from the injector orifice. You may find that the pressure builds up towards the ends with the result that there is a longer flame at the sealed ends. To counteract this the burner ports can be made to vary in size provided the total area remains constant. A rough rule is to allow a $\frac{1}{2}$ in. hole for every cubic foot of gas consumed per hour. A more accurate-method is to calculate the total burner-port area by allowing .015 sq. in. for every cubic foot of gas, and devising a suitable number of holes with suitable diameters. Make use of the following formula.


Cap

Where $.015x = y \times \pi r^2$ x=consumption of gas

- in cubic feet per hour y=number of burner ports
- r=radius of burner ports

By fixing any two of these factors the third can be readily obtained.

For example, to find how many burner ports of $\frac{3}{16}$ in. would be required where 60 cubic feet of gas is consumed in the hour.




or 32 approx.

The resulting flame should be a row of tight, blue-green flames similar to those of the domestic gas stove. Soft, woolly flames of a yellow appearance indicate insufficient primary air, which in its turn is due to too slow a rate of gas release over the burner-port area, i.e., too few holes. If the flame, on lighting, runs back to the jet orifice, there are too many holes in the burner-port area. In this type of kiln the ware is heated by the flow of hot gases and not by contact with the flame itself.

Secondary air is the air required by the burning gases to complete the process. Suitable arrangements must be made for the admittance of sufficient secondary air around the burner-port area of the burner bar to

Threaded to fit inside


external barrel



in pressure being built up inside the kiln, retarding the admittance of secondary air and resulting in a reducing atmosphere. If the kiln is indoors and the gases have to be led If the out of the building by means of a long chimney, a break should be made about 3ft. above the kiln to prevent the updraught becoming too fierce.

Kiln Atmosphere

The atmosphere inside the kiln is of great importance to the potter. A reducing atmosphere is one where there is no free oxygen. Thus in a biscuit firing carbonaceous matter may be left to burn out later, in a firing the reactions of the glaze. In a glost firing the reactions of the glaze are quite different in a reducing atmosphere. The colour of the metal, e.g., copper red, is obtained instead of the colour of the oxide of the metal, e.g., copper green.



ensure that all the gases are consumed and

the maximum heat liberated within the kiln. Flames coming from the chimney are spectacular but wasteful !

Provision must be made for the removal of

burnt gases. A nice balance must be preserved between the need for a clean atmosphere and

the retention of the hot gases to enable the heat to be transferred to the ware and the

construction which will cause the hot gases

to circulate within the kiln or behind a thin

lining will keep the heat in the kiln where it

is wanted. An aperture of I sq. in. for every

10 or 15 cubic feet of gas consumed should

be made in the kiln leading to a length of drain pipe which will act as a chimney.

Three or four feet of chimney will be enough. More will create too big a pull and draw the

gases through before they have released their


heat to the ware. Less chimney may result

Generally speaking any

Exhaust Gases

lining of the kiln.

Primary air intake



By "MOTILUS" Modern Motorship Model : Model Half-timbered Village

T is not very often that I hear of a model of a modern cargo ship built to the free-lance design of the model-Free-lance models are, I find, genermaker. ally of old-time sailing ships or, if modern, then they are usually model yachts. In the main, however, ship modellers are ship lovers, so they often build to a favourite prototype.

Earlier this year I was very interested to receive, from a correspondent in the United States, photographs and particulars of a ship model which he had not only made but had mainly white and also the masts, while the funnel is buff. Particular attention has been paid to comprehensive deck detail and, as a result, Mr. Hungerford has produced an excellent and interesting modern ship model.

A Model Half-timbered Village

An attractive, coloured model of a half timbered village, displayed by Messrs. Bassett-Lowke, Ltd., in their London shop in High Holborn, tempted me into making further inquiries. I found that this model has been made from the set of three "Puffin Building Books," published by Messrs. Penguin Books, Ltd., earlier this year. This is the second of the series, the first having been a model Cotswold village.

This simple card village was so effective that before I left the shop I purchased a set of Building Books (13s. the set or 4s. 4d. each book), and spent a few hours making up the models. No glue, pins or paint are necessary: just a pair of scissors, pencil and ruler, and a good, sharp blade for cutting slits. (I used an X-Acto knife for this last operation and found it an admirable tool for the job.) I was impressed by the accuracy with which the printed parts fitted together if cut with care and precision.

When completed, the individual buildings, such as farmhouse and barn, manor house,



also designed himself. Mr. John D. Hungerford, of Seattle, Washington, is the ambitious modelmaker who, during 1951, designed and built the model cargo and passenger motorship illustrated in Fig. 1. Mr. Hungerford informs me that his design is on the lines of a modern Scandinavian diesel-engined cargo ship.

Mr. Hungerford's prototype would have an overall length of 314ft., breadth 46ft., DW capacity 3,150 tons, and a service speed of 18 knots. The model is to a scale of kin. to Ift. and thus measures 3ft. 34in. from stern to stem.

The model is built in the traditional style of a full-hull display model and is mounted in a glass showcase. The hull is red below the waterline and white above, with a broad black boot-topping. The superstructure is Fig. 1 (Left).—A view of the decks on Mr. Hungerford's model ship, showing the careful detail work, as befits a display model.

2 (Above).—This realistic Fig. Fig. 2 (Above).—This realistic model of an English half-timbered village was built from "Puffin Building Books." All these cut-out models are based on authentic prototypes and are ready for assembly when cut from the pages of the books.


guildhall, etc., can be arranged to suit the owner's taste, and, incidentally, they would be admirable for use as village scenery on

a gauge 00 model railway layout. The illustration (Fig. 2) shows my own model village when I had finished it.

An American Railroad "Old-timer"

An American Railroad "Old-timer" Mr. H. Bühlimann, of Zurich, Switzerland, has sent me a photograph (Fig. 3) of the latest addition to his collection of models of old-time American steam locomotives. This is the 1890 "Jupiter" of the Baltimore and Ohio Railway, and it is similar to the "Commodore Vanderbilt" of 1885, featured in my article last March. All Mr. Bühlimann's old-time models are gauge o scale and electrically operated.

:24



-A Swiss-made model of an 1890 locomotive of the U.S.A. Baltimore and Ohio Fig. 3.-Railroad. This model is in the collection of Mr. H. Buhlimann of Zurich.

HIGHSTONE UTILITIES



Crystal Sets. Our latest Model is a real radio receiver, which is fitted with a permanent crys-

Fecilier, which fitted with a permanent crys-fitted with a permanent crys-fitted with a permanent crys-fitted with a permanent crys-fitted with a permanent crys-late to the second post of the second



 1/3. póst 4.d. Wire Banis, 6d.

 All deaphones listed are.

 1/3. póst 4.d. Wire Banis, 6d.

 1/4. All deaphones listed are.

 1/5. póst 4.d. Wire Banis, 6d.

 1/6. póst 4.d.

 1/6

with condenser (pencil type), with vest-pocket cills, indispensable for electricians, etc., 7/6, post 5d.
 Sold er in g froms, Our new stream-lined iron is post 5d. Standard from with adjustable bit. 200/250 v. 60 watts, 13/6, post 6d. Heavy Duty Fron, 150 watts 14'6, post 6d. Heavy Duty Fron, 150 watts 14'6, post 6d. Heavy Duty Fron, 150 watts 14'6, post 6d. Heavy Soldering Frons, for use on ras, 1.4, post 6d. packets or Ib. reels. 6/, postage extra.
 Mierophones.-Just the thing for im-promotu concerts, room-to-room communi-cation, etc. Bakelite table model, 6/0 Sespension type, 8/6. Post 6d. May Suttoms (carbon), 2'. Moving Coll, 4/6. Transformers, 5'. All post 4d. each.
 Rotary Transformers, 24 v. input; Output 200, 200/26, carr. 5. Also 12 v. input; Output 6 v. 5 amp.; 150 v. 10 mA. 230 v., 200/20 mA. 22/6. Carrlinge 5'.
 Morse Keys.-Standard-size keys wired to work Buzzer or Lam, 3'. post 6d. Sightly smaller keys, 2/6, post 4d. BUZZERS. 3/6, or heavy duty, 4/6, post 6d. Sightly smaller keys, 2/6, post 4d. 150. Morse Keys.-Standard-size keys wired to more buzzer or camp. 3'. Post 6d. Sightly smaller keys, 2/6, post 4d. 16'.
 Temminals, brass, 2BA mounted on strips and 200 mA. 92/6. Also 150 m. Madet of 10'. doc. post 4d. 41'.
 The Anavy duty, 4/6, post 6d. Sightly smaller keys, 2/6, post 4d. 150 m. Madet of 10'. doc. post 4d. 41'.
 The and 10'.
 The and Phonese of the Sightly seful capital and 200 mA. same price Hybrays, etc., 10'. each, 10'.
 The and Phonese of the sight seful capital and 200 mA. same price Hybrays, etc., 10'. each, 10'.
 The and Phonese of really useful capital and monors key. This country only.
 The Intercommunication Strong metal

All carriage 2/s. This county only.
 Field Intercommunication Sets, complete with ringing hand generator, bell, signal lamp, morso key, relay, in strong metal lamp, morso key, relay, in strong metal lamp, morso key, relay, in strong metal lamp, morso key, relay, in strong the strong structure of the strong structure of the structure of

HIGHSTONE UTILITIES

55, New Wanstead, London, E.11. Letters only. New Illustrated List sent on request with lid. stamp and S.A.E.



5" SANDER-POLISHER £9.17.6

Imagine! One sturdy HANDY-UTILITY power tool, a selection of HANDY-UTILITY accessories and attachments, and you're ready for anything -sanding, grinding, wire brushing ... buffing, waxing, polishing ... and the same magnificent tool can be used as an electric drill, with 1/4" capacity in steel! There are two robust Stands to increase the usefulness of your 5" Sander-Polisher still further. Full particulars from your HANDY-UTILITY dealer.



DEALER, TOOL SHOP, IRONMONGER OR STORE Smee's H.U.40

GALPINS

ELECTRICAL STORES

408 HIGH St., LEWISHAM, S.E.I3

Tel.: Lee Green 0309. Nr. Lewisham Hospital TERMS : CASH WITH ORDER. NO

All goods sent on 7 days' approval against cash

EARLY CLOSING DAY THURSDAY

EX-U.S.A. W.D. ROTARY TRANS-FORMERS, 12 volts D.C., input 500 volts, 50 mlamps., 275 volts 100 mlamps D.C. output. Complete with smoothing switches, fuses, etc., as new, 17/6 each, carriage 216, can be run on 6 volts, giving half the stated output.

MAINS TRANSFORMERS (NEW). 2001250 volts input, in steps of 10 volts, output, 0, 6, 12, 24 volts 6 amps, 42/6 each, post 1/6. Another as above but 10-12 amps, 55/- each, post 1/6; another, as above but 25/30 amps, 75/- each, carriage 3/6; another, input as above, output 0/18/30/36 volts 6 amps, 47/6 each, post 1/6. EX-NAVAL ROTARY CONVERTERS, 110 volts D.C. input, output 230 volts A.C. 50 cycles, I phase, 250 watts capable of 50% overload, weight 100 lb., price £101101- each, carriage forward.

ROTARY CONVERTERS, 24-28 volts D.C. input, 1,200 volts 70 m/zmps, D.C. output, 101- each, P.F.

SWITCHBOARD METERS, 4in. scale moving coil (D.C.) only 0 to 14 amps, 17/6 each, post 1/6.

each, post 1/6, MAINS TRANSFORMERS (NEW), input 200/250 volts in steps of 10 volts, output 350/0/350 volts 180 m/amps, 4 volts 4 amps, 5 volts 3 amps, 6:3 volts 4 amps, 4/51- each, post 1/6; another 350/0/350 volts 180 m/amps, 6:3 volts 8 amps, 0/415 volts 4 amps, 451- each, post 1/6; another 500/0/500 volts 150 amps, 4 volts 4 amps C.T., 6:3 volts 4 amps, C.T., 5 volts 3 amps, 4/16 each, post 1/6; another 425/0/425 volts 160 m/amps, 6:3 volts 4 amps, C.T., twice 5 volts 3 amps, 4/16 each, post 1/6; MAINS TRANSFORMERS (NEW), volts 160 m/amps, 6.3 volts 4 amps, C.T. twice 5 volts 3 amps, 4716 each, post 116. MAINS' TRANSFORMERS (NEW), input 200/250 volts in steps of 10 volts, output 350/0/350 volts 300 m/amps, 6.3 volts 8 amps twice, 4 volts 4 amps, 5 volts 4 amps, 701- each, carriage 316; ditto, 450/01450 volts 250 m/amps, 6.3 volts 8 amps twice 4 volts 4 amps, 5 volts 4 amps, 701-each, carriage 316; another, input as above, output 500/01500 volts 250 m/amps, 6.3 volts 8 amps twice, 6.3 volts 4 amps, 701-each, carriage 316; another, input as above, output 500/01500 volts 250 m/amps, 6.3 volts 8 amps twice, 6.3 volts 4 amps, 701-each, carriage 316; another, input as above, output 500/01350 volts 250 m/amps, 6.3 volts 8 amps, 4 volts 4 amps, 701- each, carriage paid; another, input as above, output 500/350/01350/01sts 250 m/amps, 6.3 volts 6 amps, 012/6.3 volts 2 amps, 0141S volts, 015, 0170 amps, 951- each, carriage 716. MAINS TRANSFORMERS, 230 volts

or 12 voits 501/0 amps, 93- each, carriage 716. MAINS TRANSFORMERS, 230 volts input, 150/01150 volts 200 amps, 6.3 volts 8 amps, 5 volts 2 amps output, 231- each. A UTO WOUND VOLTAGE CHANGER TRANSFORMERS, tapped 011/01200/230 volts 350 watts, 551- each, post 116; as above, but 500 watts 70/-each, post 116; E X-RADAR MAINS TRANS-FORMERS, 230 volts input 50 cycles 1 phase, output 4,50015,000 volts approx. 80 mlamps, 6.3 volts 2 amps, 4 volts 13 amps, 2 volts 2 amps, these transformers are new, immersed in oil, can be taken out of the oil and used as television transformers giving output of 10 mlamps, overall size of transformers separately 51 in. X41 in. X41 in. Autor X31 X241 and Y41 autor 251- each.

and 3in. × 3in. × 2½m., proce the carriage paid. ELECTRIC LIGHT QUARTERLY TYPE CHECK METERS, all for 200/250 volts A.C. 50 cycles I phase, 5 amps load, 17/6 each, post 1/6; 10 amp 21/- each, post 1/6; 20 amps load, 25/- each, post 1/6. EX-R.A.F. ROTARY CONVERTERS. 24 volts D.C. input 50 volts, 50 cycles, 1 phase at 450 watts output, complete with step-up transformer 50 to 230 volts, £9/10/-each, carriage 10/-.

EX-NAVAL ROTARY CONVERTERS, 230 volts D.C. input, 230 volt 50 Cys. 1 phase output, 250 watts, £15 each, carriage 101-. Another 110 volt D.C. input 230 volt 50 Cys. 1 phase output at 850 watts, £25 each, carriage 201-. IN STOCK.—Meters, Chargers, Rheo-stats. Transformers specially made to order. Please forward your enquiry.



EXTENSION SPEAKERS New type baffle stand with metal fret, Sin. Price 25/9. Tax paid. Post: 1/9. Other types and sizes in stock.

SALVAGE RADIO-GRAM CHASSIS

SALVACE RADIO-GRAM CH END DRIVE £7/17/6. FRONT DRIVE £9/17/6. 5 Valve S'het.' 1952 Model. Made to sell at three times this price. Latest pin-type midget valves (BBA series) reconditioned, tested and guar-anteed. Write for details without obligation. Record changer units also available. Single Speed (£1/17/6). and Three Speed (£10/17/6).

C.O.D.



D

SALVAGE MAINS TRANSFORMERS Guaranteed for three months. 260-0-260, 6.3 v., 3 a., 12/9, Post 2/-, Also Standard O.P. Transformers. Salvage, unused, tested. Will match all normal O.P. valves with 2-5 ohm Speech Coils, 3/9. Post 1/6.



(E10/17/6). PERSONAL RADIOS.—Price £6/7/6, 4 v. T.R.F. receiver with choice of walnut brown or ivory plastic cabinet. Complete instructions for building this popular set, including point to point wiring instructions, are supplied with the kit of parts. There is no other comparable set available to-day at this price. When ordering, please state whether you require A.C. model or A.C./D.C. model. Postage and packing 3/6 extra. Assembled ready for use, 35/- extra. VALVES.—Salvage and surplus. Tested. EF91, EF92, EB91, 6F15, EF36, EF50, 6K7, 174, IRS, all at 8/9. SU61, ECL80, at 11/9. 8D2, 9D2, 15D2, SP2, KT32, PEN383, at 6/9.

at 6/9.

PANNIER BAGS. New. 14in. x 10in. x 5½in. Tough vulcanised canvas, lined žin. sponge rubber. Webbing straps with buckle and snap clasp. 7/6 each. Postage 1/6. STEEL BOXES.—Sheet steel, with locking lid, 101in. x 82in. x 51in. With webbing shoulder straps. 2/-. Postage 1/-.

SOLDERING IRONS.--Many as new, but some faulty (repairable). Most sizes and shapes of bits available. 9/9. Postage 9d.

SOLDER .-- Salvage stocks of Ersin Multicore Solder. 12/6 per lb. reel or 4d. yard. WIRE -- Spring Steel in reels of 25 yds. (.032in.) and 50 yds. (.014in.). 1/- per reel. 5 for 4/-. Postage 6d. each. Nickel chrome resistance wire, same sizes, 4/6 per reel.

DUKE'S 621, ROMFORD ROAD, LONDON, E.12. (GRANGEWOOD 6677) MONEY C.W.O. BACK

STAMP FOR 1952 LIST



THIS VALUABLE BOOK

which details the wide range of Engineering and Commercial courses of modern training offered by E.M.I. Institutes-the only Postal College which is part of a world-wide Industrial Organisation. Courses include:-

Mechanical Engineering Gen. Mech. Eng. Diesel Engines Refrigeration Metallurgy Workshop Practice Maintenance Eng. Machine Tools & Metrology Marine Eng.

GUARANTEE

Braughtsmanship Eng. Brawing & Design Tracing Jig & Tool Design

(His

Master's

Voice)

Also. Exami A.M.Brit.L.R Aise CITY a Neating & of Commerci STITUTES

associated with

N

MARCONIPHONE

COLUMBIA &

Radio & Television Gen. Radio & T/V Eng. Radio & T/V Servicing Radar Sound Recording Industrial Electronics Advanced Radio P.M.G. Certificates Radio Amateurs Licence

Electrical Engineering Gen. Elect. Eng. Installations & Wiring I.E.E. Theory

Civil Engineering and Building Civil Eng. **Building Construction** Heating & Ventilating Sanitary Eng. Surveying **Clerk of Works** Carpentry & Joinery **Builders Clerks**

Automobile Engineering Gen. Motor Eng. High Speed Oil Englnes Garage Management

Production Engineering & Management Gen. Prod. Eng. Industrial Admia Works Management Production Planning Personnel Management Time & Motion Study Costing Office Practice

Aeronautical Engineering Gen. Aero. Eng. A.R.B. Licences A.R.M. Certificates

nation Courses for: General Certificate of Education, I	B.Sc. (Eng.), Common Preliminary, A.M.J.Mech.E., A.M.I.C.E., A.M.I.Strucl.E.
	& V.E., M.R.San.I., A.M.I.San.E., A.M.I.Munc.E., A.M.I.E.D., A.M.S.E., L.I.O.B
id GUILDS Certificates in Mechanical, Electrical, Aeronautic	al, Automobile, Telecommunications and Structural Engineering; Refrigeration
Ventilation. Courses also provided for all branches	POST NOW
e and Business Management.	Please send, without obligation, the above FREE BOOK.
	rieuse seno, michour oungation, die above much book.

COURSES	E.M.
FROM	Subjec
12	Name
1.62	Addre
PER MONTH	

PUST NUT	
Please send, without obligation, the above FREE BOOK	
E.M.I. Institutes, Dept. 144, 43 Grove Park Rd., London	W,4
Subject(s) which interest me	
Name	
Address	

ICIOG

Amateur Telescope Discs SIR,-With reference to the O correspondence pub-lished on page 358 of your July issue concerning the making of a telescope re-

flector, your readers may be interested to know that we can supply amateur te escope makers with the necessary blanks made in the finest quality white optical glass. They can be supplied in 6in., 8in., 10in., 12in., can be supplied in 6in., 8in., 10in., 12in., 14in., 16in. and 18in. diameter, both in white crown glass and in low expansion glass, We with or without the edges machined. can also offer discs in well annealed green plate glass for grinding "tools." Any of the above sizes are usually held in stock, but we can accept orders for non-standard sizes at slightly increased prices. In either case we are happy to deal direct with the telescope maker

It might also be of interest to know that we can supply blanks for crown and flint combinations for object glasses, also material from which eyepieces can be constructed .-CHANCE BROTHERS LIMITED, 28, St. James's Square, London, S.W.I.

Tramway Exhibition

SIR,-With reference to the notice in D PRACTICAL MECHANICS concerning our recent Tramway Exhibition.

We had a very successful show, and were very agreeably surprised at the public's interest in Tramway History. Most of our models were up to Science Museum standard, and all in 3in. scale representing cars from Colchester, East Ham, West Ham, Erith and London County Council. Smaller exhibits ranged from "oo" to "o" gauge, and com-prised S.M.E.T., Croydon, M.E.T. and Blackpool.

I should also like to mention that PRACTICAL MECHANICS was the means of a very early relic coming to light, to wit, an early brass Token, given in exchange for the necessary cash, before the introduction of the paper ticket dating back to 1864. This was sent to me by one of your readers named Mr. Miles, of Stoke-on-Trent. One side portrays in relief, Francis Train's Marble Arch Tramway, and the other side Stafford-shire Potteries Street Railway Co., Limited, "Train's Patent." Many thanks are due to the journal and to Mr. Miles .- F. J. ROCHE (East Ham).

Boat Engine Problems

SIR,-Here are a few suggestions regarding S boat engine problems mentioned in an inquiry from J. Lappage published in the August issue of PRACTICAL MECHANICS.

I would like to point out that conversion kits can be obtained for Ford, Austin and Morris engines (to convert from car to marine engines) from a number of firms including A. C. Whitehorn, Ltd., 110, Ashley Rd., Bristol, who would probably suggest the best propeller for the converted engine and hull. Also, a closed-water circuit is better in muddy water, in order to prevent the jacket silting-up. It is comparatively easy to make a heat exchanger for the cooling water and




fit it under the hull in contact with the river water .--- A. BROWN (Cardiff).

Westminster Chimes

S IR,-I wish to submit an idea which I think improves "Westminster Chines." The same arrangement is useful for rewinding and setting the chimes, and can be adapted very simply to the specification given in PRACTICAL MECHANICS for May, 1952. I have had this idea working very efficiently in the set I made some while ago.

Instead of having the grooved wheel (in




which the weights are suspended) the wheel on which a rachet is fixed revolves freely on the camshaft. Engaging the ratchet is a cog-wheel which is sweated to the camshaft end.

The operation for rewinding is, therefore, to pull down the light weight (as in winding a clock) until the trigger in the relay just clicks and it is then ready for a further period of chimes.—T. A. DEIGHTON, (Cottingham).

Model Diesel-driven Launch

SIR,-The enclosed photograph shows a two-thirds of a metre model launch I have built similar to streamlined construc-tional details of which are given in your book "Model Boat Building." The engine is an E.D. Mark II diesel and the propeller is cast in aluminium and hand finished. The boat weighs 4lbs. in sailing trim, and this



Mr. N. I. S. Crosslev's model launch.

includes a 40z. fuel tank made of copper tubing 2in. diameter added since the photograph was taken.

The rudder is the same size as fitted to the metre boat, as the smaller one originally fitted allowed the boat to wander off course. She is too fast to handle comfortably, except on a line.—NORMAN I. S. CROSSLEY (Hazel Grove).

Tropical Aquariums

SIR,-I read with interest the article in the August issue by H. R. Hodgkinson on making a safety device for tropical aquariums. I would like to point out that unless the author is concerned with the requirements of the rarer and more delicate species of tropical fish he is mistaken when he states that the water temperature of a tropical aquarium must be maintained within 2 deg of 75 deg. F., and that should the heater fail the fish will die in a few hours. The majority of tropical fish which have

been hardened, by being accustomed to a temperature which varies by 3 or 4 deg., being higher in summer than in winter, and lower during the night than during the day, are unaffected by a temperature as low as 68 deg. F., and only when the temperature drops to 65 deg. F. is there imminent dan-ger of the health of such fish being imperiled. However, fish which are accustomed to a water temperature continually lept at 75 deg. F. are very susceptible to a sudden slight drop in temperature, caused either by the failure of a heater, or by the aquarium being in a cold draught from an open door or window.

The important point is, that should for any reason the temperature be allowed to fall. it must be restored to its normal value very gradually if no ill effects on the fish are to be experienced.

It would take much longer than a few hours for the water temperature of an averaged sized tank, kept in a living room, to fall below the value required by hardened fish

I mention these points to try to prevent the potential aquarist from getting the impression that he must become a slave to his thermometer, if his fish are to be healthy.—P. R. C. STANDEVEN (Bradford).

Interplanetary Space Travel

S IR,—With reference to Arthur C. Clarke's book, "The Exploration of Space," also to letters from readers Dennis Urch and H. H. Porritt in a recent issue.

Einstein's theory of Relativity is incorrectly and optimistically used to save time in space travel to the distant stars. Stating that time in a rocket near light speed is slower than Earth's time is only half the picture.

According to Einstein's theory, absolute motion (speed) cannot be measured or detected, and only *relative* motion can be measured.

If we take an object A and say that it is at 98 per cent. light speed, we must ask relative to what? Then A is at 98 per cent. L.S. to object B; also it is equally true to say that B is at 98 per cent. L.S. to A. We can take our choice. Another point is that the speed of light will remain constant to both A and **B**, no matter what their speed or direction. This is a fundamental of the relativity theory.

Now as we can only measure relative motion, the speed of our rocket must be measured *relative* to some other body, such as the Earth. But if the rocket speed is relative to the Earth, it is just as correct to say the Earth is travelling relative to the rocket. And in this case it is the Earth's

time that is slower than the rocket's. This leaves us with a situation which depends on our point of view. Is it the rocket

(Continued at foot of page 38).



"Handicrafts with X-acto"

TRIX LIMITED, of 11. Old Burlington Street, London, W.I, have just issued the second edition of their comprehensive handbook bearing the above title. Written by W. A. G. Bradman, F.R.S.A., the book, which is well illustrated, is intended to show how the well-known X-acto tools can be used for a variety of purposes including chip carving, inlay stringing, intarsia work, wood joints, pictorial marquetry, paper sculpture, scraper board work and lino-cutting. Further information concerning this useful handbook (priced at 4/6) can be obtained from Trix Ltd., at the above address.

Water-bottle Tops

A NEW water-bottle top was recently introduced to the motoring trade by Creators Ltd. It is manufactured from P.V.C., and will fit most bottle necks up to 1¹/₂ in. diameter. It is ideally suited for the motorist who wishes to keep his own supply of distilled water in an old oil or mineral water bottle. The cap is resistant to acids, grease and water, and is supplied in two colours red and green.

Retail price is 1/- each (supplied to the trade in display cards of eighteen, and subject to fulli retail and trade discounts).

BUILDING A TAPE RECORDER

(Continued from page 13)

(earth) pin on the plug used on the chassis. If it is found that there is a slight residual hum a separate wire must be connected to the chassis and taken to a good earth connection. A length of standard 80 ohm coaxial cable is joined to the soldering lugs of the recording head, and a coaxial plug attached to the other end for insertion in the socket on the top of the chassis.

Operation

To use the recorder, place an empty spool on the right-hand spindle and a spool of tape on the left-hand spindle, with the end leading off from the left, so that it may be taken across the table to the right, and attach the adhesive end of the tape to the centre of the right-hand spool. Looking down on the deck the tape should come down from the left-hand side of the lefthand spool across the deck to the right-hand side of the right-hand spool, this revolving in an anti-clockwise direction when switched on. The righthand spool should be rotated by hand anti-clockwise until two or three turns of tape have been taken up, and then the length of tape between the spools should be carefully lifted and placed across the copper face of the two heads, and round the cap-stan top, and the slack taken up. Turn the tape-deck switch to its centre position (" play"), and the main panel switch to "record." Set the record volume control about half-way on, and turn the play-back control until the mains switches click to the "on" position. Do not turn the control any farther. Wait a few moments for the valves to attain maximum temperature, plug a microphone into the Input 1 socket and then close the tape-drive control which will switch on the motor and cause the tape to be slowly wound off the left-hand spool on

Further information can be obtained from Strand Publicity Ltd., 10, Stanhope Row, Mayfair, W.1.



The new water-bottle tops, by Creators Ltd.

to the right-hand one. As soon as it is seen to be moving smoothly, speak a few words close to the mike, stop the tape by opening the tape control and turn the record volume control back to zero.

Now lift the tape clear of the heads and turn the tape-deck switch to the left, which is the position of rapid re-wind. Holding the tape drive control knob carefully, close it until the motor starts and as soon as a few inches of tape have been wound back (approximately as much as was wound off to make the test recording), open the switch, replace the tape and you are ready to play back the recording. Turn the tape-deck lefthand switch to its central position again, and turn the main switch to "play-back." Turn up the volume control (VR2) to maximum, and start the tape. You should hear the test recording, and if heard but not clear, a slight adjustment should be made to the slotted control on the bias unit. This will probably have to be about one-quarter of the way on in a clockwise direction. The correct setting of this bias control depends upon the tape used, and too high a bias will give a weak signal as it will partially erase it, and too little bias will give a distorted signal. A few test recordings should be made to find the best setting, and once adjusted this will not have to be touched again unless a different make of tape is used.

The play-back volume control may be set to about $\frac{1}{4}$ to $\frac{1}{2}$ way on and used as a monitor when recording, provided that care is taken to keep the microphone facing away from the speaker, as otherwise microphonic feed-back will take place and a howl will start which will be difficult to stop. For testing the recording section when first setting up a pair of headphones may be connected by means of a suitable plug to the socket on the top of the chassis, disconnecting the lead from here to the recording head. Johnsons Photographic Apparatus and Accessories Division

WE are informed by Johnsons of Hendon Ltd., that the progressive expansion of this section of their business has necessitated a move to much larger premises in Hendon. As from Monday, September 15th, the address of the photographic apparatus and accessories division of the company will be: Apparatus House, 35 and 37, Brent Street, Hendon, N.W.4. (Telephone (unchanged): HEN 7671.

The head office, laboratories and works remain, of course, at 335, Hendon Way.

It would prevent delay and help considerably if orders and correspondence referring only to apparatus and accessories were in future addressed to the Brent Street premises.

"Gryphon" Fractional H.P. Motors

AS a result of continued research in the Brook laboratories, since the introduction of their fractional horse-power motor, they have now developed a new type embodying many improvements in design and performance. The stator is housed in a heavy steel shell with a strong, detachable castiron foot. End shields, too, are of sturdy design with reinforcing rings and ribbed openings, all of which contribute to quieter, vibrationless running and consequent lessening of strain on the bearings.

Further particulars are obtainable from Brook Motors, Ltd., Empress Works, Huddersfield.

MODEL OF HYDRO-ELECTRIC POWER STATION

WITH reference to our "World of Models" article in the September issue, concerning model hydro-electric power stations, "Motilus" writes to us as follows:

"I was given wrong information and I must apologise to the North of Scotland Hydro-electric Board and the firms concerned. I have now ascertained the correct information which is as follows:

"The model is to illustrate a pipe-line for a hydro-electric scheme. It is not full length to scale, as it would have been too long for general purposes, but it does include every essential detail. It was constructed from drawings and photographs of the Grudie Bridge installation, to the order of Messrs. Mechans, Ltd., of Glasgow, who supplied the pipe-line for the prototype."

LETTERS FROM READERS

(Continued from page 37)

or the Earth at 98 per cent. Light Speed? We make our choice and it is *that* one's time which is going slower.

One other point which seems to have been overlooked: at near light velocity, to an observer (if that were possible) there would be a space time continuous expansion, i.e., slowing of time and increase of space (distance) for the pilot of our rocket. This means that the pilot would gain nothing from the slowing of time, as the distance to a star would increase by the same factor.

Also, to our pilot's point of view, space and time would be normal. To him it would be the observer's space time that had expanded.

So there is nothing to justify the view that light velocities would shorten the time or distances to the stars. It will still take 100 years to travel 100 light years at the speed of light.—A. J. BULL (London, W.6).



Every man or woman who uses words, will find this Idea and Word Chart a priceless boon. lt's a godsend to all. It gives the word yoù want when you want it. Words and ideas leap into the mind-vitalise the message-grip the interest — sway - convince compel. Easy-quick-sure.

Have you always at immediate command just the word you need ? You can have. It's easy with this amazing Chart. Send for a free specimen copy embodied in a descriptive brochure. Enclose 21d. stamp for postage.

PSYCHOLOGY PUBLISHING CO., LTD. (DEPT. PR/HV20) MARPLE CHESHIRE

You Can Become a HANDICRAFTS INSTRUCTOR

EXPERIENCE NOT ESSENTIAL Men who enjoy making things in Men who enjoy making things in wood or metal can turn their hobby into a permanent and interesting *Career 1* Short hours, long holidays, and security in a job you would really enjoy, can be yours if you become a Handicrafts Instructor, Let us send you details of the easiest and quickest way to get the necessary qualification.

We definitely Guarantee "NO PASS-NO FEE"

If you would like to know about our unique method of preparing you for one of these appointments, write today, and we will send you an informative 144-page Handbook-FREE and without obligation. Mark your letter "Handicrafts Instructor." British Institute of Engineering Technology

591, Shakespeare House, 17/19, Stratford Pl., London, W.1 BIET



NEWNES PRACTICAL MECHANICS

0



0

The French International held at Cormeilles-en-Vexin on Sunday, 29th June, 1952. Placings :

Dr. C. Gobeaux (Belgium), E.D. "Radio Queen" & E.D. Mk. IV 1st Engine.

2nd H. J. Taplin (Britain), E.D. "Radio Queen," E.D. Mk. IV Engine & E.D. Mk. II Radio.

4th & E.D. Mk. III Radio.

G. Honnest-Reddlich (Britain), Veron Skyskooter, E.D. Mk. I Engine & E.D. Mk. III Radio. 6th

D. Taplin (Britain), E.D. "Radio ueen," E.D. Mk. IV Engine & E.D. 7th Queen," E.D. Mk. 11 Radio.

(Out of 18 competitors.)

The "LANE"

D

1st (2.5 c.c. class), held in Brussels on Sunday, 6th July.

Wright (Britain), Engine, E.D. 2.46, Glo-plug head. Speed, 98.54 m.p.h.

Diesel engines, kit sets, radio control units and accessories. Your nearest model shop will give you full details. SEE US AT STAND No. 30 AT THE

MODEL ENGINEER EXHIBITION

E.D. Mk. III 2.46 RACING ENGINE Can be used as a diesel, glo-plug or spark ignition engine. Develops over a b.h.p. at 14,000 r.p.m. plus. Two ball-race crank shaft and exhausts as an integral

part of the crank case. Total weight 5 oz. Price £4 2s. 6d.

THE E.D.

"RADIO QUEEN"

Specially designed for remote control by the E.D. Radio Control Unit and to be powered by the E.D. 3.46 Mk, IV Diesel. Radio Queen Kit Set. Price £4 5s. 0d.

1223 IS, VILLIER'S ROAD, KINGSTON, ON THAMES, SURREY, ENGLAND. **MICRO-LATHE**

PRICE £10-3-2 (Carriage extra-Average 4/6)

COUNTERSHAFT (less large pulley), £2/4/0. DRILL CHUCK, "O" Shank, 8/3.

ELECTRIC MOTOR, I Ph. 230/25 V. 1 h p. Constant Speed, £5/0/0. Neat Portable Home Workshop built from

'LANE'' components Photo shows "LANE" Micro-lathe reducing Jin. mild steel bar down to In. IN ONE CUT, GENUINE REPEATABLE PERFORMANCE.

2½in. x 4 Jaw Indep. Chuck, 38/6.

TELEPHONE- SETS, comprising G.P.O. hand-phones, 2 bells, 2 push G.P.O. hand-phones, 2 bolls, 2 pushes and 80ft. twin wire. Price 65'- post free. Makes an excellent inter-office. works or domestic installation. Really professional instruments, Brand new, not rubbish. Single instruments, 18/6. not rubbish. Single instruments, 18/6. BATTERY CHARGERS for A.C. mains. For charging 2-volt accumu-lators at 4 amp. Parts with diagram. 17/8. Complete, 21/6. Postage 10/1. FOR TRICKLE CHARGING CAR CELLS, parts with diagram. Output 14 amps. for 6v. or 12v. cells. Price 42/6. Post 1/-. 3 amp. output, 50/-. POWERFUL HAND ENGRAVER for all Metals, Plastics, etc. Operates from 6 v. battery or through trans-former, 12/6. Post 1/-. Instrument Wires, Ebonite. Metals. Workshop Materials. Illustrated List 2d. ECONOMIC ELECTRIC Cc.

WILCO FIECTRO

204, LOWER ADDISCOMBE ROAD. CROYDON. ADDiscombe 2027

"INEXPENSIVE TELEVISION." I vised and enlarged edition giving circuit R1365, etc., also 45Me/s Pye Strip, 2 post 3d. 2/6

RECEIVER R.135; as specified for "In-expensive Television." Complete with 10 valves, 45/-, Cge. 76. 45 Me.s PYE STRIP. A ready-made vision receiver for London frequency. Complete with 6 EF50 valves and an EA50. 57/6, post and pkg. 16.

yest and pkg. 16. WICROAMNETER. D.C. 100-0-100, 21in. Bush. 40:-, post 1/6. MOVING COIL METER with 1 M/A movement, 21in. flush. rectifler type, scaled 0/100 volts A.C. Resistance 100 K. ohms. A vory useful basic meter 30/- post free. EF50 VALVES. Red Sylvanian or British Guaranteed unused. Ex new equipment Guaranteed 76. post 6d.

7 6, post 6a. **PORTARLE TEST METER.** Just the job for the home constructor, in meat caso, fin x 51n. x 41m., reading 1.5, 3, 150 volts, 6 and 60 m/a, D.C., 5 k. and 25 k. ohms. \$7/6. post 1/6.

The both first block of a final both for the both first block of the both for the b

PHOTO FLOOD LAMPS, -1,000 watt. 230 volt, 10'- each, post 1'-. RI'SISTANCE MATS.-Make Ideal heating mats for Aquariums, Photographic solu-tions, Print dryers, etc. Mains voltage, 150 or 620 watts, Black heat, size 10in, x 6in, 2/6 post free.

METAL RECTIFIERS. Bridge Types. 6 v. 1a., 10/6; 12 v. 1a., 12/6; 24 v. 75 mA., 5/-; 36 v. 25 a., 30/-; 48 v. 75 mA., 7/6; 48 v. 150 mA., 10/-; 26 v. 25 a., 75/-, Post L-**28** V. 180 HPA, 10⁻¹ row 1, 100 g, 11n, diameter. Any number of sections can be fitted to-gether. 2/6 dozen, 6/- for 3 dozen, 11/- half gross, 20/- gross, 26 per 1,000.

SLOW MOTION DIALS,--6in. Scaled 0-100, reduction 20 i or direct, ideal for wavemeters, signal generators, etc., Our price, while they last, 5/6 each, post 1'price, while they last, 5/6 each, post 1'-. THIERMOSTAT SWITCH.—Binetal type in scaled glass tube, 21in. x in. 30 deg. Cent. Ideal for Aquarlums, Wax and Oil Baths, Gluepots, etc. Will control 1 amp. at 240 v., 5'- each, post 6d. THERMOSTAT.—Satchwell 12in. stem, 0250 v.A.C.D.C., 15 amps. A.C., 1 amp. D.C., 10 to 90 dog. Cent. 35/-, post 1.6. ELASHING: SWITCH INIT with 6

10 to 90 dog. Cent., 35/-, post 1.6. FLASHING SWITCH UNIT with 6 contacts. Full rotation 60 seconds, operated by a sangamo Synchronous Motor. 230 volts A.C. 2 watts. In metal case, 31/n. x 21/m. x 21/m. 13/-, post 1/-. ACFIL PUMPS.-These pumps enable you to fill all accumulators on the bench with the carboy at floor level. Brand new. only 30/-, post 1/6.

only 30-, post 1/6. INTERESTED IN FISHING ?-Then send for one of our tapered whip aorials and make yourself a fine rod worth pounds. Consists of three tubular steel, seamless copper plated sections 4ft. Jong, which screw into each other and are well finished, 7f6, carriage 2/-. (Erc, 6/6.) CUTIER IEADS.-" Recording " high impedance. A bargain at 55- each, post 1/-. CUTTER STYLII, 6/- per doz., large quantity available at special rates. PORTARLE ELECTRIC BLOWERS.-

PORTABLE ELECTRIC BLOWERS. 220,230 volts 220 watts. Completely e closed, 8tt. flexible hose and nozzle, 7 yd C.T.S. Flex. Many uses where clean, di ahr is required. 28/15/-.

ACCUMULATOR CHARGERS in black caccie cas with fuses and meter, 6 and 12 volts at 4 annys. Bargain Price, £4/19/6. Pkg. and carr., 5/-. "ELF" CIRCUIT BREAKER, 220 volts, 2 annys., size 31n. round, 10/6, post 1/-.

KLAXON GEARED MOTORS No. 1K58B3-W7. Torque 15 lbs. ins., 175 r.p.m., 220/240 v. A.C. Induction type, £10 each. 24-VOLT D.C. MOTORS with double ended shaft 2in. x 3in., 8/6, post 1/-.


TWIN FLEX in black braided covering, approx. 25-yd. coils, 7/6, post 1/-.

PRE-AMPLIFIERS for T.V., including EF50 valve, 15/- each, post 1/6.

HAND TELEPHONE. Brand new with cord, 15/- each, post 1/G. INERT CELLS, 14 volts, size 2in, x 2in, x in. Just add water, last for years, ideal for Electric Bellš, Telephones, Models, etc. Only 2/- each, post and pkg. 1/-, or 4 for 10/-, post free.

VOLTAGE REGULATOR.-Input 230 volts A.C., 21 amps.; output, 57.5 volts to 228 volts in 16 steps with current limiting reactor. Ideal for welding, £15.

MASTS, TELESCOPIC. Extending to 12it. in 7 sections. 15/6, post 1/6.





This interesting circuit is designed around the famous "twin" valve now available as a British midget type operating from midget dry batteries. By the use of midget components and the elimination of tuning coils the set, when not in use, is small enough to slip into the jacket pocket. This set requires no aerial or earth, and can be used indoors or out, giving powerful headphone reception of many stations on the medium waveband. Full instructions, circuit, point-to-point wiring diagram, and component itst. **PRICE 3'3 POST FREE.**

PRICE 3'3 POST FREE. SWIFT RADIO (P) 137, Cotham Brow, Bristol, 6. ORDERS BY POST ONLY

64 London Rd., Twickenham

39

NEWNES PRACTICAL MECHANICS

October, 1952



Fifty top-ranking specialists give you the fruits of their lifetime's experience

This latest Newnes' technical work has been planned in particular to aid the ambitious engineer. Written by the foremost specialist engineers in the light of post-war development and experience, it sets out to equip you with knowledge vitally necessary if you wish to gain a higher position. You can examine the complete work in your own home free of charge and without obligation.

Basic Processes and Machines Modern Methods and Materials Production Engineering Installation, Operation & Maintenance

Here is what you receive for Free Examination

2,022 pages of invaluable infor-mation written by skilled engineers, many of them executives of world-famous engineering firms. 2,000 instructive works photographs, diagrams, per-spective and working drawings, etc. 4 Volumes strongly bound in Rich Maroon Canvas Cloth.

24 Unique Data Sheets, contain-ing facts, figures, engineering drawings, special photographs, etc.

JUDGE THIS NEW WORK FOR YOURSELF

without cost or obligation You are invited to examine it in your own home for 7 days. No cost—no obligation. You are the sole judge of its value to you. Simply complete and post coupon below. DO THIS TO-DAY— NOW—it is to your advantage.

If you do not wish to cut your" Practical Mechanics," apply on own notepaper to George Newnes Ltd. (PME.1), 66/69, Great Queen St., London, W.C.2.

12 Instructive Wall Charts, pre-senting technical details -in convenient form.

1 Strong Chart Case, with pockets for Data Sheets and Wall Charts. Bound in cloth.

1 copy. Workshop Calculations, Tables and Formulae, a time-saving and work-saving pocket book for engineers.

2 Years' Free Technical Advisory Service.

7

l

1

- - FREE EXAMINATION

To: GEORGE NEWNES Ltd., 66-69 Great Queen St., London, W.C.2.

YES, send me post paid for seven days' FREE examination Newnes' ENGINEERING WORKS PRACTICE.

It is understood that I may return the work within eight days with no further obligation. If I keep it I will send you a first payment of 10s. 6d. eight days after delivery and 10s. 6d. monthly thereafter until the sum of \pounds 7 17s. 6d. has been paid. Cash price within eight days is \pounds 7 10s. 0d.

Name				
			Househol	
	10 N N	4	Date	
(Parent's if under	21)		Date	PME.1



Best British makes, 6 x 30. Eyepiece focusing. Complete with web case. Guaranteed £7-19-6 condition. Post 2/- extra.

U.S. ARMY LENSATIC COMPASSES

Incorporates lens system and sighting vein, thereby enabling bearings to be taken. Card diameter 17in. Weight 24 oz. Unused and perfect. Complete in waterproof case. 92/6 including, postage. 22/6

BRITEX MICROSCOPES

A soundly designed and well constructed microscope with built-in illumination. Specifica-tion: height 9in.; stage, 2žin. x 2in.; magnification, X50 to X150. Postage 1/6 extra.

MSE OPTICAL UNITS

This is an optical locating device for fitting to own Jacob's Chuck of {in. or {in. It is totally enclosed and a sight can readily be taken down the spindle centre, through the chuck on to the workpiece markings. Available in shanks of No. 2 or No. 3 Morse taper. Unused and perfect at almost half makers' price. Including postage. £6-15-0

EX-GOVERNMENT BARR & STROUD RANGEFINDERS

Coincidence type, 80cm. base. Range from 250yds, to 20,000yds. Can be read directly, quickly and accurately on measuring scale. Magnification 10 X. Nett weight 13bs. Overall length 35jin. Each instrument tested and guaranteed to be in perfect condition. Original cost approx. £100. Complete with wood transit case. Carriage free U.K. £12

SATISFACTION GUARANTEED ON ALL PURCHASES OR FULL REFUND

A few oddments in precision measuring tools available. Unique and interesting stocks of Astro Telescopes and Binoculars; Drawing and Surveying Instruments; Navigational Equipment. Photographic Goods. We specialize in apparatus for the home constructor. Lists available

CHARLES FRANK Phone: BELL 2106 Grams : BINOCAM, GLASGOW,

Instrument makers and Dealers. since 1907.

67-73, SALTMARKET

GLASGOW, C.I

October, 1952



stamped, addressed envelope, three penny A stamped, addressed envelope, three penny stamps, and the query coupon from the current issue, which appears on page 8 (THE CYCLIST), must be enclosed with every letter containing a query. Every query and drawing which is sent must bear the name and address of the reader. Send your queries to the Editor, PRACTICAL MECHANICS, Geo. Newnes, Ltd., Tower House, Southampton Street, Strand, London, W.C.2.

Paper Making at Home

I WOULD like to carry out an experiment at home of trying to make a rough or crude type of paper. Is it at all possible and, if so, could you give me any information on how to proceed ? --E. Minshall (Northwich).

you give me any information on now to proceed r -E. Minshall (Northwich). TO make even the crudest of papers you must have some sort of "beating engine." This consists of a wooden drum with nails around its periphery. This drum is revolved under water so that the periphery. This drum is revolved under water so that the periphery. This drum is revolved under water so that the periphery. This drum is revolved under water so that the periphery. This drum is revolved under water so that the periphery nails come into close contact with a series of nails driven in the side of the vat. Whils the drum is revolving paper is pushed down on to it so that the paper is forced into contact with the nails on the side of the vat. Between these nails and the nails on the drum it is gradually shredded. Gradually, paper fabre will be suspended in the water and it will give a white, milky appearance to the latter. When the water has a fine metallic gauze. This retains the shredded fibres of paper and enables them to be laid out on the gauze, thus bringing into being a sheet of paper-like material. The thinner the paper used for shredding, the better will be the latter process and the better the quality of the paper prepared. For an experiment, ordinary tissue paper shredded into, and boiled up with, hot water will give quite passable results, although the newly-made paper would be much more enduring if it were passed alum and 92 parts water. Modernicing Old Picture Frames

Modernising Old Picture Frames

I WISH to give a modern finish to a number of old picture frames, and would be very grateful if you could advise me in this matter. I have seen various finishes, some smooth and some rough, but they are generally off-white in colour. -K. Bachmann (Hove).

<text><text><text><text><text><text><text><text>

By obtaining the colours in quantity and by making

the gelatine binding medium yourself, the whole cost of the picture decoration can be reduced to an absolute minimum.

Dental Waxes

I. The enclosed sample of wax is used for sticking artificial teeth in boxes and on dis-play cards. Could you give me the composition and any idea of how it is made, and what ingredient would raise or lower its melting point? I will need to make it into strips of jin. z jin. Could you

Readers are asked to note that we have discontinued our electrical query service. Replies that appear in these pages from time to time are old ones and are published as being of general interest. Witt readers requiring information on other subjects please be as brief as possible with their enquiries.

suggest a way of doing that and a lubricant for the mould employed ? Please give the names of suppliers of the ingredients. 2. The enclosed wafer is part of a "base plate" which is used for reinforcing wax "try ins." Could you tell me its composition, where the ingredients may be obtained, and a suitable mould lubrleant for it ?--M. Behan, L.D.S. (Drogheda).

I. It would take about two weeks of an analyst's time to investigate the composition of the two wax samples which you have submitted for examination, particularly in view of the complexity of the modern dental waxes. We feel sure, therefore, that you will not expect our query service to undertake this specialist and professional work for you. There are, however, innumerable wax mixtures which you could make up for yourself fairly easily. Here is one of an average, simple composition:

Paraffin wax			90	parts (by	weight).
Ceresin Beeswax	***			99	99
Japan wax	• • •		40	55	33
Prime yellow Carn	auba wa	ax	. 3	55	57 · . 75
Venice turpentine				33	92

Melt the waxes in a pan heated on a steam or water bath. Add a little wax or oil-soluble dye to give the shade and colour required, or, in place of this, stir in a small quantity of rouge or finely-ground iron oxide. Finally, stir in the Venice turpentine. Pour the mixture, whilst still warm, into narrow wooden channels made by nailing wood strips together, using a strong paste of soap and water as the mould lubricant.

THE P.M. BLUE-PRINT SERVICE
12FT. ALL-WOOD CANOE. New Series, No. 1, 3s. 6d.*
IO-WATT MOTOR. New Series. No. 2, 35. 6d.* COMPRESSED-AIR MODEL AERO ENGINE. New Series. No. 3, 5s.*
AIR RESERVOIR FOR COMPRESSED-AIR AERO ENGINE, New Series. No. 3a, 1s. "SPORTS" PEDAL CAR. New Series. No. 4, 5s.*
F. J. CAMM'S FLASH STEAM PLANT. New Series. No. 5, 5s.
SYNCHRONOUS ELECTRIC CLOCK. New Series. No. 6, 5s.*
ELECTRIC DOOR-CHIME. No. 7, 3s. 6d.* ASTRONOMICAL TELESCOPE. New Series. No. 8 (2 sheets), 7s.*
CANVAS CANOE. New Series. No. 9, 3s. 6d.*
DIASCOPE. New Series. No. 10, 3s. 6d.*
EPISCOPE. New Series. No. 11, 3s. 6d.*
PANTOGRAPH. New Series. No. 12, 1s. 6d.*
COMPRESSED-AIR PAINT SPRAYING PLANT. New Series. No. 13, 7s. 6d.*
MASTER BATTERY CLOCK [®] Blue-prints (2 sheets), 3s. 6d. Art board dial for above clock, 1s.
AUTROADD CRECOROAT

OUTBOARD SPEEDBOAT 10s. 6d. per set of three sheets.

LIGHTWEIGHT MODEL MONOPLANE. Full-size blue-print, 3s. 6d.

P.M. TRAILER CARAVAN. Complete set, 10s. 6d.*

P.M. BATTERY SLAVE CLOCK---2s. RECEIVER.

" PRACTICAL TELEVISION " (3 sheets), 10s. 6d. The above blue-prints are obtainable, post free,

from Messrs. George Newnes, Ltd , Tower House, Southampton Street, Strand, W.C.2.

An * denotes constructional details are available, free with the blueprints.

Any ordinary pharmacist should be able to supply the above materials and thus save you the cost of carriage. If not, apply to a good London firm of laboratorysuppliers, such as Messrs. Baird and Tatlock, Ltd., 14-17, St. Cross Street, Hatton Garder, London, E.C.1, or Messrs. Hopkin and Williams, Ltd., St. Cross Street, Hatton Garden, London, E.C.1. 2. The "wafer" which you mention is built up on the same lines as the above, but is softer and more adhesive. You can lower the softening-up point and increase the plasticity of these waxes by increasing the amount of Venice turpentine which is incorporated, by increasing the amount of the white waxes (parafin and ceresin) or by adding one or two parts of a plasticising liquid, such as tricrescyl phosphate. You can harden the wax mixtures by reducing, the proportions of the above ingredients, and, also, by increasing the amounts of the Carnauba wax, which is the hardest of all the waxes. waxes.

waxes. It would, in our opinion, be far better for you to obtain these particular waxes from a dental manufactur-ing firm, rath r than to attempt to make them up on your own initiative and without adequate experience and "know how."

Formula for Flexible Moulding Compound

COULD you supply me with a formula for making a flexible, moulding compound for plaster casting ?—P. Reed, (Greenock).

Interest of the second seco

with. For use, the stiff product should be placed in a basin and surrounded by hot water, or even merely warm water. It will quickly become as flexible as rubber, and when allowed to cool will rapidly set stiff again. We take it that this is the sort of thing which you desire.

Frosting Electric-light Bulbs

PLEASE tell me how to "frost" clear electric light bulbs (230 v.). The type of bulbs I have had to use can only be obtained in the clear state and they give too brilliant a light.—G. W. Eyre (Cleethorpes).

and they give too orminant a fight.—G. w. Eyre (Cleethorpes).
 THE only method of permanently frosting the outside of clear electric-light bulbs is by means of the fumes of hydrofluoric acid. This substance actually corrodes the glass surface and thereby renders it opaque very effectively. Place a small quantity of powdered fluorspar at the bottom of a lead or iron vessel and cover the substance with strong sulphuric acid. Place the bulb to be frosted in the upper part of the vessel and then put the whole assembly in a pan of hot water. Under the influence of heat, the fluorsparsulphuric acid mixture will generate free hydrofluoric acid which will pass off as a gas and thereby make contact with the glass of the bulb above. When the bulb has become frosted sufficiently it is merely rinsed in water and drice.
 A still simpler method of effecting this result is to dip the bulb for a few minutes in a warm dilute solution of hydrofluoric acid which latter can be obtained in special containers from Messrs. Oswald M'Cardell & Co., Ltd., Sudbury Hill, Harrow, Midds.
 If you use the alum solution method of superficially frosting the bulb dissolve the alum in a 5 per cent. solution of gelatine. This will have the effect of keeping the alum crystals on the glass and of retarding their faking-off.

Damp-proofing Window-sill

I AM experiencing dampness beneath a bay window, and believe that rain is seeping through the rough concrete window-sill on the outside. Can you advise me how to render this weatherproof or if I should "fill" in rough surface and finish with hard gloss paint? I would prefer the sill to be its natural colour if possible.—T. Whale (West Bromwich).

The trouble is probably due to the fact that the lower We are the trouble of the trouble of the trouble of the trouble brickwork underneath without any demp-insulating membrane, such as slates or bituminised felting between the two. This is a common defect these days. We note that you wish to retain the natural colour and a rough surface of the window-sill surround and yet, at the same time, to render it damp-proof. There is one good way, although a rather expensive one, of doing this. It consists in making-up a thin " paint " of stone-dust (of the required colour) and

hydrolysed ethyl silicate (a transparent liquid) and brushing this on to the surrounds of the window, par-ticularly outside, but, if necessary, inside the room. Choose fair weather for the job, when all the dampness has disappeared. Within a week the silicate mixture will have become rock hard, in which condition, it will be insoluble and damp-resistant, and will act as a binder for the powdered stone which has been mixed with it. When hard, the area can be brushed over with paint or treated in any other manner which you may desire. Hydrolysed ethyl silicate is not a very stable substance. It must be used within one month of its delivery. It seeps into the stone or brickwork and slowly releases silica within the pores of the work, which silica form's a sort of continuous film which is impervious and completely damp-resisting. Hydrolysed ethyl silicate can be obtained from Silicaseal, Ltd., Westgate Hill Grange, Newcastle-on-Tyne, 4, which firm will no doubt send you particulars of this substance in response to your inquiry.

doubt send you particulars of this substance in response to your inquiry. As an alternative, the stonework should be brushed liberally with raw, hot linseed oil. After one or two applications of this, the area should be given a good coating of any white or red-lead paint, which, when dry, may be given a surface coat of paint as required. The most suitable substance for your use in this case is undoubtedly the hydrolysed ethyl silicate, since it gives efficient damp-resistance without materially altering the colour or appearance of the treated area. Only its initial expense is against it for this class of work.

Covering Damp Walls

Covering Damp Walls I HAVE recently moved into a house, built in 1939, and have started interior decorations. The wall covering, instead of being the usual plaster, appears to be a very hard, smooth and impervious cement. The walls are inclined to be damp, due, I think, to condensation, as interior partition walls are as bad as exterior walls, but the condition soon clears up when the weather allows plenty of ventilation. My difficulty is in renewing wall covering. Wallpaper bubbles and soon becomes loose, and unless distemper is put it just runs down the wall. How can I treat this surface so that ordinary distemper and wallpaper can be applied, and also what should be used for filling cracks ?--K. L. Peers (Hayes).

distemper and walipaper can be appared, and also what should be used for filling cracks ?-K. L. Peers (Hayes). YOUR trouble is that your walls have been rendered with an impervious coating of material. If the walls had been of plaster the trouble would not have arisen and it is difficult for us to see why, in fact, the walls were not originally so plastered. An ordinary plastered wall absorbs a small amount of damp or moisture which is deposited on it by condensation from the atmosphere or from other sources. When the room becomes warner the absorbed moisture is again given off from the plaster and it is not noticed therein. But when the wall is not able to absorb moisture, the latter collects on the wall sufface and, in the end, begins to trickle down the wall in an unpleasant manner. To make a really good job of your walls the impervious material would have to be chipped off down to the brick-work or, at any rate, for about one inch of depth and then replaced by ordinary wall plaster, this latter being given a skim coat of Keene's white cement. This would provide a very excellent " eggshell " finish on which any colourwash or distemper or colourwash, but, usually, when a room is apt to give rise to a good deal of condensation, it is better to do without paper on the wall and to have merely a plaster or other ough-surfaced absorbent coating. To the same reason a plaster surface should never be papine from the wall any treatment be applied which will destroy the essential porosity of the plaster surface. An alternative treatment open to you is to remove the papine from the wall and then to apply several oats of an ordinary distemper in the hopes that this layer will effectively be sufficiently absorptive to deal with an excess moisture which may be present in the applied which is manufactured by Messrs. John Hall & Sons, Ltd., Hensgrove, Bristol, which, although rather expensive, is, we think, sufficiently absorptive to deal with variations of moisture contents in room atmosphere. The filting cracks in wall p

absorptive to deal with variations of moisture contents in room atmospheres. For filling cracks in wall plasters there is nothing better than wall plaster itself, ordinary coment or Keene's white cement. The edges of the cracks should be thoroughly wetted before the new filling material is put in, otherwise the dry edges of the cracks will absorb moisture too rapidly from the fresh filling material and will, in the end, result in the filling material becoming loose and falling away.

Blooming Lenses

PLEASE supply me with details of the process used in blooming optical lenses. I have considerable experience of camera and instru-ment repairs including binoculars and the removal and reassembly of the lenses present no difficulty.—M. Bardell (Sutton Coldfield).

no difficulty.—M. Bardell (Sutton Coldheld). THE "blooming" or "coating" of lenses and other optical glass surfaces is, in general, a fairly straightforward process, but it necessitates costly apparatus, for which reason it is not generally under-taken by individual workers. Essentially, the optical components are stripped of all their metal work and placed in a special holding-frame in which they are enclosed within a dome-shaped stout glass vessel which is then highly evacuated. A mineral fluoride, usually magnesium fluoride, is then

electrically heated within the same evacuated enclosure. electrically heated within the same evacuated enclosure. By this means the fluoride is, as it were, evaporated and a "mist" or "rain" of the fluoride is thus created within the enclosure. The mist of fluoride subse-quently condenses on the glass surfaces, with the result that a very thin layer or coating of the fluoride is deposited thereon in a more or less uniform layer. The coating is obtained in the crystalline condition. As such, it is perfectly transparent and it does not interfere with the direct transmission of light. It is these properties which render so valuable the deposit on the glass surface. on the glass surface.

To be of greatest efficiency, a lens, such as a camera lens, should have all its glass-to-air surfaces, at which reflection of the light rays may take place, bloomed, but more usually only the front and back lens surfaces are thus treated, because it is found that this "semi-blooming" gives fairly adequate results. The same applies to binoculars. Thus, if you want the highest degree of efficiency in any of these instruments, you will have every glass-to-air surface systematically bloomed. If otherwise, merely the first glass-to-air surface of the objective lens will be sufficient for such treatment. If you find yourself unable to undertake this optical work, it can be done for you by a firm such as Messrs. C. J. Whilems, Ltd., 116rd Optical Works, Forest Road, Barkingside, Essex. Equipment for the blooming process can be obtained from The Cambridge Instrument Co., Ltd., 13, Grosvenor Place, London, S.W.I, or from Messrs. Philip Harris & Co., Ltd., 144-146, Edmund Street, Birmingham, or from most firms of laboratory dealers specialising in optical work.

A Simple Periscope

I WISH to make a simple periscope (to be used on land, of course) and should be obliged if you would kindly forward defails.-W. Carter (Birmingham, 23).

A SIMPLE and efficient periscope can be made of thin can be made of thin wood, such as plywood, boxed up as shown in the sketch. The top and bottom ends can and bottom ends can be either square or bevelled, as shown, but in either case the two mirrors, M, must be fixed at an angle of 45 deg. Openings are arranged on opposite arranged on opposite sides and at opposite ends of the box for collecting the light rays which form the pic-ture L. For small periscopes the mirrors such as are

For small periscopes the mirrors such as are carried in ladies' hand-bags would be suitable. Obviously the height of the viewer and the height of the obstruc-tion to direct vision must determine the length of the periscope.

Making a Dress-making " Judy "

making " fudy" I WISH to make a dressmaking form, or " Judy," at home. This, apparently, will entail two processes : (a) making the mould of myself; (b) using the mould to cast the "Judy."-Can you please tell me what materials to use, and the cheapest and easiest method?--Marie Moore (Co. Sligo).

<text> T is very difficult to make for oneself the dressmaking

not be difficult now to join the two frame halves together to form a complete form for the body, and from the wire "skeleton" thus resulting, a pajer-maché-mould may be prepared by pasting or gluing newspaper sheets over the wires until an adequate thickness of paper has been built up. When dry, the newspaper form may be surface painted to give it protection and great stiffness. In this manner you will be able to create a "Judy" replica of the figure using a minimum of materials. Modern establishments which do this work use a synthetic resin moulding material which is placed over a rubber-like, skin-tight garment worn by the "subject." Moulding material of this type is "Vinamold," manu-factured by Vinyl Products, Ltd., Butter Hill, Car-shalton, Surrey, but we do not think that you, even with the aid of an assistant, would be successful in working this method.

Soft Bromide Paper

I HAVE some soft bromide paper which is of little use to me unless 1 can get it to give similar results to normal paper. Is it possible to make it more contrasty, either by a treatment before exposure, or by an addition to the de-developer, or by an after-treatment ?—F. R. Nunn (Derby).

developer, or by an after-treatment ?—F. R. Nunn (berby). We bromide papers of ex-Service origin, of which here are large quantities on sale. These materials are volve unsuitable for printing or enlarging from ordinary characteristics of a bromide paper. For example, you of contrasty or even a normal printing paper from ore which has been coated with a soft emulsion. This is a contrasty or even a normal printing paper from ore which has been coated with a soft emulsion. This is a contrasty or even a normal printing paper from ore which has been coated with a soft emulsion. This is a contrasty or even a normal printing paper from ore which has been coated with a soft emulsion. This is a contrasty or even a normal printing paper from ore which which many people have found to their ost, and no with a strong the optimistics. They require heavy, duction these ex-W.D. "soft" papers should not be sold without some assessment and statement of their haracters and potentialities. They require heavy, duction these ex-W.D. "soft" appers should not printing the contrasty negatives—the sort of negatives is fored too greatly, the entire paper will "veil" with a strong M.Q. developer, but if the development is fored too greatly, the entire paper will "veil" with a part the paper as well as possible in the ordinary way and then reduce the greyish prints in a weak hypo-intergranide solution which will have the offect of the paper as well as possible in the ordinary to the ordinary of per cent. Hypo solution until the hypo solution is preced in this solution and gendy rocked therein for bourd 15-20 minutes until their contrasts improve. But you these expedients you will never get the good clear results obtainable on contrastic grades of bromide paper.

Painting and Re-covering a Car Sunshine Roof


I WISH to re-cover the sunshine roof panel of my Standard 8 car and I also wish to change the colour to another shade of fawn to match the present finish. What kind of paint should I use for this purpose and where could I obtain a small quantity ? A paint which would also improve the weatherproofing would be preferred. - C. J. Northam (Swindon).


weatherproofing would be preferred. - C. J. Northam (Swindon). THE car roof covering fabric consists of a stout fabric base surface impregnated with a transparent synthetic resin which has probably been heat-treated by running through hot rollers in order to give it greater subility and insolubility. We take it that you do not wish to apply a mere stain to the surface of this material but an actual paint. This would, of course, cover up the grain or surface pattern of the material, but, as you say, it would certainly improve its water-resisting qualities. You have a very free choice in this matter. Having got the material well fastened down, you can apply almost any type of paint, but it is most advisable that the paint should be of good quality, having good drying properties. We recommend two thin coats of-any gloss' paint of a fabric with thick paint applica-tion, because a thick paint coating would only tend to crack and to craze under the heat of the sun and, in consequence of sudden temperature changes. Start with one thin layer of good oil paint, as above recom-mended, and only give a second coat when you think the fabric is really in need of it. In other words, keep the paint coating down to a very minimum. No priming coating is, or should be, necessary.

A Correction

WITH reference to the query by W. B. Gilmore on reflecting telescopes which appeared in the July issue.

issue. In the reply to (3) Is it possible to use a convex para-bolic mirror in place of the usual prism arrangement, the answer should have read, "In both Cassegrainian and Gregorian types of reflecting telescopes, per-forated primaries and small convex or concave secondary mirrors are used. . . ." In the published sketches, for the Newtonian (left) read "1/40th of mirror area silhouetted by prism" not one-quarter. For the Cass. or Greg. (right) read "Convex or concave secondary mirror" not convex parabolic mirror. In neither case would the figure of the secondary be parabolic.











All letters should be addressed to the Editor, "THE CYCLIST," George Newnes, Ltd., Tower House, Southampton Street, Strand, London, W.C.2.

Phone : Temple Bar 4363 Telegrams : Newnes, Rand, London

Comments of the Month By F. J. C.

Minimum Charges for Cycle Repairs THE National Association of Cycle

Traders has recently produced a schedule of minimum charges for cycle repairs. These charges relate to labour only, for it is clearly stated that "all goods supplied will be charged extra." The object behind this list is to ensure that all cycle traders conform to the standard charges and do not cut prices. The only method of ensuring this would be to publish the list of charges or to have them prominently displayed in every cycle shop. There could then be no possibilities of one dealer overcharging, which is far more important to the cyclist. Whether a dealer undercuts or not is a matter of trade policy, but in the long run will benefit the cyclist. There is nothing like free competition to keep prices down.

Some may think the charges perhaps a little on the high side. For example, a complete overhaul of cycle, taking down, examining bearings, small new parts where required, correctly adjusting, greasing, lubricating thoroughly and completing will cost the cyclist f_{11} 17s. 6d., or, say, 12½ per cent. of the cost of his machine. The basis of the charge is set out to make it appear to be a major job, but in reality the cyclist will find other charges tacked on such as replacing cone bearings and cotters. There is no definition as to what are "small new parts." To clean a bicycle costs 9s. 6d., and to dismantle it completely ready for frame repairs and enamelling, f_{11} 11s. 6d. If a gear case is fitted there is an extra charge of 6s. 3d. ; straightening the pedal spindle costs 2s. 9d., whereas straightening a crank (ordinary), " not removing," costs 1s. 3d. Surely no cycle repairer worthy of the name would straighten a crank without removing it because of risk of damage to the bottom bracket, etc.

To fit a new chain and adjust the rear wheel and brake would cost 3s., and to fit a new connecting link 1s. 3d. Some of the charges seem exorbitant, and will be honoured more in the breach than the observance; whilst in general we are in favour of standard prices for parts and for labour, we think the public should be made aware of those prices. The Ford Motor Car Company have had such a system in operation for years and owners know precisely what labour and spare parts will cost. Merely to publish a schedule of prices and not put it into the hands of the user, which is the best means of enforcing it, is to defeat its very object.

The World Buys British

NOTWITHSTANDING the competition of the Germans and the Japanese, bicycle exports have increased by over $\pounds_{2,000,000}$ during the first seven months of this year as compared with the corresponding period in 1951. The number of bicycles exported was 1,738,005. This is 151,666 more than during the first seven months of 1951. Bicycles alone brought in

\pounds 14,518,426. The total value of the industry's export was \pounds 28,109,485.

The Tour of Britain

THE Tour of Britain passed by without any untoward incident, as was naturally to be expected, except by those carping critics who have been attacking it for years, and refuse to acknowledge that they are wrong. The two national bodies have been trailed at their heels, but now that the race is over the results must give them their quietus, for the race brought a large amount of publicity to the sport, and the trade is at long last veering round to the point of view that road sport of this type is better for it than secretive time trials. Let the time trialists run their sport in the way they like, and let others run theirs as they wish.

One has only to read of the enthusiasm for cycling sport in the early part of the present century to realise what can be done. The trade then took a great interest in road racing, and no doubt open road sport would have persisted but for the shamatuerism, trade rackets, and patent frauds which were practised in connection with it. Gradually rules were framed to clean up the sport, and if these have not entirely

a long way towards it. Unfortunately in obliterating the rackets they have largely erased interest in the sport, which has been driven underground and remained there all these years.

The public is now becoming cycling conscious, and if spectacular road sport continues to develop it must, in the passage of years, do to time trials what trade rackets did to road sport in the early part of the present century.

Time trialing will always have its followers, but now that there is a choice we fear that the young, cager, up and coming generation will prefer spectacle to secrecy. They will not wish to hide their light beneath the bushel of the R.T.T.C. with its plethora of rules which give the impression that every cyclist is a potential cheat.

Cyclists-By One Who Doesn't Know THESE are the days of columnists,

THESE are the days of columnists, a stupid practice which we have copied from America. To be a successful columnist you pick on any old topic, make an Aunt Sally of it, shy verbal brickbats at it and generally show how knowledgeable and clever you are.


GORDON

A morning newspaper the other day allowed one of its columnists to deal with cyclists always a good topic when there is not a fruity murder to fill the space. This particular columnist does not break forth into rhapsodic encomiums about cyclists. He thinks that they are pests apparently because they get in his way when he is motoring. Because of this he thinks that motorists should be allowed one cyclist a year. He thinks they constitute one of the major hazards on British roads, and he labels the female cyclist as the most pernicious, although he does lay tribute at the feet of the pulchritudes by referring to them as "the tasty dish with bright eyes, pink cheeks, ruby lips, and golden hair, wearing a pair of shorts and a light shirt." The Parthian shot is that they should be "banished completely, for she makes you take your eye off the road and your mind off the serious business of operating your motor vehicle."

This represents motorists as an impressionable and salacious lot. That there are cyclists worthy of criticism, as with all other types of road user, no one will dispute, but a general lambasting of the sort to which we have referred is unjustifiable.

> Helston, Cornwall

Looking down Coiragehall Street, main throughfare of this ancient Cornish town. Here on May 8thevery year the famous Furry Dance takes place through the decorated streets.



Entrance to Dovedale. The old bridge over the Dove by Thorpe Farm. The turning into the lovely dale is just past the bridge by the old Izaak Walton Hotel.

THE National Cyclists' Union's handling of international teams has come in for criticism year after year, as far back as I can remember, and this year is no excep-tion. For the Olympic Games, all for the sake of four pounds to pay for insurance, the track team were sent out without a manager, to fend for themselves. Resultno gold medals for Britain. True, even a skilled manager may have made no difference, but the fact is that we had the raw material in the shape of riders and a good manager might have turned that into something better.

Then, in August's world's championships, the British road team were quartered 26 miles away from the racing circuit. The only time they went round the course beforehand was in a car—fine preparation for a 25-miles-an-hour world's championship race! At the finish, Brian Robinson, of Hudders-field. was convinced that he had finished eighth. British officials agreed. International officials, after studying a film of the finish, failed to mention Robinson at all.

Why no N.C.U. protest and a full enquiry? 3:

SUCCESS of the Daily Express "Tour of Great Britain," the 1,470 miles road race which finished last month (September 6th) has been the last straw which has tipped the N.C.U. scales into full-out support for road racing, and, they hope, an amalgama-tion with the "rebel" body, the British League of Racing Cyclists,

League of Racing Cyclists. Obviously, we cannot tolerate a "split" for ever, and all that remains is for a "face-saving" formula to be evolved so that both sides can say, "we've won." The rank and file of cyclists are heartily fed up with the ten years' old war between the rival unions; the Daily Express has proved that road racing is not only safe and practical, but also, properly presented a practical, but also, properly presented, a major attraction. The N.C.U. wants to get in on the band wagon, the B.L.R.C., having

proved their case, want to stay in supreme command.

A clash of personalities does not help; after all, major officials of both bodies are not prepared to relinquish their jobs. But a solution must be found, and found this winter.

WOMEN cyclists, if we are to judge from their "chief," Mrs. Evelyn Stancer, president of the Women's International Cycling Association, are demanding international recognition.

At the present time, this is rather a cry in the wilderness. There are no women's cycling events in the Olympic Games, or in the world's championships, and, until there is a flourishing women's branch of the sport in many countries there never will be.

Here in England we have a small, but highly organised, women's section of cycle sport. We have riders of the calibre of Elicen Sheridan, the Hercules professional, who is, on time alone, not far behind the major male professionals. But, numerically, the women are very much in the minority. Japan and Russia have full strength in women's cycling, but the European coun-tries who control the international voting, are not so interested.

The W.I.C.A., formed in England, has not yet achieved world-wide recognition. The girls have some remarkable performances to their credit, especially in long-distance road records, but as a public spectacle—well Herne Hill promoter, Johnnie Dennis, summed it up when he said, early in 1952, "No women's races at any major meeting."

OCTOBER is the month of cycling hill climbs. As you know, these are mostly dashes of a few hundred yards up a I in 6 slope. Does this really prove anything? Why not hill climbs of a mile or two, for example, the climb up the south western slope of Hindhead?

That enterprising club, the Charlotteville C.C. of Guildford, once tried to lay on such a hill climb, only to have it rejected by the controlling board, the Road Time Trials Council. But I maintain that a mile long climb is the real test of a cycling hill climber ... a 400 yards dash means nothing, and when you add in the hazards of a patch of wet leaves just in the marine of a patch "agony corner," winning a hill climb is just as much a matter of luck as strength.

Of course, the ideal would be a ten miles steady climb up a real mountain pass but we have no such climbs in this country.

Johnnie Dennis, the ex-journalist, who took over command of Herne Hill track, on behalf of the N.C.U., is by no means satisfied with 1952 attendances. He has worked hard to build up a steady public, but the crowds just decline to come.

The season as a whole will show a profit, he thinks, but this is not enough. He wants to see a regular 10,000 crowd, instead of the usual 3,000. Solution? A mid-week meeting, he thinks, instead of the customary Saturday afternoon. This means an evening fixture, and inevitably, floodlighting. Now, artificial lighting always enhances the thrill of any sport. . . but floodlights would cost at least £3,000. Would it pay? I agree with Dennis when he says that

Saturday afternoon meetings have had their day. The average cyclist prefers to spend his week-end away from London. A firstclass evening meeting, with floodlighting, would, I am sure, pull in the crowd. With floodlighting, why not a revival of

the Polytechnic 24 hours tandem paced race? This was a big draw in pre-war years. Motor racing at Goodwood, as in the recent 9 hours' race, has proved that crowds like their sport in the dark.


Japanese cyclists who came to Europe for the Olympic Games and the world's championships went back empty handed, as far as titles are concerned ... but with brief cases packed full of detailed specifications of continental racing bicycles. M. K. Kitazawa, vice-president of the Amateur Cycling Federation of Nippon, spent more time photographing racing bicycles than he did in snapping the efforts of his team! Jap threat to world markets is already, admitted by the leading British makers, in

so far as the utility cycle is concerned. If the Japs start turning out racing bikes up to a sufficient standard then we can really start getting worried!

As riders, however, the Japs were no worry to any competitor. Surprising this, because to any competitor. Surprising this, because cycling is quite a major sport in Japan. Their principal races are the Japanese championships, on road and track, the University championships, and the Tokio to Osaka road race, 1,000 kilometres (620 miles) in fue stages miles) in five stages.

Their two best riders are K. Tomioka, road champion of the Asiatic Games, and Kato, a 17-year-old sprinter.

Expert copyists that they are, the Japs can be counted on to turn out replicas of our best racing machines. Fortunately you can't duplicate, by machinery, riders such as Reg Harris!



THE CYCLIST

AROUND THE WHEELWORLD

"What is a Musette?"

IT was too much to hope that my reference to the use of the word "Musette" as referring to a cycle bag would pass unnoticed. In general, I am averse to importing into the English language foreign words when there is a word in our own language which would suit. I dislike the modern tendency towards so-called "Continental" fittings and bicycles, the presumption being that they are superior to British which they certainly are not. English bicycles and English fittings are superior to any others in the world, and the fact that the "Continental." fittings may be different does not make them better.

However, several readers have written to me regarding the musette. Apparently the word is derived from the Greek Muse, the goddess of song, music and poctry. The musctte by continuation became the word used to describe the container of musical sounds such as the bagpipe, if we admit that the bagpipe is a musical instrument.

A French dictionary gives several definitions, one of which is "a cloth bag which is hung on a horse's head to serve as a nose-bag for food; a cloth bag carried by soldiers to hold their provisions; a cloth or leather bag in which tools or different instruments are carried; a child's school bag." From this it is clear that the word can be

used to describe a cycle bag. But why do we wish to use it ? It has only recently crept into wish to use it ? It has only recently crept into use over here. Is it only used by those cyclists who like gaudy bicycles, with Continental fittings ? Of course, an English word would hardly do for *them*. However, my grateful thanks to Mr. S. J. Sears, of Algiers, to Mr. Thomas A. Lewis, of the Thorne Paragon C.C., and others, for writing to me on the subject. to me on the subject.

A Japanese Bicycle

THE photograph on this page, which has been sent to me by Mr. G. S. Campbelton, of Singapore, shows a bicycle made in Japan, and which is being sold in Singapore. It is adjustable for juniors or adults to ride, and it is also made to fold up so that it can be easily carried on bus or train or packed into a suitcase. It weighs 30lb., using 14in. wheels and 13in. tyres. The price is 120 dollars less 10 per cent. for cash. German junior cycles sell at 100 dollars less 10 per cent. ! Of course, the idea of the folding bicycle is not new; it was first introduced into this country many years ago and was resusci-tated by B.S.A. during the last war for military purposes. These machines will not, of course, reach the English market. Incidentally, those who are most anxious to press for higher wages in the engineering industries, of which the cycle trade forms a part, should not buy foreign goods, not even Continental fittings. They should buy British, which are higher in price because we pay proper wages in this country.

A Britisher who wants high wages and then buys foreign goods is helping himself along the road to unemployment.

Stallard Resigns from B.L.R.C.

DERCY STALLARD writes to say that in resigning as a founder and life honorary member of the B.L.R.C. some explanation is necessary. His explanation takes the form of a criticism as well as an apologia. He thought that following last year's Tour of Britain when riders ran off the course some attempt would be made to

By ICARUS

prevent a recurrence and to institute control of the following convoy. He says that his hopes have not materialised, "as complete control of everything appertaining to the event was placed in the hands of one person. He had supreme power, even to the extent of inviting foreign teams, making rules for the event, and nominating officials. It was the exercising of these powers that brought about my decision to resign. After the 'Warsaw-Berlin-Prague' I was asked by the President of the East German Cycling Body if I could obtain an invitation for them to compete in the Tour of Britain. This information was conveyed immediately upon my return to Mr. D. Peakall, promoter of the Tour, on behalf of the B.L.R.C. He informed me that an invitation had already been given to West Germany and therefore East Germany could not be entertained. I suggested that in view of the hospitality we had received



The Japanese twin-purpose bicycle.

from East Germany in the 'Warsaw-Berlin-Prague' his action was in exceedingly bad taste and detrimental to the League's interest, and to avoid political implications it would be much better to invite both or none.

"Based upon my experience of cycle racing in nine different countries, I submitted 16 recommendations for the consideration of Mr. Peakall, but not one of these was con-sidered worthy of being adopted in the form submitted.

"Although I had already spent three and a half weeks on the 'Warsaw-Berlin-Prague,' I felt that in view of the importance of this year's Tour of Britain to the B.L.R.C. it was my duty to volunteer my services for a further two and a half weeks in an effort to prevent a recurrence of last year's Scarborough-Nottingham stage. My offer to act as Assistant Director of the Course was accepted without enthusiasm, and under these circumstances it was not surprising that instead of the two open cars and four motor-cycles which I insisted were essential to control the race efficiently, I was offered a saloon with no guarantee of motor-cyclists. As I consider it quite impossible for any Tour of Britain under such conditions, I was forced to withdraw the offer of my services.



"Whilst I regret having to resign from the organisation, my resignation means nothing beside the disaster that can come to the B.L.R.C. by its refusal to use the experience available, or learn anything from last year's mistakes.

I think Stallard has made a mistake in resigning. If you believe in an organisation and feel that something is wrong with it, stay in and fight; you cannot rectify the trouble once you have resigned. Resignation merely gives unwanted publicity to grievance and achieves nothing, except to bring damage to the B.L.R.C. at a time when its differences. with other bodies are likely to be resolved.

B.L.R.C.-N.C.U. Settlement Next Year?

T the recent Congress of the Union Cycliste Internationale there was very little discussion about the B.L.R.C., but considerable concerning the position of the N.C.U. because of the admittance of unlicensed Continental riders in the recent Tour of Britain. The General Secretary of the U.C.I. stated that the president of the N.C.U. had made a personal appeal to the U.C.I. not to allow discussion on the differences between the two rival English bodies, and he expressed the view that by the next Congress there would be a final settlement between the two.

Eileen Sheridan

E ILEEN SHERIDAN continues to wipc records off Marguerite Wilson's slate, and her beating of the Liverpool-Edinburgh W.R.A. Record shows her to be a superior rider. It must be remembered that Miss Wilson made or broke records at a time when there was little to beat, and so in some cases she achieved the records easily.

The Liverpool-Edinburgh route is un-dulating but with many steep hills. Eileen's time was 10 hrs. 9 min. Frank Southall in 1935 took 10 hrs. 12 min. over the route, SO Eileen has knocked three minutes off this great rider's time. I expect Eileen to do great things within the next year, and eventually to corner all the records.

The N.C.U. and Cycle Traders


THERE are about 17,000 cycle traders in this country, and each of them has received an invitation from the N.C.U. to act as agents for their Associate Traders' enroller This scheme was originally formuscheme. lated in 1931 with the object of ensuring for the utility rider the benefits of membership. It is proposed in some of the more populous areas to organise N.C.U. Centre Meetings so that local retailers can be instructed on the details of the scheme. The retailer, of course, profits from the scheme. Associates pay 4s. a year and in return receive legal and third party insurance benefits. It is hoped that once the Associate is introduced to club life that he will become a full member and take a greater interest in club affairs.

The Cycle Show

HER MAJESTY THE QUEEN has graciously consented to be Patron of the Cycle and Motor Cycle Show at Earls Court from November 15th to 22nd. The Duke of Edinburgh will open the Show on Saturday, November 15th, at 11 a.m. The exhibition once again spans two Saturdays, and all the portents are that it will be well attended. Although cycle sales in this country have in the past year shown some decline there is now evidence of a revival.

THE CYCLIST

October, 1952



4

Fig. 1.-Stationary light for use with a dynamo.

THE ever-increasing cost of dry batteries is compelling the habitual night cyclist to look for some method of illumination other than the simple dry battery lamp.

The cycle dynamo is now the most generally popular method of providing the necessary power for lighting, but it also requires a small dry battery for use when stationary in towns and difficult traffic conditions where frequent stopping without lights would mean disaster.

The lighting problem is especially difficult for the motor-assisted cyclist who requires more powerful lighting than that available with the cycle dynamo on account of his higher speed and need for number-plate illumination. It is also difficult for the lightweight cyclist to whom the resistance offered by a cycle dynamo is a serious hindrance. The use of accumulators can overcome all

these drawbacks. Used in conjunction with the ordinary dynamo to give a good light for use when stationary, accumulators pro-vide a battery which is powerful, which can be charged from the dynamo while running, and which will provide full power running lights in the event of the breakdown of the dynamo. For the motor-assisted cyclist the accumulator may be charged continuously while running, and used at night to provide more powerful lights than those possible with a dynamo alone. For the light-weight cyclist, accumulators form a battery which will provide powerful lighting without the resistance of a dynamo, and which can be maintained much more cheaply than a dry battery by occasional charging from the mains.

The Accumulator

For this kind of work the nife accumulator has overwhelming advantages over the more common lead-acid type. The most important advantages here are: The nife accumulator is usually smaller and con-siderably lighter than the lead accumulator of the same capacity. 2. It is built to with-stand vibration. 3. It is made of steel and is very robust. 4. It is not harmed by over-charging. 5. It will hold its charge for long periods when idle.

The nife accumulator is unfortunately expensive initially, although its length of life and lack of need of attention make it more economical than the lead accumulator in the long run. They can, however, be bought on the surplus market from a few dealers in surplus radio components. The dealers in surplus radio components. The most suitable ex-Service type of accumulator is a unit made up of two cells connected in series. The connection is made by means of the outer case which is provided with a rubber sheath to prevent short circuiting the cells when several units are used together. The voltage of each cell is approximately 1.3 volts, making the voltage of the unit 2.6 volts. The capacity of each unit is about 15 ampere hours. Two of these units in series, although giving only 5.2 volts, make a battery which is quite suitable for running 6-volt bulbs. The electrolyte used in nife cells consists of a 1.19 specific gravity solu-tion of potassium hydroxide (caustic potash)

A Method of Using Accumulators in Conjunction with a Dynamo By P. J. PULLAR-STRECKER

in distilled water. This should be prepared accurately and exposed to the atmosphere as little as possible since it absorbs carbon dioxide which quickly makes it useless. The specific gravity of the electrolyte remains constant and gives no indication of the state of charge. It should be changed annually and each cell should be well rinsed with dis-tilled water. The level of the electrolyte in each cell should be maintained by the addition of distilled water from time to time. As considerable gassing takes place during charging, nife cells are nearly always fitted with valves which allow gas to escape, but do not allow carbon dioxide to enter. In the type of ex-Service unit described, this valve has been made simply by drilling a few holes in the sides of the filled cap and covering them with a rubber band. The filler cap




Fig. 2.-Lighting system for a motor-assisted bicycle.

is incorporated in the terminal of each cell. It is important to see that this rubber band is seated correctly, and that no holes are left exposed to the atmosphere.

A Stationary Light

The output of almost all modern cycle dynamos is alternating current. To make this suitable for charging the accumulator, a rectifier must be connected between the battery and the dynamo. This also serves purpose of minimising the discharge of the battery through the dynamo without the use of an expensive cut-out.

The circuit is arranged so that the full power of the dynamo can be used for lighting when travelling at low speeds, and the batteries can be brought into operation at high speeds and when about about to stop, for charging and lighting respectively. This for charging and lighting respectively. is effected by a single-pole double-throw switch (e.g. a motor-cycle dip switch) on the handlebars, which isolates the battery when not in use. The battery supplies power in place of the dynamo, i.e., to the head-lamp and the tail-lamp. Where the headlamp is of the type designed to accommodate a dry battery, a low power 6-volt bulb may be exchanged for the existing pilot lamp, and the lead to the headlamp and the lead to the dynamo joined together at the headlamp. The battery position of the headlamp switch now provides a dip position which is useful for saving the power of the battery during long stationary periods.

For the Motor-assisted Cyclist

For the motor-assisted cyclist, accumulators are used to augment the supply of electricity from the dynamo, permitting the use of larger bulbs in the head- and taillamps. Since the batteries are charged continuously while running, it is preferable to use a hub dynamo for this type of lighting.

Full-wave rectification is used as it is never necessary to supply the lamps directly from the dynamo. A switch is fitted on the handlebars to control the lights, and a second switch is included on or near the battery box to take the accumulators out of the circuit while the cycle is not in use. This is necessary because there is a slight discharge (a few milliamps) through the dynamo in spite of the fact that rectifiers are used.

For the light-weight cyclist, accumulators are simply used as a rechargeable battery to operate the lights. The lamps are controlled by a switch on the handlebars which isolates the batteries when they are not in use. To charge the batteries from the mains,

a 6.3-0-6.3-volt radio transformer may be used together with a full-wave rectifier. The filler caps should be loosened during rapid charging to allow the gases to escape freely. The rate of charging should be reduced if the temperature of the cells rises above 95° F. Charging should be continued until the voltage of each cell remains steady at 1.75-1.8 volts for at least two hours.

A battery made up of two of the ex-Service units described is used for all the above lighting arrangements. The overall measurements of the battery are $4\frac{1}{2}$ in. high x $3\frac{1}{2}$ in. wide x 3 in. thick. The battery can be mounted in any convenient position, but it should normally be upright, or almost so. A good position is underneath the junction between the crossbar and the saddle post, or behind the saddle, e.g., in the saddle bag. The rectifiers used should be of the selenium metal type. These may be obtained from most dealers in radio components. For the circuit shown in Fig. 1, the stationary light first described, a 6-volt, $\frac{1}{2}$ amp., half-wave rectifier is used. The black or green terminal is connected to the dynamo, and the red terminal to the lead joining the rear lamp and headlamp. For the circuit recommended for the motor-assisted cyclist (Fig. 2) a 6-volt bridge rectifier with a capacity of 1/2 amp. in each section should be used. The green terminals are connected to the ter-minals of the dynamo, and the two red terminals are joined together and connected to the battery. The two black terminals are joined to the frame. In this circuit a dynamo designed for a frame return system must not be used. Only a dynamo which is insulated (electrically) from the frame can be used. In the last circuit, Fig. 3, a radio heater trans-former, centre tapped, is used. The secondary former, centre tapped, is used. The secondary of this has three terminals. The outside two (marked "6.3 v.") should be connected to the two green terminals of a 6-volt full-wave rectifier. The red terminal should be connected to the positive terminal of the bettern and the voltmeter. The centre terbattery and the voltmeter. The centre ter-minal of the transformer (marked "O") is connected to the negative terminal of the battery and voltmeter.





Fig. 3:-Circuit for charging the accumulator from the mains.

Day after day ... Week after week ... Year after year.

Dunlop cycle tyres keep on proving their reliability — they are tough yet flexible to give long, economical life plus real riding comfort. For hack work, club riding or racing . . .

You'll ride more comfortably on



OUT AND ABOUT ON B.S.A. Bicycles. That's the holiday programme for Britain's most carefree and fare-free families. On their comfortable, smooth-running B.S.A.s they travel when and where they please. And when holiday time is over, B.S.A.s mean fare-free working days for Father, fare-free shopping trips for Mother and fare-free journeys to school for the children.


> But ..., all the world wants B.S.A.S. More and more go for export. Hurry to your dealer! He' may still have the model you want. Make your choice from the fully-illustrated catalogue. 9 out of every 10 B.S.A.s produced go to swell the export drive.

o B.S.A. Cycles Ltd., 12, Armoury Road, hirmingham, 11. Please send Bicycle Catalogue. NAME ...

Post this coupon TODAY

ADDRESS

It's time you had a





October 9952

THE CYCLIST

I.C.S. TRAINED MEN are in Greater Demand

than ever-Maximum production depends on high technical skill, such as that acquired by I.C.S. Students

TENS OF THOUSANDS MORE TRAINED MEN ARE URGENTLY NEEDED NOW -BUT THERE IS NO WORTH-WHILE PLACE FOR THE UNTRAINED

Ambitious men everywhere have succeeded through I.C.S. Home-Study Courses. So also can you.

The man with an I.C.S. Training in any one of the subjects listed below knows it thoroughly, completely, practically. And he knows how to apply it in his everyday work.

Accountancy Advertising Advertising Architecture Architectural Drawing Boiler Engineering Book-keeping Building Construction Building Specifications Business Training Business Training Business Management Carpentry and Joinery Chemical Engineering Chemistry, I. & O. Civil Engineering Clerk of Works Coal Mining Commercial Art Concrete Engineering Dissel Engines Draughtsmanship Drawing Office Practice

6

Electrical Engineering Electric Power, Lighting, Transmission, Traction Eng. Shop Practice Farming (Arable and Livestock) Fire Engineering Foremanship Fuel Technology Heating and Ventilation Horticulture Hydraulic Engineering Illumination Eng. Industrial Management Machine Designing Machine-Tool Work Maintenance Eng. Marine Engineers Mechanical Drawing Mechanical Engineering Mining Engineering Motor Engineering Motor Mechanics Motor Vehicle Elec. Municipal Eng. Plumbing Production Engineering Radio Engineering Radio Service Eng. Refrigeration Sales Management Sales Management Salesmanship Sanitary and Domestic Engineering Sheet-Metal Work Short-Story Writing Steat Metal Work Short-Story Writing Starctural Steelwork Surveying Television Technology Welding, Gas and Elec. Woodworking Drawing Works Engineering

Students intending to sit for examinations in Architecture, Quantitles, Civil Eng., Mech. Eng., and others, should enrol NOW for preparatory Courses. Using a specially prepared Study Programme, the student studies in his spare time, at his own pace and, with time for revision, sits with full confidence of success.

Courses are also available for most other Technical, Protessional, Commercial, and Civil Service Exams., including General Certif. of Education.

(I.C.S. Examination Students are coached until successful.) Moderate fees include ALL books required. GENEROUS DISCOUNT TO H.M. FORCES.

If you need technical training, our advice on any matter concerning your work and your career is yours for the asking—free and without obligation. Let us send our special free booklet on the subject in which you are specially interested. DON'T DELAY. Make ACTION your watchword.

The successful man DOES to-day what the failure INTENDS doing to-morrow. Write to us TO-DAY Dept. 169A, I.C.S., 71, KINGSWAY, W.C.2.

CUT HERE

INTERNATIONAL CORRESPONDENCE SCHOOLS LTD. Dept 169A, International Buildings, Kingsway, London, W.C.2. Please send me the free booklet describing your Courses in


Addresses for Overseas Readers Australia : 140, Elizabeth Street, Sydney, Egypt : 40, Sharia Abdel Khalek Sarwat Pasha, Cairo. Eire : 13, Anglesea Street, Dublin, C.4. India : Lakshmi Bldg., Sir Pherozsha Nehta Rd., Fort, Bombay. New Zealand : 182, Wakefield Street, Wellington

Address

Bombay. Bombay. New Zealand : 182, Wakefield Street, Wellington. N. Ireland : 26, Howard Street, Belfast. South Africa : 45, Shortmarket Street, Cape Town.



..... Age.....





THE "FLUXITE QUINS" AT WORK "Something's gone wrong f Something's loose l

Fetch FLUXITE 1 And switch off the juice 1 Our cooker's stone cold,

And no need to be told. The 'fridge' is cooking our goose."

For all SOLDERING work—you need FLUXITE—the paste flux —with which even dirty metals are soldered and "tinned." For the jointing of lead—without solder; and the "running" of white metal bearings—without "tinning" the bearing. It is suitable for ALL METALS—excepting ALUMINIUM.

With Fluxite joints can be "wiped" successfully that are impossible by any other method


Used for over 40 years in Government works and by leading engineers and manufacturers. Of all Ironmongers—in tins, from 1/- upwards.

• TO CYCLISTS: For, stronger wheels that will remain round' and true, here's a time-tested tip. The the spokes where they cross with fine wire 'AND SOLDER. It's simple-with FLUXITE-but IMPORTANT.



Write for Book on the ART OF "SOFT" SOLDERING and for Leaflets on CASE-HARDENING STEEL and TEMPERING TOOLS with FLUXITE. Also on "WIPED JOINTS." Price 13d, Each.

FLUXITE LTD., Bermondsey Street, S.E.I





Claremont House, Esher, Surrey. House and gardens are open to the public.

The Old Stagers

THE other week I looked on an old bicycle with more than twenty years of riding in it, and thinking what a shame it was to neglect its excellence, I brushed the dust away, gave it a dose of oil, blew up the tyres and away we went. It is perhaps a bit old fashioned in its outline and equipment, its inherited lever brakes and patched celluloid guards, but for running quality there is nothing better in my ownership. And it is remarkable how neat it emerges from many months of neglect, due I'm sure to the all-black finish quite popular in the day of its building but now, I suppose, gone for ever. It was made for me in 1931 and went on tour to Scotland within a week, and goodness knows how far it has been since. Being curious I looked up the bill, which was £11, being a special price charged by an old trade friend of mine who has since retired. He has given up work, but one of the results of that labour still goes on, and so far as I can determine goes on as purringly as when I first pressed its pedal; and remember, I have the very best of the moderns with which to compare it. The thought has entered my head to give it to some deserving youngster, but after this further association I think selfishness will win; for after all I'm not sure a gift of such a bicycle would be appreciated as such a bicycle deserves to be. No, we yearn for plate and colour, for festoons of brake wire and flimsily built festoons of brake wire and flimsily pedals with scarce a foothold to them, and if the generous mood overtakes me and the deserving case arises, I think I would rather part with a modern machine than this old mile collector that has carried me so gaily for many thousands of miles.

The Old Neglect

TT happened again in mid-May on a rough morning with rain streaking into the lap of my cape. I was on the way to work quite happily contented with my slow progress when one of my numerous car owning friends passed me, stopped until I had overtaken, and then very kindly wanted me to park the bicycle and go to town as his passenger. I assured him I was quite happy, perfectly dry, liked to feel the rain on my face, and by so progressing had a vehicle on which to

return home in my good time. "You're incorrigible," he said, "but I wish I could do it." If I like to ride a bicycle far more " You're than I like to drive a car, surely that is an individual choice with which no one should quarrel. I think many people take the line of least resistance in the first instance because car passage is more impressive and flatters their sense of importance, and it is only later in life they find out the error. Add to that notion the streak of laziness in most of us, and fundamentally you have the answer that cycling is "not the thing' among the type of folk who can, or think they can, afford a car. And yet these same folk tell me-and I know dozens of themhow lucky I am to be able to ride, and what a fool I should be to give it up. I agree, but to be able is the governing phrase, and one which ought to be in the minds of the younger generation. The certain way, per-haps the only way, is to keep on riding no matter how rich you become, and thus in preserving vitality-gently, serenely and surely -you automatically preserve health, and a kind of individual happiness that wraps you in satisfaction. Sometimes I feel it is shocking taste to give such a testimony to my own way of life, it smacks of the superior in all but the ingredients; yet how else can I promote the goodness I find in cycling? For if a man writes of his interests in finding them so excellent a way of life, he must write from conviction and often wonder why so few elderly people miss simple things that are so good. I can only tell you this is so from my own experience, and wish there were more of us to publicise the genial fascination of cycling.

A Change from Habit

WHEN I promised rather more than a year ago to take my daughter touring in Ireland, if she came on a bicycle, I had not reckoned on her enthusiasm for, the different scenes and characteristics of that land and its people. She had been talking, so that at Christmas time another lady member of my family asked me why she was cut out—her words—of the pilgrimage. "All right," I said, "get cycling fit and we'll make the affair an occasion." Since then little troubles have intervened due to breakdown in bodily structure, and I was reminded in early Spring that "a promise

was a promise so why not go in the car." It was certain this lassie could not ride a bicycle over the roads I wanted to travel and -well, what would you have done? So I have spent the greater part of June touring Ireland in a car because I made a promise, and the original conditions of it were altered by illness. Yet in a way I'm not altogether sorry at the upshot, for it proved to many friends that car travel for me is not so much prejudice as a means to take the lame over ways and into areas I have known as a cyclist since my first visit to Ireland in 1898. I went cheerfully, the only way to fulfil a promise, and at times tried to remember that motoring moderately may be the next best thing to cycling.

Service for the Future

LDERLY cycling means the kind of travel that makes for ease without any undue effort and is in no hurry to roll away the hours. We are not all built this way or the crowded cyclists on the road would be a still greater "trouble" to other users thereof; but there must be many hundreds of thoussands who could be like this, if they would, and be the happier and healthier for it. Many don't want to now; they are content to look on and be wheeled around under power, but the day will come to such when they will regret their loss of genial activity and be sorry. Some won't ride a bicycle because "it isn't done"-they are the snobs with too much money and too little sense ; but there are thousands of others with a good bicycle and the ability to ride it quietly for 60 miles, who just do not take the trouble to make a discovery for themselves and use it for their joy.

Let us persuade the older folk at a loose end to take up cycling, and urge the present young people never to give up their grip on the pastime that can serve them so well when the glory of winning or losing has departed.

The Right Bicycle

F an individual decides to take to cycling as an expression of genial travel undertaken easily, then let him or her select a bicycle for that purpose. Not a great unwieldly thing hung about with gearcase and odd gadgets, but a lightweight mount modified to fit the rider. Eschew narrow tyres for 1³gin. size, but let them be opensided and see they are fully inflated. Don't despise a slightly dropped bar, it gives you a restful position against a wind or on long slopes ; , and be sure the saddle is comfortable by being big enough to really lean on. Those skimpy seats the lads revel in, mainly for lightness, are not for the like of us who need comfort as the first consideration. for gears, let the hub or derailleur be a fourchange with a normal ratio of 60in .--ves. 60in.—with a 75in, and a couple of lower ones at about 51in, or 39in, and then you will discover how delightful it is to stroll uphill. The art of cycling is greatly con-cerned with pedalling, and if you can get 12 an hour out of a 60in. gear and be comfortable you have gone a very long way towards easy cycling. Twelve an hour is all you need, except down hill, while if you average nine to ten an hour on a riding day it is remarkable how the miles pile up without wearying and what you can see on the way. Cycling properly practised is not the joy of the first hour, but the conservation of that joy at the sixth or seventh hour of riding, and when that is attained-and it can be done by anyone of normal powersyou are a cyclist, a freeman of the road, a surveyor of the finest countryside under heaven, and the owner of an enjoyment unsurpassed.

CYCLORAMA

By H. W. ELEY

State of Street Strand Gate , Winchelsea This gate is one of three built in the 14"cent to quard the town from raids by the French

October Charm

MOST out-of-doors men love this mellow month of October. It is often grand and lovely, and my records show that I havehad, in the past, some great rides during this month, when the blackberries gleam in the hedgerows and the woodland trees are at their lovely best. What tints and hues greet one in the English countryside now that October is here ! Tawny browns, and golds, and russets . . . all making a matchless golds, and russets . . . all making a matchless panorama on the hillside, and reminding us that Mother Nature is still supreme with her palette and brush.

In the silent wood there is a carpet of brown leaves ; the grey squirrels slip quickly up the smooth trunks of the beeches and, as I enter a quiet glade, a gaudy jay darts by, squawking with raucous note. And in the warren over by Great Oaks Farm the rabbits are at their best.

"The Cyclist" in California RECENTLY I had a long and most interesting letter from a gentleman in of The Cyclist—and tells me that he is a "pen pal" of veteran F. J. Urry. My correspondent, whose forefathers sprang from English soil, plans to come to the "old country" this "fall "—and plans also to buy " old a bicycle so that he can travel the roads of England and see some of the scenes and places I have from time to time tried to describe in these notes. If and when he comes to Derbyshire he is assured of a warm welcome, and I will do my best to show him some of the beauties of this shire where the stone walls intersect the fields and where the gentle River Dove, most exquisite of English rivers, flows amid the fern-covered rocks and boulders. Maybe, in some old church register, the "Man from California" will discover traces of his English ancestors !

"Practical Mechanics" Advice Bureau COUPON This coupon is available until October 31st, 1952, and must be attached to all letters containing queries, together with 3 penny stamps. A slamped, addressed envelope must also be enclosed. Practical Mechanics. October, 1952.

served in some of our villages are the "ducking stools" of yore—reserved for poor wretches suspected of "casting the evil eye" and other mysterious forms of witchcraft; and do not for-get the "Gallow Trees"—there is one still to be seen at Inkpen Beacon in Berkshire. These grim reminders of the past indicate that the "good old days" were not all so happy and carefree as some would have us believe.

The Big Bell

I WAS much intrigued recently to read of the success of a Birmingham manufacturer of bicycle bells in America. It appears that this manufacturer is a great believer in visiting export markets in person to ascertain the precise requirements. It is an excellent idea, and I suspect that in the past far too many British firms have adopted the attitude that the man overseas should be satisfied with what the home manufacturer thinks he should have and like. This Birmingham industrialist found that in the matter of cycle bells our American cousins liked a big bell and a loud bell. He set out to make such, and the result has been a big volume of orders to the benefit of export trade and to the benefit of all the employees in this Birmingham factory. It is good to know that the small accessories in the British cycle trade are as welcome as the complete bike ! May more British firms succeed in "ringing the bell" !

It's not ALL Black!

VERYONE has heard of England's EVERYONE mas mean of the indus-"Black Country"—that scarred industrial belt of South Staffordshire where the grime of coal-getting spreads like a dismal pall over the land, and where places like Tipton, and Wednesbury, and Darlaston, and Tividale, tend to repel because of their murky grim faces. Yet all of South Stafford-

"The Good Old Days"

N these times of shortages and rationing complica-tions it is not infrequent that one hears sighs for what are usually called "the good old days." Well, I suppose that in many ways they were good, but not, I am afraid, in every respect! Along with the plenteous food (those noble sirloins of beef are often quoted!) there was dire poverty, and cheek-by-jowl with opulence in our big cities there was acute distress and suffer-ing. The punishments inflicted in the good old days were grim indeed, and I was reminded of this fact when I saw the ancient "whipping ancient "whipping post" at Haveringatte-Bower, in Essex, recently. Still pre-

shire is not black and ugly, and quite near to the pits and slag heaps there are bits of pleasant verdant land as green and inviting as any in England. Kinver Edge, near Stourbridge, is still lovely, and there are other spots which I know have been left unspoiled by the scarring hand of industry. It may seem strange to suggest a "Black Country" tour ... but why not? He knows not England who only knows sunny Devon and leafy Warwickshire, and the glories of the Lakes; and these places in the "Black Country" have a character all their own Tradition and creftmenetic activity own. Tradition and craftsmanship are woven into all the "trades," and it is quite fascinating, for instance, to visit the chainmaking industry at Cradley Heath. Yes ! In the very shadow of the red forges there is green beauty and loveliness, and it is a libel on South Staffordshire to say that it is all grim and repellant. Ancient history is there, too, for Dudley Castle still stands as a reminder of days before coal was found in this part of our land.

Road Safety

THIS year has seen all sorts of activities launched in connection with road safety, and I see that the Pedal Club at one of its meetings invited five cycling M.P.s to attend and enter into a discussion about ways and means of promoting safer road travel. I note that Miss Elaine Burton, who is the Member for Coventry South, had some-thing to say about women's cycling garb, and advocated the universal wearing of shorts, and condemned skirts. Well, I do not myself see many women riders in skirts these days and, in fact, one of the good things about modern cycling is the freedom achieved in connection with clothes. I look back a long way and see again those irksome cycling clothes of the '90s, and contrast the styles then with the easy, free and attractive garb affected by the woman rider of to-day. Mr. Tom Fraser, the Member for Hamilton, suggested that big lorries should be banned from roads from 25 to 28ft. wide, the goods going by train instead of lorry. A somewhat shattering remark came from Mr. G. H. R Rogers, North Kensington's Member, who Rogers, North Kensington's Member, who admitted that when he got into a car he became "a fiend in human form"! This is strong language, but we cyclists have always had a sneaking idea that "something happens" to a man when he becomes a motorist! The pedestrian and the cyclist become "nuisances"—to be hooted at as if they possessed no "road rights"! ? Road safety is still one of the vital issues facing. this country, and much has still to be done before we can be complacent about accidents on the rolling roads of old England.

Holiday Memories

DURING the summer I was happy to receive several cards from cyclists away on holiday tours. It was good to be remembered in this way. Some of my "pen friends" had selected sunny southern rides and I received views of notable spots in Devon and Cornwall, and Dorset and Sussex. Other riders sent me views of northern beauty spots, and quite a few had chosen to tour in Yorkshire and Northumberland. All the brief comments indicated happy hours in the saddle, and the charm and freedom of the open road. Thanks to all—who, at some wayside inn, took the trouble to mail me a card of greeting !

Published about the 30th of each month by GEORGE NEWNES, LIMITED, Tower House, Southampton Street, Strand, London, W.C.2, and Printed in England by W. Speaight & Sons, Ltd., Exmoor Street, London, W.10. Sole Agents for Australia and New Zealand-Gordon & Gotch (A/sia), Ltd. Sole Agents for South Africa-Central News Agency, Ltd. Subscription Rate (including postage): For one year, Inland and Abroad 14s. (Canada 13s.). Registered at the G.P.O. for transmission by Canadian Magazine Post.

HOME CONSTRUCTORS! MODELMAKERS! HANDYMEN!

SANDING & POLISHI - the NEW, Easy, Rapid E Profitable Way /

No.6 SET

This Kit is only a small part of the complete Wolf Cub Home Constructor Outfit. A comprehensive power workshop for drilling, grinding, polishing, sawing, sanding, wood turning, etc., etc.

WOLF ELECTRIC TOOLS LTD TELEPHONE : PERIVALE 5631-4

PIONEER WORKS

HANGER LANE LONDON W.5 BRISTOL GLASGOW BRANCHES : BIRMINGHAM · MANCHESTER

We shall be pleased to see you at our STAND No. 29 WESTMINSTER where our technical staff will be only

too pleased to help and advise you

Model Engineer Exhibition, NEW ROYAL HORTICULTURAL HALL, October 20-29th

★ CONTENTS OF No. 6 SET AS ABOVE-DRILL EXTRA

• Write at once for fully illustrated brochure

AMAZING ADAPTABILITY

LAMBSWOOL

SANDING DISCS

"PROFITABLE PLEASURE"

BONNET

FLEXIBLE RUBBER BACKING DISC

UNIVERSAL SIDE HANDLE

Build your Cub Drill into

a fine Saw Bench-add a few parts and hey presto!

you've a splendid Lathe.

Please do not fail to inspect the athe

GAP BED, BACK GEARED. COMPOUND REST, RACK FEED,

SET OVER TAILSTOCK

12%" BETWEEN CENTRES

THE	" Z Y	'TO'	33"	LAT	THE
with m	any	valua	able	refin	ements
Height of co				i	3 in.
Distance be			• • •	***	124 in.
Height from				***	4] in. 2 in.
Height from			•••	***	8 T.P.I.
Headstock					ĝ in.
Tailstock B					8 In.
Headstock					in.flatbelt
Faceplate, d					
Overall len	eth of L	ache			30 in.
Change Wh	eels:20), 25, 30	, 35, 40	45, 50,	55, 60, 65.
		a low sector	and f	"hamen	Wheele

Back Geared Guards and Change Wheels, together with Catch Plate and Finished Back Plate for Chuck are all included

CASH PRICE £28/1/0

it it is more convenient for you to purchase on deferred terms please ask at stand for details, or send a postcard for quotation.

341, 343, 345, OLD STREET, LONDON, E.C.1 Telephone : CLERKENWELL 8301 (Ten Lines)

'Ilustrated brochure sent free and post free on request.

TYZACK & SON

Free Guide — SUCCESS IN ENGINEERING

One of the following Courses taken quietly at home in your spare time can be the means of securing substantial well-paid promotion in your present calling, or entry into a more congenial career with better prospects.

ENGINEERING, RADIO, AERO, ETC.

Aero. Draughtsmanship
Jig & Tool DesignElec. Draught
MachineJig & Tool & Die Design
Sheet MetalworkMachine
MachineSheet MetalworkStructural
StructuralAutomobile Repairs
Garage Management
Works M'gmnt. & Admin.
Practical Foremanship
Ratefixing & Estimating
Tractical Foremanship
Mathemating Telecommu
Time & Motion Study
Engineering Inspection
Metallurgy
Radio Servy
Refrigeration
Steam Engine Technology
Diesel Engine Technology
Diesel Engine TechnologyElect. Draught
Mathematine
Television
Generators
Aircraft Mathematic
Maintenance Engineering
Diesel Engine Technology
Ordnance Survey Dr'ship

Elec. Draughtsmanship Machine " Automobile " Structural " R/F Concrete " Structural Engineering Mathematics (all stages) Radio Technology Telecommunications Wiring & Installation Television Radio Servicing Generators & Motors Generators & Motors Generation & Supply Aircraft Mainten. Licences Aerodynamics Electrical Design vey Dr'ship

BUILDING AND STRUCTURAL

L.I.O.B. A.M.I.S.E. Building Construction Costs & Accounts Surveying & Levelling Clerk of Works Quantity Surveying

A.R.San.I. L.A.B.S.S. Builders' Quantities Carpentry & Joinery Building Inspector Building Draughtsmanship Heating and Ventilating

GENERAL, LOCAL GOVERNMENT, ETC.

Gen. Cert. of Education Book-keeping (all stages) College of Preceptors Woodwork Teacher Metalwork Teacher Housing Manager (A.1.Hsg.)


Common, Prelim, Exam. A.C.I.S., A.C.C.S. A.C.W.A. (Costing) School Attendance Officer Sanitary Inspector Civil Service Exams.

BECOME A DRAUGHTSMAN-LEARN AT HOME AND EARN BIG MONEY

Men and Youths urgently wanted for well paid positions as Draughtsmen, Inspectors, etc., in Aero, Jig and Tool, Press Tool, Electrical, Mechanical and other Branches of



Engineering. Practical experience is unnecessary for those who are willing to learn—our Guaranteed "Home Study" courses will get you in. Those already engaged in the General Drawing Office should study some specialised Branch such as Jig and Tool or Press Tool Work and so considerably increase their scope and earning capacity.





FOUNDED 1885 - FOREMOST TODAY

132-PAGE BOOK FREE! SEND FOR YOUR COPY

This remarkable FREE GUIDE explains :

- Openings, prospects, salaries, etc., in Draughtsmanship and in all other branches of Engineering and Building.
- How to obtain money-making technical qualifications through special RAPID FULLY-GUARANTEED COURSES.

MANY INTERESTING COURSES TO SELECT FROM !

A.M.I.Mech.E.,	A.M.I.M.í.,
A.M.Brit.I.R.E.	A.M.I.P.E.,
A.M.I.C.E.,	A.M.I.Struct.E.,
A.M.I.Mun.E.	M.R.San.I.
A.M.I.E.D.,	A.F.R.Ae.S.,
London B.Sc., D	Jegrees.

Fully guaranteed postal courses for all the above and many other examinations and careers. Fully described in the New Free Guide.



THE ACID TEST OF TUTORIAL EFFICIENCY SUCCESS-OR NO FEE

We definitely guarantee that if you fail to pass the examination for which you are preparing under our guidance, or if you are not satisfied in every way with our tutorial service—then your Tuition Fee will be returned in full and without question. This is surely the acid test of tutorial efficiency.

If you have ambition you must investigate the Tutorial and Employment services we offer. Founded in 1885, our success record is unapproachable.



1	TO: NATIONAL INSTITUTE OF ENGINEERING Dept. 29), 148-150, Holborn, London, E.C.I
	Please Forward your Free Guide to NAME ADDRESS
	My general interest is in : (1) ENGINEERING (Place a cross against (2) AERO (3) RADIO (4) BUILDING (the branches in which (5) MUNICIPAL WORK you are interested.) The subject of examination in which 1 am especially interested is

To be filled in where you already have a special preference. (11d. stamp only required if unsealed envelope used.)